




# Inxpect SRE 200 Series

**SRE - Safety Radar Equipment**



**Instruction manual**  
**v1.10 - EN**

Original instructions



**WARNING!** Anyone who uses this system must read the instruction manual to ensure safety. Read and adhere to the "Safety information" chapter in its entirety before using the system for the first time.

Copyright © 2021-2025, Inxpect SpA

All rights reserved in all countries.

Any distribution, alteration, translation or reproduction, partial or total, of this document is strictly prohibited unless with prior authorization in writing from Inxpect SpA, with the following exceptions:

- Printing the document in its original format, totally or partially.
- Transferring the document on websites or other electronic systems.
- Copying contents without any modification and stating Inxpect SpA as copyright owner.

Inxpect SpA reserves the right to make modifications or improvements to the relative documentation without prior notice.

Requests for authorizations, additional copies of this manual or technical information about this manual must be addressed to:

Inxpect SpA  
Via Serpente, 91  
25131 Brescia (BS)  
Italy  
[safety-support@inxpect.com](mailto:safety-support@inxpect.com)  
+39 030 5785105

# Contents

<b>Glossary of terms</b>	<b>vi</b>
<b>1. Introduction</b>	<b>9</b>
<b>1.1 This manual</b>	<b>9</b>
1.1.1 Objectives of this instruction manual	9
1.1.2 Obligations with regard to this manual	9
1.1.3 Provided documentation	9
1.1.4 Instruction manual updates	10
1.1.5 Intended users of this instruction manual	10
<b>1.2 Safety</b>	<b>11</b>
1.2.1 Safety information	11
1.2.2 Conformity	14
<b>2. Get to know Inxpect SRE 200 Series</b>	<b>15</b>
<b>2.1 System components</b>	<b>15</b>
2.1.1 Inxpect SRE 200 Series	15
2.1.2 Control units	17
2.1.3 Sensors	19
2.1.4 Configuration tools	21
<b>2.2 Functioning principles</b>	<b>22</b>
2.2.1 Sensor functioning principles	22
2.2.2 Field of view	23
2.2.3 Detection fields	23
<b>2.3 Sensing safety functions</b>	<b>26</b>
2.3.1 Safety working modes and safety functions	26
2.3.2 Safety working mode: Access detection and restart prevention (default)	26
2.3.3 Safety working mode: Always-on access detection	27
2.3.4 Safety working mode: Always-on restart prevention	28
<b>2.4 Additional safety functions</b>	<b>29</b>
2.4.1 Stop signal	29
2.4.2 Restart signal	29
2.4.3 Muting	32
2.4.4 Dynamic system configuration	34
2.4.5 Fieldbus controlled	36
<b>2.5 Other functions</b>	<b>37</b>
2.5.1 Restart prevention function: static object detection option	37
2.5.2 Anti-tampering functions: anti-rotation around axes	38
2.5.3 Anti-tampering functions: anti-masking	39
2.5.4 System recondition	41
2.5.5 Electromagnetic robustness	42
2.5.6 Surface moisture robustness	42
<b>2.6 Applications</b>	<b>43</b>
2.6.1 Basic concepts	43
2.6.2 Stationary application	44
2.6.3 Mobile application	44
<b>2.7 Digital I/O interfaces</b>	<b>44</b>
2.7.1 Digital inputs	45
2.7.2 Digital outputs	46
<b>2.8 Data exchange interfaces</b>	<b>49</b>
2.8.1 Fieldbus communication (PROFIsafe)	49
2.8.2 Fieldbus communication (Safety over EtherCAT® - FSoE)	52
2.8.3 Fieldbus communication (CIP Safety™ on EtherNet/IP™)	53
2.8.4 MODBUS communication	55

<b>3. Installation and usage</b>	<b>57</b>
<b>3.1 Installation and use procedures</b>	<b>57</b>
3.1.1 Before installation	57
3.1.2 Install Inxpect SRE 200 Series	57
3.1.3 Set the sensor inclination with a 1° precision	64
3.1.4 Configure Inxpect SRE 200 Series	67
3.1.5 Validate the safety functions	68
3.1.6 Fieldbus network integration	71
3.1.7 Other procedures	72
<b>3.2 Use Inxpect Safety application</b>	<b>73</b>
3.2.1 Get to know Inxpect Safety	73
3.2.2 Configure the system	74
3.2.3 Validate the safety functions	76
3.2.4 Manage the configuration	76
<b>3.3 Use Inxpect Safety Studio application</b>	<b>77</b>
3.3.1 Get to know Inxpect Safety Studio	78
3.3.2 Configure the system	78
3.3.3 Manage the configuration	78
<b>4. Maintenance and troubleshooting</b>	<b>80</b>
<b>4.1 LEDs</b>	<b>80</b>
4.1.1 Control unit status LEDs	80
4.1.2 Control unit Fieldbus LEDs	81
4.1.3 Sensor status LEDs	84
<b>4.2 Troubleshooting</b>	<b>84</b>
4.2.1 Troubleshooting procedures	84
4.2.2 Event log management	88
4.2.3 INFO events	92
4.2.4 ERROR events (control unit)	94
4.2.5 ERROR events (sensor)	96
4.2.6 ERROR events (CAN bus)	98
4.2.7 Auto-resume	98
<b>4.3 Maintenance</b>	<b>99</b>
4.3.1 Planned maintenance	99
4.3.2 Extraordinary maintenance	99
<b>5. Technical references</b>	<b>102</b>
<b>5.1 Data and parameters</b>	<b>102</b>
5.1.1 Technical data	103
5.1.2 Digital input signals	108
5.1.3 Control units layout	118
5.1.4 Control unit parameters	121
5.1.5 Target position angle conventions	122
5.1.6 Separation distance calculation	123
<b>5.2 Electrical installation</b>	<b>126</b>
5.2.1 Terminal blocks and connector pin-outs	127
5.2.2 Electrical connections	129
<b>6. Appendix A: sensor lines</b>	<b>137</b>
<b>6.1 Core line sensors: S201A</b>	<b>137</b>
6.1.1 Main features	137
6.1.2 Sensor field of view	138
6.1.3 Installation recommendations for stationary application	140
6.1.4 Installation recommendations for mobile application	142
6.1.5 Range of distances	143

6.1.6 Configuration parameters .....	144
<b>6.2 Pro line sensors: S201A-W and S203A-W .....</b>	<b>147</b>
6.2.1 Main features .....	147
6.2.2 Sensor field of view .....	149
6.2.3 Installation recommendations for stationary application .....	153
6.2.4 Installation recommendations for mobile application .....	156
6.2.5 Range of distances .....	157
6.2.6 Configuration parameters .....	158
6.2.7 Classic shape .....	159
6.2.8 Corridor shape .....	160
<b>6.3 Omni line sensors: S202A-MC1, S202A-MC2, S202A-MC4 .....</b>	<b>161</b>
6.3.1 Main features .....	161
6.3.2 Sensor field of view .....	162
6.3.3 Installation recommendations for stationary application .....	163
6.3.4 Installation recommendations for mobile application .....	164
6.3.5 Configuration parameters .....	164
6.3.6 Classic shape .....	166
6.3.7 Corridor shape .....	168
6.3.8 Range of distances .....	170
6.3.9 Cuboid shape .....	172
<b>6.4 Plug&amp;Safe sensors: S202A-MS .....</b>	<b>173</b>
6.4.1 Main features .....	173
6.4.2 Installation recommendations .....	174
6.4.3 Configuration parameters .....	174
<b>6.5 Plug&amp;Safe sensors: S202A-MV .....</b>	<b>175</b>
6.5.1 Main features .....	176
6.5.2 Installation recommendations .....	176
6.5.3 Configuration parameters .....	177
<b>7. Appendix B .....</b>	<b>179</b>
<b>7.1 Other information .....</b>	<b>179</b>
7.1.1 System software .....	179
7.1.2 Disposal .....	180
7.1.3 Service and warranty .....	180
7.1.4 Intellectual property .....	180
7.1.5 Checklist for installing ESPE .....	181

# Glossary of terms

## A

---

### **Activated output (ON-state)**

Output that switches from OFF to ON-state.

## D

---

### **Dangerous area**

Area to be monitored because it is dangerous for people.

### **Deactivated output (OFF-state)**

Output that switches from ON to OFF-state.

### **Detection distance x**

Depth of the field of view configured for detection field x.

### **Detection field x**

Portion of the field of view of the sensor. Detection field 1 is the field closer to the sensor.

### **Detection signal group 1**

Output signal (dual channel) that describes the monitoring status of the detection fields belonging to group 1.

### **Detection signal group 2**

Output signal (dual channel) that describes the monitoring status of the detection fields belonging to group 2.

### **Detection signal x**

Output signal (dual channel) that describes the monitoring status of the detection field x.

### **Detection warning group 1**

Output signal (single channel) that describes the monitoring status of the detection fields belonging to group 1.

### **Detection warning group 2**

Output signal (single channel) that describes the monitoring status of the detection fields belonging to group 2.

### **Detection warning x**

Output signal (single channel) that describes the monitoring status of the detection field x.

**E****ESPE (Electro-Sensitive Protective Equipment)**

Device or system of devices used for the safety-related detection of people or parts of the body. ESPEs provide personal protection at machines and plants/systems where there is a risk of physical injury. These devices/systems cause the machinery or plant/system to switch over to a safe status before a person is exposed to a dangerous situation.

**F****Field of view**

Sensor area within which the detection field/s can be defined.

**Fieldset**

Structure of the field of view which can be composed of up to four detection fields.

**FMCW**

Frequency Modulated Continuous Wave

**G****Gray area**

Area of the field of view where detection or not of a moving object/person depends on the characteristics of the same object itself.

**H****Horizontal angular coverage**

Property of the field of view that corresponds to the coverage on the horizontal plane.

**I****Inclination**

Sensor rotation around the y-axis. The sensor inclination is the angle between a line perpendicular to the sensor and a line parallel to the ground.

**M****Machinery**

The system for which the dangerous area is monitored.

**Monitored area**

Area that is monitored by Inxpect SRE 200 Series. It is composed of all the fields of all the sensors.

**O****OSSD**

Output Signal Switching Device

## R

---

### RCS

Radar Cross-Section. Measure of how detectable an object is by radar. It depends, among other factors, on the material, dimension and position of the object.

### Reference plane

Plane where the person to be detected walks or stands.

## S

---

### Safe state

System state for motion detection, failure, stop signal or configuration in progress. If the system is in this state, the machinery system must put the area into a safe condition and/or prevent restarting of the machinery.

### System application

Configuration tool to configure and validate the system.

## V

---

### Vertical angular coverage

Property of the field of view that corresponds to the coverage on the vertical plane.

# 1. Introduction

## Contents

This part includes the following topics:

1.1 This manual .....	9
1.2 Safety .....	11

## 1.1 This manual

### 1.1.1 Objectives of this instruction manual

This manual explains how to integrate Inxpect SRE 200 Series to safeguard the machinery operators and how to install, use and maintain them safely.

This document includes all the information as Safety Manual according to IEC 61508-2/3 Annex D. Please refer in particular to "Safety parameters" on page 103 and to "System software" on page 179.

The functioning and safety of the machinery to which Inxpect SRE 200 Series is connected is out of the scope of this document.

### 1.1.2 Obligations with regard to this manual



**NOTICE:** this manual is an integral part of the product and must be kept for its entire working life.

It must be consulted for all situations related to the life cycle of the product, from its delivery to decommissioning.

It must be stored so that it is accessible to operators, in a clean location and in good condition.

In the event of manual loss or damage, contact Technical Support (see "Service and warranty" on page 180).

Always make the manual available for consultation when the equipment is sold.

### 1.1.3 Provided documentation

The following documents are downloadable from the site <https://tools.inxpect.com>.

Document	Code	Date
Instruction manual (this manual)	Inxpect SAF-IM-200S_7_00047_en	DEC 2025
Instruction manual - 9 meters range sensors	Inxpect SAF-IM-200S_9m_7_00240_en	DEC 2025
Installation instructions	Inxpect SAF-MI-100S-200S_26000041_7_00046_multi	OCT 2025
PROFIsafe communication Reference guide	Inxpect 100S_200S PROFIsafe RG_7_00067_en	DEC 2025
FSoE communication Reference guide	Inxpect 100S_200S FSoE RG_7_00237_en	DEC 2025
CIP Safety communication Reference guide	Inxpect 100S_200S CIP RG_7_00326_en	DEC 2025
MODBUS communication Reference guide	Inxpect 100S_200S MODBUS RG_7_00075_en	DEC 2025
National configuration addendum	Inxpect 200S National configurations addendum_7_00079_multi	-
Inxpect Safety Studio User manual	Inxpect SAF-UM-00434_en	AGO 2025

Document	Code	Date
Cable validator	Inxpect 100S_200S Cable Validator tool_7_00066_en	-
200S Inxpect Spare Parts	Inxpect 200S Spare Parts_7_00330_en	-

## 1.1.4 Instruction manual updates

Publication date	Code	Hardware version	Firmware version	Updates
DEC 2025	Inxpect SAF-IM-200S_7_00047_en_v1.10	<p>Control units:</p> <ul style="list-style-type: none"> <li>Type A: 2.3</li> <li>Type B: 2.4</li> </ul> <p>Sensors:</p> <ul style="list-style-type: none"> <li>S201A model: 2.2</li> <li>S203A model : 1.0</li> <li>S202A model: 1.1</li> </ul>	<p>Control units:</p> <ul style="list-style-type: none"> <li>Core Line: 2.0.1</li> <li>eXtended Line: 2.1.1</li> </ul> <p>Sensors:</p> <ul style="list-style-type: none"> <li>S201A: 3.2</li> <li>S201A-W: 5.1</li> <li>S203A-W: 5.1</li> <li>S202A: 1.0</li> </ul>	<p>Added sensors: S202A-MC1, S202A-MC2, S202A-MC4.</p> <p>Added screw specifications for 3-axis bracket, see "Pin Hex button head security screw" on page 106.</p> <p>Added Siemens PLC and TIA Portal compatibility, see "Siemens PLC and TIA Portal compatibility" on page 49.</p>
SEP 2025	Inxpect SAF-IM-200S_5m_7_00047_en_v1.9	<p>Control units:</p> <ul style="list-style-type: none"> <li>Type A: 2.3</li> <li>Type B: 2.4</li> </ul> <p>Sensors:</p> <ul style="list-style-type: none"> <li>S201A model: 2.2</li> <li>S203A model : 1.0</li> <li>S202A model: 1.1</li> </ul>	<p>Control units:</p> <ul style="list-style-type: none"> <li>Core Line: 2.0.1</li> <li>eXtended Line: 2.1.1</li> </ul> <p>Sensors:</p> <ul style="list-style-type: none"> <li>S201A: 3.2</li> <li>S201A-W: 5.1</li> <li>S203A-W: 5.1</li> <li>S202A: 1.0</li> </ul>	<p>Added Always-on restart prevention safety working mode.</p> <p>Reorganization of the manual content.</p> <p>Added Surface moisture robustness function.</p> <p>Renamed sensor axes.</p> <p>Integrated S202A sensors position and configuration.</p> <p>Added US patents.</p> <p>Updated Operating system requirements.</p> <p>Made explicit control unit lines.</p> <p>Removed Environmental robustness function.</p> <p>Removed "5m sensors" denomination.</p>
JUN 2025	Inxpect SAF-IM-200S_5m_7_00047_en_v1.8	<p>Control units</p> <ul style="list-style-type: none"> <li>Type A: 2.3</li> <li>Type B: 2.4</li> </ul> <p>Sensors:</p> <ul style="list-style-type: none"> <li>S201A model: 2.2</li> <li>S203A model : 1.0</li> <li>S202A model: 1.1</li> </ul>	<p>Control units:</p> <ul style="list-style-type: none"> <li>C201A-PNS, C201A-F, C202A, C203A, C201B-P, C201B-F, C202B, C203B: 2.0.1</li> <li>C201A-PX1, C201A-FX1, C202A-X1, C203A-X1, C201B-PX1, C201B-FX1, C201B-C, C202B-X1, C203B-X1: 2.1.1</li> </ul> <p>Sensors:</p> <ul style="list-style-type: none"> <li>S201A: 3.2</li> <li>S201A-W: 5.1</li> <li>S203A-W: 5.1</li> <li>S202A: 1.0</li> </ul>	<p>Added Anti-masking reference saving and Anti-rotation reference saving digital inputs</p> <p>Added sensors: S202A-MS and S202A-MV.</p> <p>Added Inxpect Safety Studio application.</p>

**Note:** the firmware of the control unit can be updated through the system application. The latest firmware version available contains the features described in the manual at the system level. The sensor firmware cannot be updated.

**NOTICE:** control unit firmware update can be performed only to firmware version of the same production line.

## 1.1.5 Intended users of this instruction manual

The recipients of the instruction manual are:

- the machinery manufacturer onto which the system will be installed
- system installer
- machinery maintenance technician

# 1.2 SAFETY

## 1.2.1 Safety information

### 1.2.1.1 SAFETY MESSAGES

Warnings related to the safety of the user and of the equipment as envisaged in this document are as follows:

 **WARNING!** Indicates a hazardous situation which, if not avoided, may cause death or serious injury.

**NOTICE:** indicates obligations that if not observed may cause harm to the equipment.

### 1.2.1.2 SAFETY SYMBOLS ON THE PRODUCT

 This symbol marked on the product indicates that the manual must be consulted. In particular, pay attention to the following activities:

- wiring of the connections (see "Terminal blocks and connector pin-outs" on page 127 and "Electrical connections" on page 129)
- cable operating temperature (see "Terminal blocks and connector pin-outs" on page 127)
- control unit cover, which was subjected to a low energy impact test (see "Technical data" on page 103)

### 1.2.1.3 PERSONNEL SKILLS

The recipients of this manual and the skills required for each activity presented herein are as follows:

Recipient	Assignments	Skills
Machinery manufacturer	<ul style="list-style-type: none"> <li>• defines which protective devices should be installed and sets the installation specifications</li> </ul>	<ul style="list-style-type: none"> <li>• knowledge of significant hazards of the machinery that must be reduced based on risk assessment</li> <li>• knowledge of the entire machinery safety system and the system on which it is installed</li> </ul>
Protection system installer	<ul style="list-style-type: none"> <li>• installs the system</li> <li>• configures the system</li> <li>• prints configuration reports</li> </ul>	<ul style="list-style-type: none"> <li>• advanced technical knowledge in the electrical and industrial safety fields</li> <li>• knowledge of the dimensions of the dangerous area of the machinery to be monitored</li> <li>• receives instructions from the machinery manufacturer</li> </ul>
Machinery maintenance technician	<ul style="list-style-type: none"> <li>• performs maintenance on the system</li> </ul>	<ul style="list-style-type: none"> <li>• advanced technical knowledge in the electrical and industrial safety fields</li> </ul>

### 1.2.1.4 SAFETY ASSESSMENT

Before using a device, a safety assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfills the functional safety requirements in accordance with the standards stated in "Standards and Directives" on page 14. However, this does not guarantee the functional safety of the overall plant/machinery. To achieve the relevant safety level of the overall plant/machinery's required safety, each safety function needs to be considered separately.

### 1.2.1.5 INTENDED USE

Inxpect SRE 200 Series is a human body detection system, certified SIL 2 according to IEC/EN 62061, PL d according to EN ISO 13849-1 and Performance Class D according to IEC TS 62998-1.

It performs the following safety functions:

- **Access detection function:** access of one or more persons to a hazardous area transitions the system to safe state to stop the moving parts of the machinery.
- **Restart prevention function:** prevents unexpected starting or restarting of the machinery. Detection of motion within the dangerous area maintains the system safe state to prevent machinery starting.

It performs the following additional safety functions:

- **Stop signal** (Category 3, according to EN ISO 13849-1): it forces the system transition to safe state (see "Stop signal" on page 29).
- **Restart signal** (Category 3, according to EN ISO 13849-1, Category 2, according to EN ISO 13849-1 using single channel digital output): it enables the system transition from safe state to normal state and to switch to ON-state the safety outputs related to all the detection fields with no motion detected (see "Restart signal" on page 29).
- **Muting** (Category 3, according to EN ISO 13849-1): it inhibits the detection capability of one or a group of sensors (see "Muting" on page 32).
- **Dynamic configuration switch** (Category 3, according to EN ISO 13849-1): it allows the dynamic switch among previously set configurations (see "Dynamic system configuration" on page 34).
- **Fieldbus controlled** (Category 3, according to EN ISO 13849-1, Category 2, according to EN ISO 13849-1 using single channel digital output): it monitors the input status through Fieldbus communication (see "Fieldbus controlled" on page 36).



**WARNING! the following faults makes the Fieldbus controlled additional safety function unavailable: POWER ERROR, TEMPERATURE ERROR, FIELDBUS ERROR, PERIPHERAL ERROR, FEE ERROR and FLASH ERROR.**



**WARNING! only for Stop signal, Restart signal, Muting and Dynamic configuration switch. Any fault on the sensors or the control unit brings the system to the safe state and makes the additional safety functions unavailable.**

Inxpect SRE 200 Series is suitable for protecting the human body in the following scenarios:

- dangerous area protection in stationary and mobile applications
- indoor and outdoor applications

Inxpect SRE 200 Series meets requirements of applications safety functions that require a risk reduction level of:

- up to SIL 2, HFT = 0 according to IEC/EN 62061
- up to PL d, Category 3 according to EN ISO 13849-1
- up to Performance Class D according to IEC TS 62998-1

Inxpect SRE 200 Series, in combination with additional risk reduction means, can be used for applications safety functions that require higher risk reduction levels.

### 1.2.1.6 IMPROPER USE



**WARNING! Unauthorized modifications may compromise the safety performance of the product. Unless explicitly specified in this document, do not attempt to repair, disassemble, or otherwise interfere with the product.**

The following is deemed improper use in particular:

- any component, technical or electrical modification to the product
- use of the product outside the areas described in this document
- use of the product outside the technical details, see "Technical data" on page 103

### 1.2.1.7 EMC-COMPLIANT ELECTRICAL INSTALLATION

**NOTICE:** The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

### 1.2.1.8 GENERAL WARNINGS

- Incorrect installation and configuration of the system decreases or inhibits the protective function of the system. Follow the instructions provided in this manual for correct installation, configuration and validation of the system.
- Changes to the system configuration may compromise the protective function of the system. After any changes made to the configuration, validate correct functioning of the system by following the instructions provided in this manual.
- If the system configuration allows access to the dangerous area without detection, implement additional safety measures (e.g., guards).
- The presence of static objects, in particular metallic objects, within the field of view may limit the efficiency of sensor detection. Keep the sensor field of view unobstructed.
- The system protection level (SIL 2, PL d) must be compatible with the requirements set forth in the risk assessment.
- Check that the temperature of the areas where the system is stored and installed is compatible with the storage and operating temperatures indicated in the technical data of this manual.
- Radiation from this device does not interfere with pacemakers or other medical devices.

### 1.2.1.9 WARNINGS FOR THE RESTART PREVENTION FUNCTION

- The restart prevention function is not guaranteed in blind spots. If required by the risk assessment, implement adequate safety measures in those areas.
- Machinery restarting must be enabled only in safe conditions. The button for the restart signal, when needed, must be installed:
  - outside of the dangerous area
  - not accessible from the dangerous area
  - in a point where the dangerous area is fully visible

### 1.2.1.10 RESPONSIBILITY

The machinery manufacturer and system installer are responsible for the operations listed below:

- Providing adequate integration of the safety output signals of the system.
- Checking the monitored area of the system and validating it based on the needs of the application and risk assessment.
- Following the instructions provided in this manual.

### 1.2.1.11 LIMITS

- If the static object detection option is disabled, the system cannot detect the presence of people who are immobile and not breathing or objects within the dangerous area.
- The system does not offer protection from pieces ejected from the machinery, from radiation, and objects falling from above.
- The machinery command must be electronically controlled.

### 1.2.1.12 DISPOSAL

In safety-related applications, comply with the mission time reported in "General specifications" on page 103. For decommissioning follow the instructions reported in "Disposal" on page 180.

## 1.2.2 Conformity

### 1.2.2.1 STANDARDS AND DIRECTIVES

<b>Directives</b>	2006/42/EC (MD - Machinery) 2014/53/EU (RED - Radio equipment)
<b>Harmonized standards for the Machinery Directive</b>	EN ISO 13849-1: 2023 PL d EN ISO 13849-2: 2012 EN IEC 62061: 2021
<b>Harmonized standards for the RED Directive</b>	EN IEC 61000-6-2:2019 EN IEC 61326-3-1:2017 ETSI EN 301 489-1 v2.2.3: 2019 ETSI EN 301 489-3 v2.1.1: 2019 (emission only) ETSI EN 301 489-3 v2.3.2:2023 ETSI EN 305550-1 V1.2.1: 2014 ETSI EN 305550-2 V1.2.1: 2014 IEC/EN 61010-1: 2010 + A1:2019
<b>Non-harmonized standards for Machinery Directive</b>	EN IEC 61496-1: 2020 IEC TS 61496-5:2023 IEC TS 62998-1:2019 IEC/EN 61508: 2010 Part 1-7 SIL 2 EN IEC 61000-6-2:2019 (immunity) EN IEC 61326-3-1:2017 (immunity) UL 61010-1:2023 CAN/CSA 61010-1:2023 UL 61496-1:2021 EN IEC 61784-3-3:2021 for the PROFIsafe Fieldbus IEC/EN 61784-3-12:2010, A1:2019 for FSoE Fieldbus IEC/EN 61784-3-2:2021 for CIP Safety™ Fieldbus

**Note:** no type of failure has been excluded during the system analysis and design phase.

All updated certifications can be downloaded from <https://www.inxpect.com/en/downloads>.

### 1.2.2.2 CE

The manufacturer, Inxpect SpA, states that Inxpect SRE 200 Series (Safety Radar Equipment) complies with the 2014/53/EU and 2006/42/EC directives. The full EU Declaration of Conformity text is available on the company's website: <https://www.inxpect.com/en/downloads>.

### 1.2.2.3 UKCA

The manufacturer, Inxpect SpA, states that Inxpect SRE 200 Series (Safety Radar Equipment) complies with Radio Equipment Regulations 2017 and Supply of Machinery (Safety) Regulations 2008. The full UKCA Declaration of Conformity text is available on the company's website: <https://www.inxpect.com/en/downloads>.

### 1.2.2.4 OTHER CONFORMITIES AND NATIONAL CONFIGURATIONS

For a complete, up-to-date list of product conformities and any national configurations, please refer to the National configuration addendum document. The PDF can be downloaded from the site <https://tools.inxpect.com>.

## 2. Get to know Inxpect SRE 200 Series

### 2.1 System components

#### Contents

This section includes the following topics:

<b>2.1.1 Inxpect SRE 200 Series</b>	15
<b>2.1.2 Control units</b>	17
<b>2.1.3 Sensors</b>	19
<b>2.1.4 Configuration tools</b>	21

#### Product label description

The following table describes the information contained in the product label:

Part	Description
<b>SID</b>	Sensor ID
<b>DC</b>	"yy/ww" : year and week of the product manufacture
<b>SRE</b>	Safety Radar Equipment
<b>Model</b>	Product model (e.g., S201A, C201A)
<b>Type</b>	Product variant indicating support for specific functionalities or information for commercial purposes
<b>S/N</b>	Serial number

#### 2.1.1 Inxpect SRE 200 Series

##### 2.1.1.1 Definition

Inxpect SRE 200 Series is an active protection radar system that monitors the dangerous areas of machinery.


##### 2.1.1.2 Special features

Some of the special features of this protection system are the following:

- indication of current distance and angle of the targets detected by each sensor
- customization of the detection field with advanced shapes (if available)
- up to four safe detection fields to define different behaviors of the machinery
- programmable coverage angle for each detection field
- rotation around three axes during installation to allow better coverage of detection areas
- safety Fieldbus to safely communicate with the PLC of the machinery (if available)
- possibility to switch dynamically between different preset configurations (max. 32 through Fieldbus, if available, and max. 8 with digital inputs)
- muting on the entire system or on each sensor individually
- immunity to dust and smoke
- reduction of undesired alarms caused by the presence of water or processing waste
- communication and data exchange through MODBUS (if available)

### 2.1.1.3 Main components

Inxpect SRE 200 Series is composed of a control unit and up to six sensors. The system application allows system operation configuration and checks.



**NOTICE\*:** if at least one sensor is an S202A, the maximum number of sensors is 5.


### 2.1.1.4 System status

The system can be in one of the following states:

State		Description	Status communication
Safe	Motion detected/Alarm	At least one detection field of one sensor has detected a motion	<ul style="list-style-type: none"> <li>OFF-state of the related OSSDs, if configured as <b>Detection signal "N"</b>, <b>Detection warning "N"</b> or <b>Detection signal group "N"</b></li> <li>Safety stop signal message via Fieldbus protocol, if available</li> <li>Sensor LED, see "Sensor status LEDs" on page 84</li> <li>Control unit LED, see "Control unit status LEDs" on page 80</li> </ul>
Safe	Stop signal	The system has received a stop signal	<ul style="list-style-type: none"> <li>OFF-state of all the OSSDs, if configured as <b>Detection signal "N"</b>, <b>Detection warning "N"</b> or <b>Detection signal group "N"</b></li> <li>Safety stop signal message via Fieldbus protocol, if available</li> <li>Sensor LED, see "Sensor status LEDs" on page 84</li> <li>Control unit LED, see "Control unit status LEDs" on page 80</li> </ul>
Safe	Fault	System failure	<ul style="list-style-type: none"> <li>Safety stop signal message via Fieldbus protocol, if available</li> <li>Sensor LED, see "Sensor status LEDs" on page 84</li> <li>Control unit LED, see "Control unit status LEDs" on page 80</li> </ul>
Safe	Configuration in progress	A change in system configuration is in progress	<ul style="list-style-type: none"> <li>Safety stop signal message via Fieldbus protocol, if available</li> <li>Sensor LED, see "Sensor status LEDs" on page 84</li> <li>Control unit LED, see "Control unit status LEDs" on page 80</li> </ul>
Normal		Not in any safe state	<ul style="list-style-type: none"> <li>OSSDs according to the status of the relative function.</li> <li>Sensor LED, see "Sensor status LEDs" on page 84</li> <li>Control unit LED, see "Control unit status LEDs" on page 80</li> </ul>

### 2.1.1.5 Control unit and sensor compatibility

The models and types of control unit and sensors are shown below, with their compatibility.



**NOTICE:** do not connect the control unit with other types of sensors (e.g., 9 meters range sensors).

The control unit can be simultaneously connected to sensors of different lines. For more details about the available features, see "Sensors" on page 19.

### 2.1.1.6 Control unit - sensor communication

The sensors communicate with the control unit via CAN bus using diagnostic mechanisms in compliance with standard EN 50325-5 to guarantee SIL 2 and PL d.

For correct functioning, each sensor must be properly identified with different Node IDs. By default, the sensor does not have a pre-assigned Node ID.

### 2.1.1.7 Control unit - machinery communication

The control unit communicates with the machinery via I/O (see "Digital inputs" on page 45 and "Digital outputs" on page 46).

Moreover, according to the model-type, the control unit is provided with:

- a safe communication on a Fieldbus interface. The Fieldbus interface allows the control unit to communicate in real-time with the PLC of the machinery to send information about the system to the PLC (e.g., the position of the detected target) or to receive information from the PLC (e.g., to change the configuration dynamically). For details, see "Fieldbus communication (PROFIsafe)" on page 49, "Fieldbus communication (CIP Safety™ on EtherNet/IP™)" on page 53 or see "Fieldbus communication (Safety over EtherCAT® - FSofE)" on page 52.
- an Ethernet port that allows unsafe communication on a MODBUS interface (see "MODBUS communication" on page 55).

### 2.1.1.8 Applications

Inxpect SRE 200 Series integrates with the machinery control system: when Inxpect SRE 200 Series is in safe state, the control system can put the area into a safe condition and/or prevent restarting of the machinery.

In the absence of other control systems, Inxpect SRE 200 Series can be connected to the devices that control the power supply or machinery start-up.

Inxpect SRE 200 Series does not perform normal machinery control functions.

For connection examples, see "Electrical connections" on page 129.

## 2.1.2 Control units

### 2.1.2.1 Control unit production lines

The Inxpect SRE 200 Series supports different control units:

Production line	Control unit model types	Firmware version
Core Line	<b>Type A:</b> C201A-PNS, C201A-F, C202A, C203A <b>Type B:</b> C201B-P, C201B-F, C202B, C203B	2.0.1
eXtended Line	<b>Type A:</b> C201A-PX1, C201A-FX1, C202A-X1, C203A-X1 <b>Type B:</b> C201B-PX1, C201B-FX1, C201B-C, C202B-X1, C203B-X1	2.1.1

The main additional features of the eXtended Line control units are described below:

- compatibility with Inxpect Safety Studio application
- compatibility with S202A sensors
- detection warning signal: to use single-channel OSSD
- stop signal debounce filter


### 2.1.2.2 Interfaces

The following table lists connection ports, communication interfaces and available microSD ports, for each control unit model-type:

	<b>Model</b>	<b>Type</b>	<b>micro-USB port</b>	<b>Ethernet port</b>	<b>Fieldbus port</b>	<b>microSD slot</b>
Type A	C201A	-PNS -PX1	x	x	x (PROFIsafe)	-
	C201A	-F -FX1	x	x	x (FSoE)	-
	C202A	- -X1	x	x	-	-
	C203A	- -X1	x	-	-	-
Type B	C201B	-P -PX1	x	x	x (PROFIsafe)	x
	C201B	-F -FX1	x	x	x (FSoE)	x
	C201B	-C	x	x	x (CIP Safety™)	x
	C202B	- -X1	x	x	-	x
	C203B	- -X1	x	-	-	x

### 2.1.2.3 Communication architecture

According to the model-type, this is the communication architecture between the control unit, PLC, and PC.



### 2.1.2.4 Functions

The control unit performs the following functions:

- Collects information from all the sensors via CAN bus.
- Compares the position of detected motion with the set values.
- Deactivates the selected safety output when at least one sensor detects motion in the detection field.
- Deactivates all the safety outputs if a failure is detected in one of the sensors or the control unit.
- Manages the inputs and outputs.
- Communicates with the system application for all configuration and diagnostic functions.
- Allows dynamically switching between different configurations.
- Communicates with a safety PLC through the safe Fieldbus connection (if available).
- Communicates and exchanges data through MODBUS protocol (if available).
- Performs a backup and a restore system configuration and password to/from microSD card (if available).

### 2.1.2.5 Control unit components

To know the components of each control unit model-type, see "Control units layout" on page 118.

For more information about the control unit LEDs:

- for status LED, see "Control unit status LEDs" on page 80.
- for Fieldbus LED: see "Control unit Fieldbus LEDs" on page 81.

## 2.1.3 Sensors

### 2.1.3.1 Sensor production lines

These are the sensors of each production line:

Production line	Sensor model-types	Main characteristics
Core line	S201A	4 detection fields Programmable horizontal angular coverage and detection distance Stationary, vehicle and mobile application
Pro line	S201A-W	4 detection fields Programmable horizontal angular coverage and detection distance Classic and corridor shapes Stationary, vehicle and mobile application
	S203A-W	
Omni line	S202A-MC1	Detection fields depending on model-type Programmable horizontal angular coverage, vertical angular coverage and detection distance Classic, corridor and cuboid shapes Stationary, vehicle and mobile application Compatible only with eXtended Line control units
	S202A-MC2	
	S202A-MC4	
	S202A-MS	One detection field Preset configuration Stationary application Compatible only with eXtended Line control units
	S202A-MV	

**NOTICE:** do not connect 9 meters range sensors to the control unit.


For detailed information about the sensor production lines, see "Appendix A: sensor lines" on page 137.

### 2.1.3.2 Functions

The sensors perform the following functions:


- Detect motion in their field of view.
- Send the motion detection signal to the control unit through CAN bus.
- Signal to the control unit through CAN bus the failures or faults detected on the sensor during diagnostics.

### 2.1.3.3 2-axis bracket



Part	Description
A	Sensor
B	Status LED
C	Tamper-proof screws to position the sensor at a specific angle around y-axis (tilt 10° steps)
D	Mounting bracket
E	Screw to position the sensor at a specific angle around z-axis (pan 10° steps)
F	Connectors for connecting the sensors in a chain and to the control unit

### 2.1.3.4 3-axis bracket



Part	Description
A	Sensor
B	Status LED, see "Sensor status LEDs" on page 84
C	Tamper-proof screws to position the sensor at a specific angle around y-axis (tilt 10° steps)
D	Mounting bracket
E	Tamper-proof screw to position the sensor at a specific angle around z-axis (pan 10° steps)
F	Connectors for connecting the sensors in a chain and to the control unit
G	Tamper-proof screw to position the sensor at a specific angle around x-axis (roll 10° steps)

## 2.1.4 Configuration tools

### 2.1.4.1 Introduction

To configure the system, two system applications are available:

- Inxpect Safety
- Inxpect Safety Studio

To know which configuration tool is available for each sensor, see "Appendix A: sensor lines" on page 137.

A system that includes at least one S202A sensor must be configured with Inxpect Safety Studio application.

If you configure a control unit with Inxpect Safety application you can then continue the configuration with Inxpect Safety Studio application. Conversely, if you use Inxpect Safety Studio application you cannot continue with Inxpect Safety application.

### 2.1.4.2 Functions

The application permits the following main functions to be performed:

- Configure the system.
- Create the configuration report.
- Check and validate system functioning.
- Download system log.

### 2.1.4.3 Control unit compatibility

#### With Inxpect Safety

Control unit firmware version	Inxpect Safety version				
	2.5.x	2.6.x	2.7.x	2.8.x	2.9.x
1.5.0	OK	OK	NO	NO	NO
1.6.0	NO	OK	OK	OK	NO
2.0.0	NO	NO	OK	OK	OK
2.0.1	NO	NO	NO	NO	OK
2.1.0	NO	NO	NO	OK*	OK*
2.1.1	NO	NO	NO	NO	OK*

**Note\*:** if there is at least one S202A sensor in the system, please use Inxpect Safety Studio application.

#### With Inxpect Safety Studio

Control unit firmware version	Inxpect Safety Studio version	
	1.x.y	
2.1.0	OK	
2.1.1	OK	

### 2.1.4.4 Authentication

The application can be downloaded free of charge at <https://tools.inxpect.com>.

Different user levels are available. The Admin user is in charge of user management. All the passwords can be set through the application and then saved on the control unit.

### 2.1.4.5 User levels

These are the functions available for each user level:

	Observer	Expert	Engineer	Admin	Service*
Read system configuration	x	x	x	x	x
Validation	-	x	x	x	x
Download log files	-	x	x	x	x
Sensor setup (e.g., Node ID) and configuration	-	-	x	x	-
Apply changes	-	-	x	x	-

	Observer	Expert	Engineer	Admin	Service*
Digital I/O configuration	-	-	X	X	-
Backup configuration	-	X	X	X	-
Restore configuration	-	-	X	X	-
Network and Fieldbus settings and System labels	-	-	-	X	-
Control unit firmware upgrade	-	-	-	X	-
User management	-	-	-	X	-
SD Backup and SD Restore (if available)	-	-	-	X	-
Technical support and maintenance	-	-	-	-	X
Debug and statistical information	-	-	-	-	X

**Note\*:** Service user can be enabled/disabled by the administrator. Since only Inxpect technicians are allowed to access as Service, the Service user is protected by an activation code.

### 2.1.4.6 System configuration

The control unit parameters have their own default values that can be modified via the system application. For more information about the programmable parameters, see "Appendix A: sensor lines" on page 137.

When a new configuration is saved, the system generates the configuration report.

**Note:** after a physical change of the system (e.g., new sensor installed), the system configuration must be updated and a new configuration report must be generated, too.

## 2.2 Functioning principles

### Contents

This section includes the following topics:

2.2.1 Sensor functioning principles .....	22
2.2.2 Field of view .....	23
2.2.3 Detection fields .....	23

### 2.2.1 Sensor functioning principles

#### 2.2.1.1 Introduction

The sensor is an FMCW (Frequency Modulated Continuous Wave) radar device based on a proprietary detection algorithm. It is also a multi-target sensor that sends pulses and receives information, analyzing the reflection of the nearest moving target that it encounters within each detection field.

The sensor can detect the current distance and the angle of each target.

Each sensor has its own fieldset. The fieldset corresponds to the structure of the field of view, which is composed of detection fields (see "Detection fields" on the next page).

#### 2.2.1.2 Factors that influence the sensor field of view and object detection

 **WARNING!** The presence of conductive material on the sensor could affect its field of view and, thus, object detection. For proper and safe system operation, validate the system under this condition.

### 2.2.1.3 Factors that influence the reflected signal

The signal reflected by the object depends on several characteristics of the same object:

- Metallic objects have a very high reflection coefficient, while paper and plastic reflect only a small portion of the signal
- The greater the surface exposed to the radar, the greater the reflected signal
- All other factors being equal, objects positioned directly in front of the radar generate a more significant signal than objects to the side
- Motion speed
- Inclination

All these factors have been analyzed for a human body during the safety validation of Inxpect SRE 200 Series and cannot lead to a dangerous situation. These factors may occasionally influence the behavior of the system causing spurious activation of the safety function.

### 2.2.1.4 Detected and ignored objects

The signal analysis algorithm considers only those objects that move within the field of view, ignoring completely static objects (if the static object detection option is disabled).

Furthermore, the system is able to ignore small work waste products that fall in the first part of the sensor's field of view.

### 2.2.1.5 Interference with pacemakers or other medical devices

Radiation from Inxpect SRE 200 Series does not interfere with pacemakers or other medical devices.

## 2.2.2 Field of view

### 2.2.2.1 Types of field of view

The actual detection field of the sensor depends on the parameters set during the configuration phase but also on the sensor installation height and inclination.

### 2.2.2.2 Areas of the field of view

The sensor field of view is composed of two areas:

- detection field: where the detection of objects similar to humans in any position is guaranteed
- gray area: where the actual detection of a moving object/person depends on the characteristics of the object itself (see "Factors that influence the reflected signal" above).

### 2.2.2.3 Dimensions and position

To know the dimensions and position of the field of view for each sensor, see "Appendix A: sensor lines" on page 137.

## 2.2.3 Detection fields

### 2.2.3.1 Introduction

The field of view of each sensor can be composed of detection fields. Each detection field can have a dedicated detection signal.

 **WARNING! Configure the detection fields and associate them with the dual channel safety outputs according to the risk assessment requirements.**

### 2.2.3.2 Detection fields dependency and detection signal generation


**Note:** the cuboid detection fields are independent and the dependency mode can not be set.

If a sensor detects motion within a detection field, its detection signal changes status and, when configured, the related safety output is deactivated. The behavior of the outputs related to the following detection fields depends on the detection field dependency set:


If...	Then...
the detection field dependency is enabled and thus detection fields are dependent on each other	<p>if a sensor detects motion within a detection field, all the outputs related to its following detection fields are deactivated too.</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <b>Example</b>            Detection field configured: 1, 2, 3            Detection field with target detected: 2            Detection field in alarm status: 2, 3         </div>
the detection field dependency is disabled and thus detection fields are independent from each other	<p>if a sensor detects motion within a detection field, only the output related to that detection field is deactivated.</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <b>Example</b>            Detection field configured: 1, 2, 3            Detection field with target detected: 2            Detection field in alarm status: 2         </div>

**⚠ WARNING! If detection fields are independent, an evaluation of the safety of the monitored area must be performed during the risk assessment. The blind area generated by a target can prevent the sensor from detecting targets in the following detection fields.**

In this example, both detection field 1 and 2 generate a detection signal, for target **[A]** and **[B]** respectively.




In this example, detection field 1 generates a detection signal for target **[A]** but target **[B]** could not be detected.



The detection field dependency can be set in the system application.

### 2.2.3.3 Independent detection fields: a use case

It can be useful to set the detection fields as independent, for example, if there is a scheduled temporary motion of an object in a detection field. An example can be a robotic arm moving from right to left within the detection field 1 only during a specific phase of the operative cycle.



In this case, it is possible to ignore the detection signal in the detection field 1, thus avoiding unnecessary downtime.

**⚠ WARNING! Evaluate the safety of the monitored area during risk assessment before deciding to ignore the detection signal of the detection field 1.**

**⚠ WARNING! The blind area generated by the moving robotic arm can prevent the sensor from detecting targets in the following other detection fields for a time interval. This time must be considered when defining the detection distance for detection field 2.**

### 2.2.3.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Detection field dependency	Settings > Advanced	DESIGN > sensor card > OPTIONS

## 2.3 Sensing safety functions

### Contents

This section includes the following topics:

<b>2.3.1 Safety working modes and safety functions</b>	26
<b>2.3.2 Safety working mode: Access detection and restart prevention (default)</b>	26
<b>2.3.3 Safety working mode: Always-on access detection</b>	27
<b>2.3.4 Safety working mode: Always-on restart prevention</b>	28

### 2.3.1 Safety working modes and safety functions

#### 2.3.1.1 Introduction

Each detection field of each sensor can perform the following safety working modes:

- **Access detection and restart prevention**
- **Always-on access detection**
- **Always-on restart prevention**

Each safety working mode is composed of one or both of the following safety functions:

Function	Description
Access detection	The machinery is reverted into a safe status when one or more persons enter the dangerous area.
Restart prevention	The machinery is prevented from restarting if people are in the dangerous area.

#### 2.3.1.2 Safety working modes

Via the system application, you can select which safety working mode each sensor will employ for each of its detection fields:

- **Access detection and restart prevention** (default):
  - The sensor performs the access detection function when it is in normal state (**No alarm** status).
  - The sensor performs the restart prevention function when it is in alarm state (**Alarm** status).
- **Always-on access detection**:
  - The sensor always performs the access detection function (**No alarm** status + **Alarm** status).
- **Always-on restart prevention**:
  - The sensor always performs the restart function (**No alarm** status + **Alarm** status)

#### 2.3.1.3 Access detection speed limits

The speed limits of the movements detected by the access detection function, depend on the sensor model-type. To know the range of speed of each sensor, see "Appendix A: sensor lines" on page 137.

### 2.3.2 Safety working mode: Access detection and restart prevention (default)

#### 2.3.2.1 Introduction

This safety working mode is composed of the following safety functions:

- access detection
- restart prevention

### 2.3.2.2 Safety function: access detection

Access detection allows what follows:

When...	Then...
no motion is detected in the detection field	the system is normal state
motion is detected in the detection field (see "Access detection speed limits" on the previous page)	<ul style="list-style-type: none"> <li>the system is in safe state</li> <li>the restart prevention function is activated</li> </ul>

### 2.3.2.3 Safety function: restart prevention

The restart prevention function remains active and the system in safe state as long as motion is detected in the detection field, or, with the static object detection option enabled (see "Restart prevention function: static object detection option" on page 37), as long as a static object is detected in the detection field.

The sensor can detect micro-movements of just a few millimeters, such as breathing movements (with normal breathing or a short apnea) or the movements necessary for a person to remain in balance in an upright or squatting position.

The system sensitivity is higher than the sensitivity that characterizes the access detection function. For this reason, the system reaction to vibrating and moving parts is different.

The sensor guarantees the detection of people moving at any speed from 0 up to 1.6 m/s (5.25 ft/s)\*, provided that the installation recommendations described in "Appendix A: sensor lines" on page 137 are fulfilled.

**Note\*:** a stationary person still has static residual movements that the radar can detect.

 **WARNING!** When the restart prevention function is active the monitored area may be affected by the position and inclination of the sensors, as well as by their installation height and angular coverage (see "Applications" on page 43).

### 2.3.2.4 Restart timeout parameter

When the system does not detect motion anymore or, with static object detection option enabled, no static object is detected, the system remains in safe state for the time set in the **Restart timeout** parameter. The **Restart timeout** parameter's minimum value is 0.1 s. To manage different type of restart with the additional safety function Restart signal, see "Restart signal" on page 29.

 **WARNING!** If the Restart timeout is set to a value less than 4 s, the sensor is no longer able to detect breathing movement or the movements necessary for a person to remain in balance in an upright or a squatting position. Set a value less than 4 s only for areas where people have no access.

### 2.3.2.5 How to configure it in the system application

Parameter	Inspect Safety	Inspect Safety Studio
Safety working mode	Configuration	<b>DESIGN</b> > sensor card > <b>DETECTION FIELDS</b>
Restart timeout	Configuration	<b>DESIGN</b> > sensor card > <b>DETECTION FIELDS</b> (with <b>Safety working mode</b> set as <b>Access detection and restart prevention</b> )

## 2.3.3 Safety working mode: Always-on access detection

### 2.3.3.1 Safety function: access detection

This is the only safety function available for the **Always-on access detection**.

Access detection allows what follows:

When...	Then...
no motion is detected in the detection field	the system is in normal state
motion is detected in the detection field	<ul style="list-style-type: none"> <li>the access detection function remains active</li> <li>the system is in safe state</li> <li>the sensitivity remains as it was before the motion detection</li> </ul>

 **WARNING!** If the Always-on access detection is selected, additional safety measures must be introduced to ensure the restart prevention function.

### 2.3.3.2 $T_{OFF}$ parameter

When the system does not detect motion anymore, the system remains in safe state for the time set in the  $T_{OFF}$  parameter.

The  $T_{OFF}$  value can be set from 0.1 s to 60 s.

### 2.3.3.3 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Safety working mode	Configuration	<b>DESIGN</b> > sensor card > <b>DETECTION FIELDS</b>
$T_{OFF}$	Configuration	<b>DESIGN</b> > sensor card > <b>DETECTION FIELDS</b> (with <b>Safety working mode</b> set as Always-on access detection)

## 2.3.4 Safety working mode: Always-on restart prevention

### 2.3.4.1 Safety function: restart prevention

This is the only safety function available for the **Always-on restart prevention**.

The restart prevention allows what follows:

When...	Then...
no motion is detected in the detection field	the system is in normal state
motion is detected in the detection field	<ul style="list-style-type: none"> <li>the system is in safe state</li> <li>the restart prevention function remains active</li> <li>the angular coverage and sensitivity remain as they were before motion detection</li> </ul>

The sensor can detect micro-movements of just a few millimeters, such as breathing movements (with normal breathing or a short apnea) or the movements necessary for a person to remain in balance in an upright or squatting position.

The system sensitivity is higher than the sensitivity that characterizes the access detection function. For this reason, the system reaction to vibrating and moving parts is different.

The sensor guarantees the detection of people moving at any speed from 0 up to 1.6 m/s (5.25 ft/s)\*, provided that the installation recommendations described in "Appendix A: sensor lines" on page 137 are fulfilled.

**Note\***: a stationary person still has static residual movements that the radar can detect.

 **WARNING!** When the restart prevention function is active the monitored area may be affected by the position and inclination of the sensors, as well as by their installation height and angular coverage (see "Applications" on page 43).

### 2.3.4.2 Restart timeout parameter

When the system does not detect motion anymore or, with static object detection option enabled, no static object is detected, the system remains in safe state for the time set in the **Restart timeout** parameter. The **Restart timeout** parameter's minimum value is 0.1 s. To manage different type of restart with the additional safety function Restart signal, see "Restart signal" on the next page.

 **WARNING!** If the Restart timeout is set to a value less than 4 s, the sensor is no longer able to detect breathing movement or the movements necessary for a person to remain in balance in an upright or a squatting position. Set a value less than 4 s only for areas where people have no access.

### 2.3.4.3 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Safety working mode	Configuration	<b>DESIGN</b> > sensor card > <b>DETECTION FIELDS</b>
Restart timeout	Configuration	<b>DESIGN</b> > sensor card > <b>DETECTION FIELDS</b> (with <b>Safety working mode</b> set as <b>Always-on restart prevention</b> )

## 2.4 Additional safety functions

### Contents

This section includes the following topics:

2.4.1 Stop signal .....	29
2.4.2 Restart signal .....	29
2.4.3 Muting .....	32
2.4.4 Dynamic system configuration .....	34
2.4.5 Fieldbus controlled .....	36

### 2.4.1 Stop signal

#### 2.4.1.1 Function description

The stop signal is an additional safety function that immediately halts the operation of the system. It is activated by the operator through a physical push button or another safety mechanism connected to a safety input on the control unit. Upon activation, the system transitions to safe state, regardless of the detection status of the sensors.

The function can be activated through a digital input or safety Fieldbus.

 **WARNING!** Any fault on the sensors or the control unit brings the system to the safe state and makes the function unavailable.

#### 2.4.1.2 Activation

##### Digital input

The digital input must be set as **Stop signal**.

The function can be performed only as dual channel inputs (Category 3, according to EN ISO 13849-1).

For details about the digital input signal, see "Digital input signals" on page 108.

##### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

#### 2.4.1.3 Debounce filter (only eXtended Line)

The debounce filter allows to filter test pulses in a digital input configured as **Stop signal**. Its enabling is recommended when an ESPE device equipped with OSSD is connected to the digital input.

**NOTICE:** debounce filter shall only be enabled with ESPE devices that initiate and internally monitor the OSSD test.

Per default, the filter is disabled. It can be enabled through the system application.

#### 2.4.1.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Digital input function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL INPUTS</b>
Debounce filter enabling/disabling	<b>Settings &gt; Advanced &gt; Stop signal debounce filter</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL INPUTS</b>

### 2.4.2 Restart signal

#### 2.4.2.1 Function description

The restart signal function is an additional safety function that enables the transition from safe to normal state and to switch to ON-state the safety outputs related to all the detection fields with no motion detected.

The function can be activated through a digital input or safety Fieldbus.

The restart signal feedback is activated when it is possible to manually restart at least one detection field.

The signal feedback can be communicated through a digital output or safety Fieldbus.

 **WARNING!** Any fault on the sensors or the control unit brings the system to the safe state and makes the function unavailable.

### 2.4.2.2 Activation

#### Digital input

The digital input must be set as **Restart signal**.

The function can be performed as:

- Single channel inputs/OSSDs (Category 2, according to EN ISO 13849-1)
- Dual channel inputs/OSSDs (Category 3, according to EN ISO 13849-1)

For details about the digital input signal, see "Digital input signals" on page 108.

#### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.4.2.3 Types of managed restart

**NOTICE:** it is the responsibility of the machinery manufacturer to assess if an automatic restart can guarantee the same level of safety as a manual restart (as defined in standard EN ISO 13849-1, section 5.2.2).

For each detection field independently, the system manages the following types of restart:

Type	Conditions for enabling machinery restart	Safety working mode allowed
<b>Automatic</b> (default)	The time interval set through the system application ( <b>Restart timeout</b> ) has passed since the last motion detection*.	All
<b>Manual</b>	The <b>Restart signal</b> was received correctly** (see "Restart signal (dual channel, redundancy mode coherent)" on page 112).	<b>Always-on access detection</b>
<b>Safe manual</b>	<ul style="list-style-type: none"> <li>• The time interval set through the system application (<b>Restart timeout</b>) has passed since the last motion detection* and</li> <li>• The <b>Restart signal</b> was received correctly** (see "Restart signal + System recondition (dual channel, redundancy mode coherent)" on page 115).</li> </ul>	<b>Access detection and restart prevention, Always-on restart prevention</b>

 **WARNING!** If the Automatic restart is set with the Safety working mode Always-on access detection, the restart prevention safety function is not performed, and consequently, the system does not guarantee the detection of a person within the monitored area.

**Note\*:** machinery restart is enabled if no motion is detected up to 35 cm (13.8 in) beyond the detection field.

**Note\*\*:** (for all types of restart) other dangerous system statuses may prevent the restart of the machinery (e.g., diagnostic fault, sensor masking, etc.)

### 2.4.2.4 Configure the restart signal function

 **WARNING!** If the Restart signal function has been enabled both through the safety Fieldbus and the digital inputs, the functionality can be activated from both of them.

Type	Procedure
Automatic	<ol style="list-style-type: none"> <li>1. For the involved detection fields, set the <b>Restart function</b> as <b>Automatic</b>.</li> <li>2. For each detection field in use with automatic restart, select the desired <b>Safety working mode</b> and set the <b>Restart timeout</b> parameter (or the <b>T<sub>OFF</sub></b> parameter, if present).</li> </ol>
Manual	<ol style="list-style-type: none"> <li>1. Connect the machinery button for the restart signal as convenient (see "Electrical connections" on page 129).</li> <li>2. To activate the function through digital input, set a digital input as <b>Restart signal</b>.</li> <li>3. To activate the function through Fieldbus, make sure that no digital input is configured as <b>Restart signal</b>. For details about the communication protocol, see Fieldbus protocol reference guide.</li> <li>4. For the involved detection fields, set the <b>Restart function</b> as <b>Manual</b>.</li> <li>5. For each detection field in use with manual restart, set the <b>T<sub>OFF</sub></b> parameter value.</li> </ol> <p><b>Note:</b> the <b>Safety working mode</b> is automatically set to <b>Always-on access detection</b> for all the detection fields in use with manual restart.</p>
Safe manual	<ol style="list-style-type: none"> <li>1. Connect the machinery button for the restart signal as convenient (see "Electrical connections" on page 129).</li> <li>2. To activate the function through digital input, set a digital input as <b>Restart signal</b>.</li> <li>3. To activate the function through Fieldbus, make sure that no digital input is configured as <b>Restart signal</b>. For details about the communication protocol, see Fieldbus protocol reference guide.</li> <li>4. For the involved detection fields, set the <b>Restart function</b> as <b>Safe manual</b>.</li> <li>5. For each detection field in use with manual restart, select the <b>Safety working mode</b> among those allowed and set the <b>Restart timeout</b> parameter value.</li> </ol>

#### 2.4.2.5 Restart feedback signal option settings

If at least one detection field in use is configured as **Manual** or **Safe manual** restart, the behavior of the **Restart feedback signal** depends on the option selected:

Option	Restart feedback signal behavior
Standard	<ul style="list-style-type: none"> <li>• The selected output is activated (ON-state) if there is no more motion within at least one detection field configured as <b>Manual</b> or <b>Safe manual</b> restart. The ON-state lasts as long as there is an absence of motion within one or more detection fields (configured as <b>Manual</b> or <b>Safe manual</b> restart) and until the restart signal is activated on the selected input.</li> <li>• The selected output remains in OFF-state if: <ul style="list-style-type: none"> <li>◦ none of the detection fields (configured as <b>Manual</b> or <b>Safe manual</b> restart) are ready to be restarted, and as long as a motion (or a fault) is detected within at least one detection field (configured as <b>Manual</b> or <b>Safe manual</b> restart), or</li> <li>◦ as long as no motion is detected within any detection fields configured as <b>Manual</b> or <b>Safe manual</b> restart, but none can be restarted yet.</li> </ul> </li> </ul>
Pulsed	<ul style="list-style-type: none"> <li>• The selected output is activated (ON-state) if there is no more motion within at least one detection field configured as <b>Manual</b> or <b>Safe manual</b> restart. The ON-state lasts as long as there is an absence of motion within one or more detection fields (configured as <b>Manual</b> or <b>Safe manual</b> restart) and until the restart signal is activated on the selected input.</li> <li>• The selected output switches continuously between ON-state and OFF-state if none of the detection fields (configured as <b>Manual</b> or <b>Safe manual</b> restart) are ready to be restarted, and as long as a motion (or a fault) is detected within at least one detection field (configured as <b>Manual</b> or <b>Safe manual</b> restart)</li> <li>• The selected output remains in OFF-state as long as no motion is detected within any detection fields configured as <b>Manual</b> or <b>Safe manual</b> restart, but none can be restarted yet.</li> </ul>

#### 2.4.2.6 Feedback

##### Digital output

The digital output must be set as **Restart feedback signal**.

It can be set as **Standard** or **Pulsed**, see "Restart feedback signal option settings" above.

It switches the selected output to ON-state when it is possible to manually restart at least one detection field:

- If all the used detection fields are configured as **Automatic** restart, the selected output is always in OFF-state.

## 2.4 Additional safety functions

- If at least one detection field in use is configured as **Manual** or **Safe manual** restart, the behavior depends on the option selected (see "Restart feedback signal option settings" on the previous page).

### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

#### 2.4.2.7 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Restart type	<b>Settings &gt; Restart function</b>	<b>DESIGN &gt; control unit card &gt; RESTART FUNCTION</b>
Restart feedback signal options	<b>Settings &gt; Restart function</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL OUTPUTS</b> (with an output configured as <b>Restart feedback signal</b> )
Digital input function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL INPUTS</b>
Digital output function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL OUTPUTS</b>

## 2.4.3 Muting

### 2.4.3.1 Function description

The muting function is an additional safety function that inhibits the sensing capability of the sensor on which it is activated. It can be activated for a specific sensor or for a group of sensors. This results in keeping the system in normal state even when the muted sensors detect motion.

When the muting function is activated, it is effective on one or more sensors occurs only as soon as the conditions permit (see "Muting conditions" on the next page).

The muting function can be activated for all the sensors simultaneously or only for a group of sensors. Up to two groups can be configured.

The function can be activated through a digital input or safety Fieldbus.

 **WARNING!** Any fault on the sensors or the control unit brings the system to the safe state and makes the function unavailable.

 **WARNING!** When the sensor is in muting, no sensor error is available (see "ERROR events (sensor)" on page 96).

The muting enable feedback signal is activated if at least one of the groups of sensors is in muting.

The signal feedback can be communicated through a digital output or safety Fieldbus.

**NOTICE:** it is the responsibility of the machinery manufacturer to assess whether the indication of the muting status is necessary (as defined in section 5.2.5 of EN ISO 13849-1 standard).

### 2.4.3.2 Activation

#### Digital input

The digital input must be set as **Muting group 1** or **Muting group 2**, according to the muting groups configured.

The function can be performed as dual channel inputs (Category 3, according to EN ISO 13849-1).

For details about the digital input signal, see "Digital input signals" on page 108.

### Fieldbus

 **WARNING!** If the muting function has been enabled through the safety Fieldbus and the digital inputs, only the digital inputs enabling is considered for the function.

The muting function can be enabled for each sensor individually.

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.4.3.3 Function settings

Through the system application, the following must be defined:

- for each input, the group of managed sensors
- for each group, the sensors that belong to it
- for each sensor, whether it belongs to a group or not

**Note:** if the muting function is enabled for one sensor, it is enabled for all the detection fields of the sensor, regardless if the detection fields are dependent or independent and the anti-tampering functions are disabled for that sensor.

### 2.4.3.4 Muting conditions

The muting function is active on a specific sensor only in the following conditions:

- All the detection fields involved have no active detection signal, no active static object detection signal, and the restart timeout has expired for all of them.
- There is no tampering signal or fault signal for that sensor.


When the muting is activated for a group of sensors, the function is active as soon as there is no detection in the monitored area of all sensors.

**WARNING!** Activate the muting signal on sensors monitoring the same dangerous area once the whole area is safe and nobody can access it. If the muting is activated on single sensors through Fieldbus and sensors monitoring the same dangerous area are still detecting a movement, a person could move into a space monitored by a muted sensor, compromising the safety of the whole area.

### 2.4.3.5 Enable muting signal characteristics

The muting function is enabled only if both logic signals of the dedicated input meet certain characteristics.

Below is a graphic representation of the signal characteristics.



In the system application, it is necessary to set the parameters that define the signal characteristics.

**Note:** with pulse duration = 0, it is sufficient that the input signals are at high logic level (1) to enable muting.

### 2.4.3.6 Feedback

#### Digital output

The digital output must be set as **Muting enable feedback signal**.

#### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.4.3.7 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Muting signal pulse width, pulse period and phase shift	<b>Settings &gt; Muting</b>	<b>DESIGN &gt; control unit card &gt; MUTING OPTIONS &gt; MUTING PARAMETERS</b>
Muting groups	<b>Settings &gt; Muting</b>	<b>DESIGN &gt; control unit card &gt; MUTING OPTIONS &gt; MANAGE MUTING GROUPS</b>
Digital input function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL INPUTS</b>
Digital output function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL OUTPUTS</b>

## 2.4.4 Dynamic system configuration

### 2.4.4.1 Function description

Inxpect SRE 200 Series allows a real-time adjustment of the most important system parameters, providing the means to switch dynamically among different preset configurations. Via the system application, once the first system configuration (default configuration) has been set, it is possible to set alternative presets to allow a dynamic real-time reconfiguration of the monitored area.

The dynamic system configuration function is an additional safety function that allows the control unit to select a specific dynamic configuration.

The function can be activated through a digital input or safety Fieldbus.

 **WARNING!** Any fault on the sensors or the control unit brings the system to the safe state and makes the function unavailable.

**Note:** only for S202A sensors, if the application type is set as **Stationary** and the next configuration has at least one detection field with safety working mode set as **Access detection and restart prevention** or **Always-on restart prevention**, the configuration change leads to an alarm on that/those detection field/s for at least as long as the time set in the **Restart timeout** parameter.

### 2.4.4.2 Dynamic configuration presets

The number of presets available depends on the model-type of the sensor, see "Appendix A: sensor lines" on page 137.

In a mixed system with at least one S202A sensor, the maximum number of dynamic configurations is limited to 16. If the dynamic configurations are managed by digital input the maximum presets are limited to 8.

### 2.4.4.3 Activation

#### Digital input

The digital input must be set as **Dynamic configuration switch**.

The function can be performed as dual channel inputs/OSSDs (Category 3, according to EN ISO 13849-1).

To activate one of the preset configurations dynamically, one or both the digital inputs of the control unit can be used. The result is the following:

If...	Then it is possible to switch dynamically between...
only <b>one</b> digital input is configured as <b>Dynamic configuration switch</b>	<b>two</b> preset configurations (see "Case 1" on the next page and "Case 2" on the next page)
<b>both</b> digital inputs are configured as <b>Dynamic configuration switch</b> and the encoded channel option is disabled	<b>four</b> preset configurations (see "Case 3" on the next page)
<b>both</b> digital inputs are configured as <b>Dynamic configuration switch</b> and the encoded channel option is enabled	<b>eight</b> preset configurations (see "Case 4" on the next page)

**Note:** the configuration change is safe because two-channel inputs are used.

**Note:** if the encoded channel option is enabled, any invalid combination that lasts more than 33 ms results in a fault on the inputs that brings the system to a safe state.

## Case 1

The first digital input has been configured as **Dynamic configuration switch**.

Dynamic configuration number	Input 1 (CH1 and CH2)	Input 2
#1	0	-
#2	1	-

0 = signal deactivated; 1 = signal activated

## Case 2

The second digital input has been configured as **Dynamic configuration switch**.

Dynamic configuration number	Input 1	Input 2 (CH1 and CH2)
#1	-	0
#2	-	1

0 = signal deactivated; 1 = signal activated

## Case 3

Both digital inputs have been configured as **Dynamic configuration switch**, and the encoded channel option is disabled.

Dynamic configuration number	Input 1 (CH1 and CH2)	Input 2 (CH1 and CH2)
#1	0	0
#2	1	0
#3	0	1
#4	1	1

0 = signal deactivated; 1 = signal activated

## Case 4

Both digital inputs have been configured as **Dynamic configuration switch**, and the encoded channel option is enabled.

The valid combinations are only those that differ at least by two values, and they are listed below:

Dynamic configuration number	Input 1		Input 2	
	CH1	CH2	CH1	CH2
#1	1	0	0	0
#2	0	1	0	0
#3	0	0	1	0
#4	0	0	0	1
#5	1	1	1	0
#6	1	1	0	1
#7	1	0	1	1
#8	0	1	1	1

0 = signal deactivated; 1 = signal activated

For details about the digital input signal, see "Digital input signals" on page 108.

## Fieldbus

**⚠️ WARNING!** If one or more digital inputs are configured as "Dynamic configuration switch", a switch through the safety Fieldbus is not considered.

**⚠️ WARNING!** Before activating one of the preset configurations through the safety Fieldbus, ensure that none of the digital inputs is configured as Dynamic configuration switch; otherwise, the Inxpect SRE 200 Series ignores all the switches made through the safety Fieldbus.

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.4.4.4 Dynamic system configuration parameters

All the sensor's parameters related to the detection fields can be set in the dynamic configuration, see "Appendix A: sensor lines" on page 137.

All the remaining system parameters cannot be changed dynamically and are considered static.

### 2.4.4.5 Safe configuration change

The change of the configuration takes place safely both on stationary and moving machinery. The sensor always monitors the entire monitored area and when it receives a request to change to a configuration with a longer detection field, it immediately reverts to safe state if people are present in such a field.

### 2.4.4.6 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Sensor and detection field parameters	Configuration	DESIGN > sensor card > <b>DETECTION FIELDS</b>
Dynamic configuration management	Configuration	DESIGN > (in control unit card) 
Digital input function	Settings > <b>Digital Input-Output</b>	DESIGN > control unit card > <b>DIGITAL INPUTS</b>

## 2.4.5 Fieldbus controlled

### 2.4.5.1 Function description

The Fieldbus controlled is an additional safety function that can be performed both as input and output:

- input: it monitors the input status through Fieldbus communication.
- output: it allows the specific output to be set through the Fieldbus communication.

It is only available if the Fieldbus communication is available in the control unit and it can be activated only through a digital input/output.

**⚠️ WARNING!** the following faults makes the Fieldbus controlled additional safety function unavailable: **POWER ERROR, TEMPERATURE ERROR, FIELDBUS ERROR, PERIPHERAL ERROR, FEE ERROR and FLASH ERROR.**

### 2.4.5.2 Activation

#### Digital input

The digital input must be set as **Fieldbus controlled**.

The function can be performed as:

- Single channel inputs/OSSDs (Category 2, according to EN ISO 13849-1)
- Dual channel inputs/OSSDs (Category 3, according to EN ISO 13849-1)

#### Digital output

The digital output must be set as **Fieldbus controlled**.

### 2.4.5.3 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Digital input function	Settings > <b>Digital Input-Output</b>	DESIGN > control unit card > <b>DIGITAL INPUTS</b>
Digital output function	Settings > <b>Digital Input-Output</b>	DESIGN > control unit card > <b>DIGITAL OUTPUTS</b>

# 2.5 Other functions

## Contents

This section includes the following topics:

2.5.1 Restart prevention function: static object detection option .....	37
2.5.2 Anti-tampering functions: anti-rotation around axes .....	38
2.5.3 Anti-tampering functions: anti-masking .....	39
2.5.4 System recondition .....	41
2.5.5 Electromagnetic robustness .....	42
2.5.6 Surface moisture robustness .....	42

## 2.5.1 Restart prevention function: static object detection option

### 2.5.1.1 Introduction

The static object detection option allows the restart prevention function also to detect static objects in the dangerous area.

**NOTICE:** the ability to detect an object depends on the RCS of the object. The static object detection option does not guarantee 100% detection of static objects.

### 2.5.1.2 Availability

The static object detection option is available for:

- control unit firmware version 1.5.0 or later, and
- sensor firmware version 3.0 or later.

### 2.5.1.3 Possible applications

This option can be useful if the sensor is installed on moving elements (see "Mobile application" on page 44) or to prevent the restart of a robot that could bump into a static object in the area temporarily.

### 2.5.1.4 Operation

The option can be enabled for each detection field of each sensor with the safety working mode set to **Access detection and restart prevention**. Enable the option only if the detection field is free of static objects; otherwise, the system would never reactivate the detection signals after a motion is detected in the area.

### 2.5.1.5 Settings

Via the system application, it is possible to increase or decrease the sensitivity of the static object detection of the sensors.

### 2.5.1.6 Feedback

The static object detection feedback signal is activated when at least one sensor detects a static object in one of its detection fields. The feedback signal can be performed via digital output or Fieldbus (if available).

#### Digital output

The digital output must be set as **Static object detection feedback signal**.

It switches the selected output to ON-state when at least one sensor detects a static object in one of its detection fields. The selected output remains in ON-state for at least 100 ms. If, at the same time, a moving target is detected in the detection field, the **Static object detection feedback signal** will switch its selected output to OFF-state for the duration of the movement.

#### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.5.1.7 How to configure it in the system application


Parameter	Inxpect Safety	Inxpect Safety Studio
Static object detection option enabling	<b>Settings &gt; Advanced</b>	<b>DESIGN &gt; sensor card &gt; DETECTION FIELDS</b>
Static object detection option sensitivity	<b>Settings &gt; Advanced</b>	<b>DESIGN &gt; control unit card &gt; OTHER OPTIONS</b>

## 2.5.2 Anti-tampering functions: anti-rotation around axes

### 2.5.2.1 Anti-rotation around axes

The sensor detects rotation around its axes.

**Note:** the axes are those represented in the figure below, regardless of the installation position of the sensor.



When the system configuration is saved, the sensor also saves its position. Later, if the sensor detects changes in rotation around these axes, it sends a tamper alert to the control unit. Upon reception of a tampering signal, the control unit deactivates the safety outputs. The sensor position can be saved also by an anti-masking reference saving signal, see "Anti-rotation reference saving signal activation" on the next page.

**Note:** when the position is modified with respect to the saved references (i.e., when a sensor is rotated) and the anti-rotation around axes function is enabled, the Inxpect SRE 200 Series detects the tampering and sends the message within 5 s.


The sensor can detect changes in rotation around the y-axis and the x-axis even if it is switched off. The tamper alert is sent to the control unit at the following switch on.

### 2.5.2.2 Specificity of z-axis rotation

**WARNING!** The tamper alert due to a rotation around the z-axis is reset at the next switch on. For proper and safe operation of the system, validate the system again.

A change in rotation around the z-axis is detected if it is faster than 5° every 10 s and if the system is on.

If the sensor is tilted (y-axis) downwards in a range of [-85, -95]° or upwards in a range of [85, 95]°, the anti-rotation function is not guaranteed.



*Sensor tilted downwards.*

### 2.5.2.3 Anti-rotation reference saving signal activation

The anti-rotation reference saving signal can be activated through digital input or Fieldbus communication.

#### Digital input

The digital input must be set as **Anti-rotation reference saving**.

#### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.5.2.4 Enable the anti-rotation around axes function

The anti-rotation around axes function is disabled by default.

 **WARNING!** If the function is disabled, the system cannot signal a change in the rotation of the sensor around the axes and, therefore, any changes in the monitored area. See "Checks when the anti-rotation around axes function is disabled" below.

 **WARNING!** Take precautions to prevent tampering, if the function is disabled for at least one axis of one sensor and if the rotation around that axis is not protected with tamper-proof screws.

The function can be enabled and configured for each axis of each sensor individually via the system application.

### 2.5.2.5 When to enable

Enable the anti-rotation around axes function only if it is necessary to detect a change in the rotation of a sensor around a specific axis.

It is strongly suggested the function not be enabled if the sensor is installed on a moving element (e.g., carriage, vehicle) whose motion could change the sensor inclination (e.g., motion on a slope or in a curve).

### 2.5.2.6 Checks when the anti-rotation around axes function is disabled

When the anti-rotation around axes function is disabled, perform the following checks.

Safety function	Schedule	Action
Access detection function	Before each machinery restart	Check that the sensor is positioned as defined in the configuration.
Restart prevention function	Each time the safety outputs are deactivated	Check that the monitored area is the same as defined by the configuration. See "Validate the safety functions" on page 68.

### 2.5.2.7 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Function enabling/disabling for each axis	<b>Settings &gt; Anti-tampering</b>	<b>DESIGN &gt; sensor card &gt; ANTI-TAMPERING</b>
Digital input function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL INPUTS</b>

## 2.5.3 Anti-tampering functions: anti-masking

### 2.5.3.1 Masking signal

The sensor detects the presence of objects that could obstruct the field of view. When the system configuration is saved, the sensor memorizes the surrounding environment. If the sensor subsequently detects variations in the environment that could influence the field of view, it sends a masking signal to the control unit. The sensor monitors from  $-50^\circ$  to  $50^\circ$  on the horizontal plane regardless of the horizontal angular coverage set. Upon receiving a masking signal, the control unit deactivates the safety outputs.

**Note:** the masking signal is not guaranteed in the presence of objects which cause reflection effects that bring their RCS below the minimum detectable threshold.

**Note:** when the position is modified with respect to the saved references (i.e., when a sensor is masked) and the anti-rotation around axes function is enabled, the Inxpect SRE 200 Series detects the tampering and notifies it within 5 s.

### 2.5.3.2 Environment memorization process

The sensor starts the surrounding environment memorization process when the system application configuration is saved or when an anti-masking reference saving signal is received (see "Anti-masking reference saving signal activation" below). From that moment, it waits for the system to exit the alarm status and for the scene to be static up to 20 seconds, then scans and memorizes the environment.

**NOTICE:** if the scene is not static during the 20 seconds interval, the system remains in a fault status (SIGNAL ERROR) and the system configuration must be saved again.

 *It is recommended to start the memorization process after at least 3 minutes from turning on the system to guarantee that the sensor has reached the operating temperature.*

Only at the conclusion of the memorization process it is possible for the sensor to send masking signals.

### 2.5.3.3 Anti-masking reference saving signal activation

The anti-masking reference saving signal can be activated through digital input or Fieldbus communication.

#### Digital input

The digital input must be set as **Anti-masking reference saving**.

#### Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.5.3.4 Causes of masking

Possible causes of masking signals are the following:

- An object that obstructs the field of view of the sensor has been placed in the detection field.
- The environment in the detection field changes significantly, for example, if the sensor is installed on moving parts or if there are moving parts inside of the detection field.
- The configuration was saved with sensors installed in an environment that is different from the working environment.
- There were temperature fluctuations.

### 2.5.3.5 Masking signal when the system is turned on

If the system was off for several hours and there were temperature fluctuations, the sensor might send a false masking signal when it is turned on. The safety outputs activate automatically within 3 minutes when the sensor reaches its working temperature. This does not happen if this temperature is still very far from the reference temperature.

### 2.5.3.6 Settings

For each sensor, the anti-masking settings are the following:

Parameter	Min	Max	Notes
Maximum distance from the sensor in which the function is active	20 cm(7.87 in)	100 cm(3.28 ft)*	Adjustable in 10 cm (3.94 in) increments
Sensitivity	High, Medium, Low, Disabled		See "Sensitivity levels" below

**Note\*:** only for S202A sensors, the maximum detection distance value is 50 cm(1.64 ft).

Via the system application the function can be disabled and the sensitivity level and the distance can be set.

### 2.5.3.7 Sensitivity levels

These are the four levels of sensitivity:

**Note:** the function has a gray area where the actual detection of a masking object depends on the RCS of the object and on the sensitivity level set. The high sensitivity level has the largest area, about 10-20 cm (3.94-7.87 in).

Level	Description	Example application
High	The sensor has the highest sensitivity to changes in the environment. (Suggested level when the field of view is empty up to the set masking distance)	Installations with an empty environment and a height of less than one meter, where objects could occlude the sensor.
Medium	The sensor has low sensitivity to changes in the environment. Occlusion must be evident (deliberate tampering).	Installations with a height of more than one meter, where masking is likely to occur only if voluntary.
Low	The sensor detects masking only if the sensor occlusion is complete and the objects are highly reflective (e.g., metal, water) near the sensor.	Installations on moving parts, where the environment is changing continuously, but where static objects may be near the sensor (obstacles on the route).
Disabled	<p>The sensor does not detect changes in the environment.</p> <p> <b>WARNING! If the function is disabled the system cannot signal the presence of objects that might impede normal detection (see "Checks when the anti-masking function is disabled" below).</b></p>	See "When to disable" below.

### 2.5.3.8 Checks when the anti-masking function is disabled

When the anti-masking function is disabled, perform the following checks.

Safety function	Schedule	Action
Access detection function	Before each machinery restart	Remove any objects that obstruct the field of view of the sensor.
Restart prevention function	Each time the safety outputs are deactivated	Reposition the sensor according to the initial installation.

### 2.5.3.9 When to disable

The anti-masking function should be disabled under the following conditions:

- (With restart prevention function) The monitored area includes moving parts that stop in different and unpredictable positions.
- The monitored area includes moving parts that vary their position while the sensors are in muting.
- The sensor is positioned on a part that can be moved.
- The presence of static objects is tolerated in the monitored area (e.g., loading/unloading area).

### 2.5.3.10 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Function enabling/disabling	<b>Settings &gt; Anti-tampering</b>	<b>DESIGN &gt; sensor card &gt; ANTI-TAMPERING</b>
Maximum distance		
Sensitivity		
Digital input function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL INPUTS</b>

## 2.5.4 System recondition

### 2.5.4.1 Function description

The system recondition function is useful for replacing an existing sensor without changing current settings.

### 2.5.4.2 Activation

#### Digital input

 **WARNING! If the system recondition function has been configured through the safety Fieldbus and the digital inputs, the function can be used from both.**

The digital input must be set as **System recondition** or **Restart signal + System recondition**.

The function can be performed as:

- Single channel inputs/OSSDs (Category 2, according to EN ISO 13849-1)
- Dual channel inputs/OSSDs (Category 3, according to EN ISO 13849-1)

## Fieldbus

For details about the communication protocol, see Fieldbus protocol reference guide.

### 2.5.4.3 Replace a sensor with system recondition function

See "Replace a sensor: System recondition function" on page 99.

### 2.5.4.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Digital input function	Settings > Digital Input-Output	DESIGN > control unit card > <b>DIGITAL INPUTS</b>

## 2.5.5 Electromagnetic robustness

### 2.5.5.1 Electromagnetic robustness parameter

With the **Electromagnetic robustness** parameter, it is possible to increase the robustness of the system to electromagnetic interference (e.g., due to sensors of different systems installed too close to each other or problems on the CAN bus).

In the system application, the following levels of robustness can be set:

- **Standard** (default)
- **High**
- **Very High**

 **WARNING!** The parameter impacts the system response time for the access detection safety function. According to the chosen level, the maximum guaranteed response time is 100 ms (Standard), 150 ms (High), or 200 ms (Very High).

### 2.5.5.2 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Robustness level	Settings > Advanced	DESIGN > control unit card > <b>OTHER OPTIONS</b>

## 2.5.6 Surface moisture robustness

### 2.5.6.1 Availability

The surface moisture robustness is available only for S203A sensors with firmware version 5.1 or later.

### 2.5.6.2 Surface moisture robustness function

If there are water residues on the cover, the system may generate false alarms. With the Surface moisture robustness function, it is possible to increase the system's robustness to better filter out the water residues.

 **WARNING!** The maximum field of view programmable with the function enabled is reduced, see "Field of view limitations" below. Enable the function only if the limited field of view is enough for guarantee the safety of the dangerous area.

In the system application, the option can be enabled for each sensor individually, both in stationary and mobile applications.

### 2.5.6.3 Field of view limitations

Shape	Limitation
Classic	For detection distances up to 3 m: horizontal angular coverage (left/right): from 0 to 50°
	For detection distances from 3 to 5 m: horizontal angular coverage (left/right): from 0 to 30°
Corridor	Width: left side/right side: from 0 to 1.5 m

#### 2.5.6.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Function enabling/disabling	<b>Settings &gt; Advanced</b>	<b>DESIGN &gt; control unit card &gt; OTHER OPTIONS</b>

## 2.6 Applications

### Contents

This section includes the following topics:

<b>2.6.1 Basic concepts</b> .....	<b>43</b>
<b>2.6.2 Stationary application</b> .....	<b>44</b>
<b>2.6.3 Mobile application</b> .....	<b>44</b>


### 2.6.1 Basic concepts

#### 2.6.1.1 Determining factors

The sensor installation height and inclination should be decided together with the angular coverage and the detection distances in order to have optimal coverage of the dangerous area.

#### 2.6.1.2 Sensor installation height


The installation height (h) is the distance between the center of the sensor and the ground or reference plane of the sensor.



#### 2.6.1.3 Sensor inclination

Sensor inclination is the rotation of the sensor around its y-axis. Inclination is defined as the angle between a line perpendicular to the sensor and a line parallel to the ground. Three examples are presented as follows:

- sensor tilted upwards:  $\alpha$  positive
- straight sensor:  $\alpha = 0$
- sensor tilted downwards:  $\alpha$  negative



## 2.6.2 Stationary application

### 2.6.2.1 Suitable sensors

To determine which sensors are suitable for stationary applications, see "Appendix A: sensor lines" on page 137.

## 2.6.3 Mobile application

### 2.6.3.1 Suitable sensors

To determine which sensors are suitable for mobile applications, see "Appendix A: sensor lines" on page 137.

### 2.6.3.2 Speed limits

The speed of vehicle or part of the machinery at which the detection is guaranteed depends on the sensor model-type. To know the range of speed for each sensor, see "Appendix A: sensor lines" on page 137.

### 2.6.3.3 Detection signal generation conditions

When the sensor is mounted on moving parts, it will detect static objects as moving objects.

The sensor will trigger a detection signal if the following conditions are met:

- The RCS (Radar Cross-Section) of static objects is greater than or equal to the RCS of a human body.
- The relative speed between the objects and the sensor is greater than the minimum speed necessary for detection.

### 2.6.3.4 Prevention of unexpected restart

As for stationary installations, when the moving part where the sensor is installed is arrested because of detection, the system will switch to restart prevention safety function (if **Safety working mode** is not **Always-on access detection**), and the sensor will detect the presence of a human body (see Installation recommendations in "Appendix A: sensor lines" on page 137). Static objects are then automatically filtered out and no longer detected.

The restart of the moving vehicle or moving part of the machinery in the presence of static objects can be prevented using the following methods:

- Static object detection option enabled (see "Restart prevention function: static object detection option" on page 37).
- Anti-masking function: if the function is enabled, an error will occur when the static object will be close enough to limit the detection of the sensor.  
*Note: if the anti-masking function is active while the sensor is also moving, this could generate false alarms since the environment change during movement could be detected as tampering.*
- Manual restart: the restart is triggered externally and only once the static object is removed from the trajectory of the moving vehicle or moving part.
- Application logic on PLC/control unit that permanently stops the moving part if multiple stops occur immediately after the restart of the part. If the vehicle or the part stops very quickly after the restart, this probably means that there is a static obstacle. Once the moving part is stopped, the sensor does not detect the object anymore and therefore the part moves but it stops again as soon as it detects the object again.

## 2.7 Digital I/O interfaces

### Contents

This section includes the following topics:

2.7.1 Digital inputs .....	45
2.7.2 Digital outputs .....	46

## 2.7.1 Digital inputs

### 2.7.1.1 Introduction

The system has two type 3 dual channel digital inputs (according to IEC/EN 61131-2). Alternatively, the four channels can be used as single channel digital inputs (category 2). The ground reference is common for all the inputs (see "Terminal blocks and connector pin-outs" on page 127).

When using digital inputs, it is mandatory that the additional SNS input "V+ (SNS)" is connected to 24 V DC and that the GND input "V- (SNS)" is connected to the ground in order to:

- perform the correct input diagnostic
- assure the system safety level

### 2.7.1.2 Input functions

The function of each digital input must be programmed through the system application. The available functions are the following:

- **Stop signal**
- **Restart signal**
- **Muting group 1 or Muting group 2**
- **Dynamic configuration switch**
- **Fieldbus controlled** (if available)
- **System recondition**
- **Restart signal + System recondition**: according to the input signal duration, performs the **Restart signal** function or the **System recondition** function.
- **Anti-masking reference saving**
- **Anti-rotation reference saving**

For details about digital input signals, see "Digital input signals" on page 108.

### 2.7.1.3 Single or dual channel option

By default, each digital input function needs a signal on both channels to provide the redundancy required by Category 3.

The following digital input functions can also be used as a single channel (Category 2):

- **Restart signal**
- **Fieldbus controlled**
- **System recondition**
- **Restart signal + System recondition**
- **Anti-masking reference saving**
- **Anti-rotation reference saving**

### 2.7.1.4 Redundancy mode

Two types of redundancy mode are available for the dual channels input functions:

- **Coherent redundancy**

Input Channel 1	Input Channel 2	Input logic value
0	0	Low
1	1	High
0	1	Error
1	0	Error

- **Inverted redundancy**

Input Channel 1	Input Channel 2	Input logic value
0	1	Low
1	0	High
0	0	Error
1	1	Error

By default, the redundancy mode is coherent. For the following input functions, the inverted redundancy mode can be set to guarantee compatibility with different connected devices:

- **Muting group "N"** (only if pulse width = 0)
- **Restart signal**
- **Fieldbus controlled**
- **Dynamic configuration switch**
- **System recondition**
- **Restart signal + System recondition**
- **Anti-masking reference saving**
- **Anti-rotation reference saving**

### 2.7.1.5 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Digital input function	Settings > Digital Input-Output	DESIGN > control unit card > <b>DIGITAL INPUTS</b>
Single/dual channel input		
Dual channel redundancy		

### 2.7.1.6 SNS input

The control unit is provided with an **SNS** input (high logic level (1) = 24 V) needed to check the correct functioning of the inputs.

**NOTICE:** if at least one input is connected, the SNS input "V+ (SNS)" and the GND input "V- (SNS)" must also be connected.

## 2.7.2 Digital outputs

### 2.7.2.1 Outputs

The system has four digital OSSD short-circuit protected outputs that can be used individually (detection warning) or programmed as dual channel safety outputs (detection signal) to ensure the system safety level.

An output is activated when it switches from OFF to ON-state (from 0 V to 24 V) and deactivated when it switches from ON to OFF-state (from 24 V to 0).

### 2.7.2.2 Output functions

The function of each digital output must be programmed through the system application.

The available functions are the following:

- **Detection signal "N"**: (e.g., alarm signal) switches the selected output to OFF-state when a sensor detects a motion in detection field N\*, receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.  
**Note\*:** "N" is the number of the corresponding detection field (e.g., **Detection signal 1** for detection field 1, **Detection signal 2** for detection field 2).  
**Note:** when an OSSD is configured as **Detection signal "N"**, a second OSSD is automatically assigned to it to provide a safe signal.
- **Detection warning "N"** - only eXtended Line: (e.g., alarm signal) switches the selected output to OFF-state when a sensor detects a motion in detection field N\*, receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.  
**Note\*:** N is the number of the corresponding detection field (e.g., **Detection warning 1** for detection field 1, **Detection warning 2** for detection field 2).
- **Detection signal group 1 or Detection signal group 2**: switches the selected output to OFF-state when at least one sensor detects a motion in a detection field belonging to the group (see "Detection signal/warning group settings" on the next page), receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.  
**Note:** when an OSSD is configured as **Detection signal group 1 or Detection signal group 2**, a second OSSD is automatically assigned to it to provide a safe signal.
- **Detection warning group 1 or Detection warning group 2** - only eXtended Line: switches the selected output to OFF-state when at least one sensor detects a motion in a detection field belonging to the group (see "Detection signal/warning group settings" on the next page), receives a stop signal from the related input, or when there is a system failure. The selected output remains in OFF-state for at least 100 ms.
- **System diagnostic signal**: switches the selected output to OFF-state when a system fault is detected.
- **Muting enable feedback signal**

- **Fieldbus controlled** (if available)
- **Restart feedback signal**
- **Static object detection feedback signal**

Each output status can be retrieved by Fieldbus communication (if available).

### 2.7.2.3 Output configurations

The system installer can decide to configure the system as follows:

- two dual channel safety outputs (e.g., **Detection signal 1** and **Detection signal 2**, usually alarm and warning signals)
- one dual channel safety output (e.g., **Detection signal 1**) and two single channel output (e.g., **System diagnostic signal** and **Detection warning 2**)
- each output as a single output (e.g., **Detection warning 2**, **System diagnostic signal**, **Muting enable feedback signal** and **Restart feedback signal**)

 **WARNING!** To use Inxpect SRE 200 Series for a category 3 safety system, both the channels of a safety output must be connected to the safety system. Configuring a safety system with only one channel safety output may result in serious injuries due to an output circuit fault and a failure of the machinery to stop.

### 2.7.2.4 Dual channel safety output configuration

The dual channel safety output is automatically managed by the system application and it only matches the single OSSD outputs as follows:

- OSSD 1 with OSSD 2
- OSSD 3 with OSSD 4

### 2.7.2.5 Detection signal/warning group settings

Each detection field of each sensor can be assigned to a group to associate them with the same safety output.

Through the system application, each detection field of each sensor can be associated with a group or both groups. By default, a detection field does not belong to any group.

 **WARNING!** Consider the detection field dependency choice during the group's configuration. See "**Detection fields dependency and detection signal generation**" on page 24

#### Example

It is possible to configure that the following detection fields belong to group 1:

- Detection field 1 of Sensor 1
- Detection field 1 of Sensor 3
- Detection field 2 of Sensor 1

By doing so, a specific output assigned to **Detection signal group 1** or **Detection warning group 1** will switch to the OFF-state when a movement is detected in one of these detection fields.

### 2.7.2.6 Output status of detection signal outputs

The output status is the following:

- activated output (24 V DC): idle signal, no motion detected, and normal functioning
- deactivated output (0 V DC): motion detected in the detection field or failure detected in the system

### 2.7.2.7 Pulse test for detection signal outputs


A pulse test is provided for the detection signal output, in particular for the outputs configured as follows:

- **Detection signal "N"**
- **Detection warning "N"**
- **Detection signal group "N"**
- **Detection warning group "N"**

The test is performed with the idle signal periodically pulsed to 0 V to detect short-circuits to either 0 V or 24 V.

The pulse duration at 0 V ( $T_L$ ) can be set at 300  $\mu$ s or 2 ms through the system application.

**Note:** the devices connected to the OSSD should not respond to these temporary, self-diagnostic 0 V pulses of the signal.



For details, see "Technical references" on page 102.

### 2.7.2.8 OSSD diagnostic checks

Per default, the OSSD Diagnostic check (e.g., for short-circuits) is deactivated. This check can be activated through the system application.

If activated, the control unit will monitor:

- short-circuit between OSSDs
- 24 V short-circuit
- open circuit (only trips on demand, i.e., when the safety function is activated on the transition from 24 V to GND)

**Note:** the short-circuit to GND (fail-safe fault) is always monitored even if the OSSD diagnostic check is deactivated.

**⚠ WARNING! If an external common cause failure leads to a 24 V short-circuit on both the OSSDs, the control unit cannot communicate the safe state condition via OSSD. The integrator is responsible for avoiding this condition by monitoring the test pulses generated periodically on the OSSDs.**

**⚠ WARNING! To be compliant with the IEC TS 61496-5 standard, it is necessary to activate the OSSD diagnostic checks and set the Anti-masking sensitivity parameter to High.**


### 2.7.2.9 External resistor for OSSD outputs

To guarantee the correct connection between the OSSDs of the control unit and an external device, it may be necessary to add an external resistor.

If the pulse width set (**OSSD Pulse width**) is 300  $\mu$ s, it is strongly recommended to add an external resistor to guarantee the discharge time of the capacitive load. If it is set at 2 ms, an external resistance must be added if the resistor of the external load is greater than the maximum resistive load allowed (see "Technical data" on page 103).

Below are some standard values for the external resistor:

OSSD Pulse width value	External resistor ( $R_e$ )
300 $\mu$ s	1 k $\Omega$
2 ms	10 k $\Omega$



### 2.7.2.10 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
Digital output function	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL OUTPUTS</b>
Detection signal group	<b>Settings &gt; Detection field groups</b>	<b>DESIGN &gt; control unit card &gt; DETECTION FIELD GROUPS</b>
Detection signal pulse test	<b>Settings &gt; Digital Input-Output &gt; OSSD Pulse width</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL OUTPUTS</b>
OSSD diagnostic check activation	<b>Settings &gt; Digital Input-Output</b>	<b>DESIGN &gt; control unit card &gt; DIGITAL OUTPUTS</b>

## 2.8 Data exchange interfaces

### Contents

This section includes the following topics:

<b>2.8.1 Fieldbus communication (PROFIsafe)</b> .....	<b>49</b>
<b>2.8.2 Fieldbus communication (Safety over EtherCAT® - FSoE)</b> .....	<b>52</b>
<b>2.8.3 Fieldbus communication (CIP Safety™ on EtherNet/IP™)</b> .....	<b>53</b>
<b>2.8.4 MODBUS communication</b> .....	<b>55</b>

### 2.8.1 Fieldbus communication (PROFIsafe)

#### 2.8.1.1 PROFIsafe support

The safety communication using PROFIsafe is available on all the control units provided with the PROFIsafe interface. For details, see "Control units" on page 17.

#### 2.8.1.2 Siemens PLC and TIA Portal compatibility

Profisafe modules embedded in the control units are compliant only with TIA Portal software (version 15.1, 16, 17, 18 or 19) and Siemens PLC from 1200 and 1500 series.

Older versions of Siemens software or older PLC models do not have the capability to include 12-bytes size structures.

### 2.8.1.3 Communication with the machinery

The Fieldbus makes the following actions possible:

- Choose preset configurations dynamically.
- Read the status of the inputs.
- Read the status of each detection field
- Control the outputs.
- Read the target data.
- Mute the sensors.
- Enable the restart signal.
- Enable the system recondition signal.
- Save the anti-masking reference
- Save the anti-rotation reference

For details, see the PROFIsafe communication Reference guide.

### 2.8.1.4 Input data coming from the PLC

If neither digital input nor OSSD is configured as **Fieldbus controlled**, the behavior of the input data coming from the PLC is as described below:

Condition	Input data coming from the PLC	System behavior
IOPS (PLC provider status) = bad	the last valid value of the input variable is retained	the system keeps working in its normal operating state
Connection loss	the last valid value of the input variable is retained	the system keeps working in its normal operating state
After power-up	the initial values (set to 0) are used for the input variables	the system keeps working in its normal operating state

If at least one digital input or OSSD is configured as **Fieldbus controlled**, the behavior of the input data coming from the PLC is as described below:

Condition	Input data coming from the PLC	System behavior
IOPS (PLC provider status) = bad	the last valid value of the input variable is retained	the system keeps working in its normal operating state
Connection loss	the last valid value of the input variable is retained	the system transits to safe state, deactivating the OSSDs, until the connection is re-established.
After power-up	the initial values (set to 0) are used for the input variables	the system remains in a safe state with the OSSDs deactivated, until the input data are passivated.

### 2.8.1.5 Data exchanged through PROFIsafe

The following table details the data exchanged through the Fieldbus communication:

 **WARNING! The system is in the safe state if the control unit status byte of the System configuration and status module PS2v6 or PS2v4 is different from "0xFF".**

Data type	Description	Communication direction
Safe	<p>SYSTEM STATUS DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>internal status</li> <li>status of each of the four OSSDs</li> <li>status of each single channel and dual channel input</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>status of each detection field (target detected or not) or error status</li> <li>status of static object detection option</li> <li>muting status</li> </ul>	from the control unit
Safe	<p>SYSTEM SETTING COMMAND</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>set the ID of the dynamic configuration that shall be activated</li> <li>set the status of each of the four OSSDs</li> <li>save the reference for the anti-rotation around axes</li> <li>enable the restart signal</li> <li>enable the system recondition signal</li> <li>save the anti-masking reference</li> <li>save the anti-rotation reference</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>set the muting status</li> </ul>	to the control unit
Safe	<p>DYNAMIC CONFIGURATION STATUS</p> <ul style="list-style-type: none"> <li>ID of the dynamic configuration currently active</li> <li>signature (CRC32) of the dynamic configuration ID currently active</li> </ul>	from the control unit
Safe	<p>TARGET DATA</p> <ul style="list-style-type: none"> <li>Current distance and angle of the targets detected by each sensor. For each detection field of each sensor, only the closest target to the sensor is considered.</li> </ul>	from the control unit
Unsafe	<p>DIAGNOSTIC DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>internal status with an extended description of the error condition</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>internal status with an extended description of the error condition</li> </ul>	from the control unit
Unsafe	SYSTEM STATUS AND TARGET DATA	from the control unit

### 2.8.1.6 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
See "Parameters list" below	Admin > Fieldbus Parameters	DESIGN > control unit card > PROFIsafe FIELDBUS

### 2.8.1.7 Parameters list

Parameter	Min	Max	Default
System configuration and status PS2v6	1	65535	145
Sensors information PS2v6	1	65535	147
Sensor 1 detection status PS2v6	1	65535	149
Sensor 2 detection status PS2v6	1	65535	151
Sensor 3 detection status PS2v6	1	65535	153
Sensor 4 detection status PS2v6	1	65535	155
Sensor 5 detection status PS2v6	1	65535	157

Parameter	Min	Max	Default
Sensor 6 detection status PS2v6	1	65535	159
System configuration and status PS2v4	1	65535	146
Sensors information PS2v4	1	65535	148
Sensor 1 detection status PS2v4	1	65535	150
Sensor 2 detection status PS2v4	1	65535	152
Sensor 3 detection status PS2v4	1	65535	154
Sensor 4 detection status PS2v4	1	65535	156
Sensor 5 detection status PS2v4	1	65535	158
Sensor 6 detection status PS2v4	1	65535	160

## 2.8.2 Fieldbus communication (Safety over EtherCAT® - FSoE)

### 2.8.2.1 FSoE support

The safety communication using FSoE is available on all the control units provided with the FSoE interface. For details, see "Control units" on page 17.

### 2.8.2.2 Communication with the machinery

The Fieldbus makes the following actions possible:

- Choose preset configurations dynamically.
- Read the status of the inputs.
- Read the status of each detection field
- Control the outputs.
- Mute the sensors.
- Enable the restart signal.
- Enable the system recondition signal.

For details, see the FSoE communication Reference guide.

### 2.8.2.3 Data exchanged through FSoE

The following table details the data exchanged through the Fieldbus communication:

 **WARNING! The system is in the safe state if Byte 0 of the selected TxPDO has at least one of its bits equal to 0, except for bit 4, which can assume any value.**

Data type	Description	Communication direction
Safe	<p>SYSTEM STATUS DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>internal status</li> <li>status of each of the four OSSDs</li> <li>status of each of single channel inputs and dual channel inputs</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>status of each detection field (target detected or not) or error status</li> <li>status of static object detection for each detection field</li> <li>muting status</li> </ul>	from the control unit
Safe	<p>SYSTEM SETTING COMMAND</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>set the ID of the dynamic configuration that shall be activated</li> <li>set the status of each of the four OSSDs</li> <li>enable the system recondition signal</li> <li>enable the restart signal</li> <li>save the anti-masking reference</li> <li>save the anti-rotation reference</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>set the muting status</li> </ul>	to the control unit
Safe	<p>DYNAMIC CONFIGURATION STATUS</p> <ul style="list-style-type: none"> <li>ID of the dynamic configuration currently active</li> <li>signature (CRC32) of the dynamic configuration ID currently active</li> </ul>	from the control unit
Unsafe	<p>DIAGNOSTIC DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>internal status with an extended description of the error condition</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>internal status with an extended description of the error condition</li> </ul>	from the control unit
Unsafe	SYSTEM STATUS	from the control unit

#### 2.8.2.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
See "Parameters list" below	Admin > Fieldbus Parameters	DESIGN > control unit card > <b>FSoE FIELDBUS</b>

#### 2.8.2.5 Parameters list

Parameter	Min	Max	Default
FSoE Safe Address	1	65535	145

### 2.8.3 Fieldbus communication (CIP Safety™ on EtherNet/IP™)

#### 2.8.3.1 CIP Safety support

The safety communication using CIP Safety on EtherNet/IP is available on all the control units provided with the CIP Safety interface. For details, see "Control units" on page 17.

### 2.8.3.2 Communication with the machinery

The Fieldbus makes the following actions possible:

- Choose preset configurations dynamically.
- Read the status of the inputs.
- Read the status of each detection field
- Control the outputs.
- Mute the sensors.
- Enable the restart signal.
- Enable the system recondition signal.
- Save the anti-masking reference
- Save the anti-rotation reference

For details, see the CIP Safety communication Reference guide.

### 2.8.3.3 Data exchanged through CIP Safety

 **WARNING!** The system is in the safe state if Byte 0 of the selected safety input connection (T20) has at least one of its bits equal to 0, except for bit 4, which can assume any value.

The following table details the data exchanged through the Fieldbus communication:

Data type	Description	Communication direction
Safe	<p>SYSTEM STATUS DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>• internal status</li> <li>• status of each of the four OSSDs</li> <li>• status of each of single channel inputs and dual channel inputs</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>• status of each detection field (target detected or not) or error status</li> <li>• status of static object detection for each detection field</li> <li>• muting status</li> </ul>	from the control unit
Safe	<p>SYSTEM SETTING COMMAND</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>• set the ID of the dynamic configuration that shall be activated</li> <li>• set the status of each of the four OSSDs</li> <li>• enable the system recondition signal</li> <li>• enable the restart signal</li> <li>• save the anti-masking reference</li> <li>• save the anti-rotation reference</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>• set the muting status</li> </ul>	to the control unit
Safe	<p>DYNAMIC CONFIGURATION STATUS</p> <ul style="list-style-type: none"> <li>• ID of the dynamic configuration currently active</li> <li>• signature (CRC32) of the dynamic configuration ID currently active</li> </ul>	from the control unit
Unsafe	<p>DIAGNOSTIC DATA</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>• internal status with an extended description of the error condition</li> </ul> <p>Sensor:</p> <ul style="list-style-type: none"> <li>• internal status with an extended description of the error condition</li> </ul>	from the control unit
Unsafe	SYSTEM STATUS	from the control unit

### 2.8.3.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
See "Parameters list" below	<b>Admin &gt; Fieldbus Parameters</b>	<b>DESIGN &gt; control unit card &gt; CIP Safety FIELDBUS</b>

### 2.8.3.5 Parameters list

Parameter	Min	Max	Default
IP Address	-		DHCP
Network mask	-		DHCP
Gateway	-		DHCP
Host name	-		[empty]
Safety Network Number (SNN)	-		0xFFFFFFFFFFFF
Fieldbus endianness (only for non-safe connections)	Big Endian, Little Endian		Big Endian

## 2.8.4 MODBUS communication

### 2.8.4.1 MODBUS support

MODBUS communication is available on all the control units provided with the MODBUS interface. For details, see "Control units" on page 17.

### 2.8.4.2 MODBUS communication enabling

The MODBUS communication can be enabled and set via the system application

Within the Ethernet network, the control unit acts like a server. The client must send requests to the IP address of the server on the MODBUS listening port (default port is 502).

### 2.8.4.3 Data exchanged through MODBUS

The following table details the data exchanged through the MODBUS communication:

Data type	Description	Communication direction
Unsafe	SYSTEM STATUS DATA Control unit: <ul style="list-style-type: none"><li>internal status</li><li>status of each of the four OSSDs</li><li>status of each single channel and dual channel input</li><li>revision information</li></ul> Sensor: <ul style="list-style-type: none"><li>status of each detection field (target detected or not) or error status</li><li>muting status</li><li>revision information</li></ul>	from the control unit
Unsafe	DYNAMIC CONFIGURATION STATUS <ul style="list-style-type: none"><li>ID of the dynamic configuration currently active</li><li>signature (CRC32) of the dynamic configuration ID currently active</li></ul>	from the control unit
Unsafe	TARGET DATA <ul style="list-style-type: none"><li>Current distance and angle of the targets detected by each sensor. For each detection field of each sensor, only the closest target to the sensor is considered.</li></ul>	from the control unit
Unsafe	DIAGNOSTIC DATA Control unit: <ul style="list-style-type: none"><li>internal status with an extended description of the error condition</li></ul> Sensor: <ul style="list-style-type: none"><li>internal status with an extended description of the error condition</li></ul>	from the control unit

#### 2.8.4.4 How to configure it in the system application

Parameter	Inxpect Safety	Inxpect Safety Studio
See "Parameters list" below	<b>Admin &gt; MODBUS Parameters</b> <b>Admin &gt; Network Parameters</b>	<b>DESIGN &gt; control unit card &gt; MODBUS</b> <b>DESIGN &gt; control unit card &gt; MODBUS &gt; SET DEVICE ETHERNET PARAMETERS</b>

#### 2.8.4.5 Parameters list

Parameter	Min	Max	Default
MODBUS Enable	Enabled, Disabled		Enabled
MODBUS Listening port	1	65534	502
Ethernet IP Address	-	-	192.168.0.20
Ethernet Netmask	-	-	255.255.255.0
Ethernet Gateway	-	-	192.168.0.1
Ethernet TCP port	1	65535	65534

# 3. Installation and usage

## 3.1 Installation and use procedures

### Contents

This section includes the following topics:

3.1.1 Before installation .....	57
3.1.2 Install Inxpect SRE 200 Series .....	57
3.1.3 Set the sensor inclination with a 1° precision .....	64
3.1.4 Configure Inxpect SRE 200 Series .....	67
3.1.5 Validate the safety functions .....	68
3.1.6 Fieldbus network integration .....	71
3.1.7 Other procedures .....	72

### 3.1.1 Before installation

#### 3.1.1.1 Materials required

- Two tamper-proof screws (see "Tamper-proof screws specifications" on page 106) to mount each sensor.
- Cables to connect the control unit to the first sensor and the sensors to one another (see "CAN bus cables recommended specifications" on page 106).
- A data USB cable with a micro-USB connector (micro-B type) or, only if the Ethernet port is available, an Ethernet cable to connect the control unit to the computer.
- A bus terminator (product code: 07000003) with resistance of 120 Ω for the last sensor of the CAN bus.
- A screwdriver for tamper-proof screws (see "Tamper-proof screws specifications" on page 106) to be used with the Hex pin security bit supplied in the control unit package.

#### 3.1.1.2 Operating system required

- Microsoft Windows 64 bit 11 or later
- Apple OS X 14.0 Sonoma or later

#### 3.1.1.3 Install the system application (Inxpect Safety or Inxpect Safety Studio)

*Note: if the installation fails, the dependencies needed by the application may be missing. Update your operating system or contact our Technical Support to receive assistance.*

1. Download the application from the <https://tools.inxpect.com> website and install it on the computer.
2. With Microsoft Windows operating system, download and install from the same site also the driver for USB connection.

#### 3.1.1.4 Initiate Inxpect SRE 200 Series

1. Calculate the position of the sensor and the depth of the dangerous area (see "Separation distance calculation" on page 123).
2. "Install Inxpect SRE 200 Series".
3. "Configure Inxpect SRE 200 Series".
4. "Validate the safety functions".
5. Optional. Integrate Fieldbus network, see "Fieldbus network integration" on page 71.

### 3.1.2 Install Inxpect SRE 200 Series

#### 3.1.2.1 Install procedure

1. "Install the control unit".
2. Optional. "Mount 3-axis bracket".
3. "Install the sensors".

### 3.1 Installation and use procedures

4. "Connect the sensors to the control unit".

**Note:** connect the sensors to the control unit off-site if access to the connectors becomes difficult once installed.

#### 3.1.2.2 Install the control unit

 **WARNING!** To prevent tampering, make sure the control unit is only accessible to authorized personnel (e.g., key-locked electrical panel)

1. Mount the control unit on the DIN rail.
2. Make electrical connections (see "Terminal blocks and connector pin-outs" on page 127 and "Electrical connections" on page 129).

**NOTICE:** if at least one input is connected, the SNS input "V+ (SNS)" and the GND input "V- (SNS)" must also be connected.

**NOTICE:** when powered, the system takes about 20 s to start. During that period, the outputs and the diagnostic functions are deactivated, and the green sensor status LEDs of the connected sensors in the control unit flash.

**NOTICE:** make sure to avoid any EMC interference during the control unit installation.

**Note:** to correctly connect the digital inputs, see "Voltage and current limits for digital inputs" on page 127.


#### 3.1.2.3 Mount 3-axis bracket

The bracket that allows rotation around the x-axis (roll) is an accessory in the package.


**NOTICE:** for environments with strong vibrations, it is recommended to use the 2-axis bracket instead.

**Note:** for an example of sensor installation, see "Examples of sensor installation" on page 62.


1. Unscrew the screw at the bottom and remove the bracket with the sensor and the aligning ring.



2. Attach the roll bracket to the base. Use the tamper-proof screw provided with the bracket.



3. Mount the bracket with the sensor and the aligning ring. Use the tamper-proof screw provided with the bracket.



### 3.1.2.4 Install the sensors

**Note:** for an example of sensor installation, see "Examples of sensor installation" on page 62.


**Note:** the usage of a thread-locking fluid on the threads of fasteners is suggested, especially when the sensor is installed on a moving or vibrating part of the machinery.

**Note:** if no bracket is used for sensor installation, use tamper-proof screws and threadlocker.

### 3.1 Installation and use procedures


1. Position the sensor as indicated in the configuration report and fasten the bracket with two tamper-proof screws directly onto the floor or another support.

**NOTICE:** make sure the support does not inhibit machinery commands.




2. With an Allen key, loosen the screw at the bottom to pan the sensor.

**Note:** to avoid damaging the bracket, loosen the screw completely before panning the sensor.




3. Pan the sensor until it reaches the desired position.


**Note:** a notch is equal to a  $10^\circ$  of rotation.



4. Tighten the screw.




5. Loosen the tamper-proof screws to tilt the sensor.




6. Tilt the sensor to the desired inclination (see "Applications" on page 43).


**Note:** a notch is equal to a 10° of inclination.



7. To set the inclination with 1° precision, see "Set the sensor inclination with a 1° precision" on page 64.





8. Tighten the screws.





### 3.1.2.5 Examples of sensor installation

**NOTICE:** refer to the sensor LED position to identify the sensor field of view.




*Floor installation*



*Wall installation (for example for access control of an entrance).*

**Note:** install the sensor so that the field of view is tilted towards the outside of the hazardous area to avoid false alarms.



Installation on the machinery.


### 3.1.2.6 Connect the sensors to the control unit

**Note:** the total maximum length of the CAN bus line is 80 m (262.5 ft).

**Note:** when replacing a sensor, to confirm the change, in the system application, save the changes and send the configuration to the control unit.


1. With the cable validator tool (downloadable from the site <https://tools.inxpect.com>), decide if the control unit will be positioned at the end of the chain or inside it (see "Chain examples" below).
2. Set the DIP switch of the control unit based on its position in the chain.
3. Connect the desired sensor directly to the control unit.
4. To connect another sensor, connect it to the last sensor in the chain or directly to the control unit to start a second chain.
5. Repeat step 4 for all the sensors to be installed.
6. Insert the bus terminator (product code: 07000003), into the free connector of the last sensor of the chain(s).

### 3.1.2.7 Chain examples



Chain with control unit at the end of the chain and a sensor with bus terminator

### 3.1 Installation and use procedures





Chain with control unit inside the chain and two sensors with bus terminator

#### 3.1.3 Set the sensor inclination with a 1° precision


##### 3.1.3.1 Procedure

In the following procedure, the sensor inclination angle to be considered is that of the sensor relative to the default position of the 2-axis bracket, regardless of how the bracket is assembled and how the sensor is installed.


1. Remove the tamper-proof screws and remove the sensor from the bracket.
2. Remove the internal adjustment ring from the bracket.




3. Reinsert the adjustment ring in the bracket holes according to the unit value of the desired inclination degrees (see "How to choose the adjustment ring position" on the next page).




4. Insert the sensor and the tamper-proof screws in the bracket (see "How to insert the sensor" on the next page).



5. Tilt the sensor downward or upward the number of notches corresponding to the tens place value of the desired angle (for example, for an inclination angle of +38°, the tens place value is 3: tilt the sensor upward three notches).




6. Tighten the screws.




### 3.1.3.2 How to choose the adjustment ring position

On both sides of the bracket, insert the adjustment ring in the hole corresponding to the desired degree unit value (0-9°).

For example, for 8° (upward), +38° (upward) and -18° (downward) the unit value is always 8°:



Side 1



Side 2


### 3.1.3.3 How to insert the sensor

To insert the sensor in the bracket, take into account the following rules:


To tilt the sensor...	...then insert the sensor as follows	See
upward	with the <b>rear</b> of the case facing the desired angle	"Example 1 (upward): +62°" below
downward	with the <b>front</b> of the case facing the desired angle	"Example 2 (downward): -37°" on the next page

#### Example 1 (upward): +62°

In this example, the rear of the case is facing the following angles: 1°, 2°, 3°, 4°, 5°.




Side 1




Side 2

**Example 2 (downward): -37°**

In this example, the front of the case is facing the following angles: 5°, 6°, 7°, 8°, 9°.




Side 1




Side 2

**3.1.3.4 Example: set the sensor inclination to +62°**

1. Insert the adjustment ring in the hole corresponding to 2°.




Side 1



Side 2

2. Insert the sensor in the bracket with the rear of the sensor facing the 2° angle.



3. Tilt the sensor upward of six notches.

**3.1.4 Configure Inxpect SRE 200 Series****3.1.4.1 Configure procedure****Procedure using Inxpect Safety**

1. Connect the control unit to the computer using a data USB cable with a micro-USB connector or the Ethernet cable (if an Ethernet port is available).
2. Supply power to the control unit.
3. Start the application.
4. Define the area to be monitored.
5. Configure the inputs and outputs.

### 3.1 Installation and use procedures

6. Optional. Synchronize the control units.
7. Save and print the configuration.

For more information about these steps, see "Configure the system" on page 74.

#### Procedure using Inxpect Safety Studio

1. Start the application.
2. Create a project and add 3D models and 2D models as desired.
3. Add and configure the control units.
4. Add and configure the sensors of each control unit.
5. Save the project.
6. Connect the control unit to the computer using a data USB cable with a micro-USB connector or the Ethernet cable (if an Ethernet port is available).
7. Supply power to the control unit.
8. Set the control unit connection parameters.
9. Pair the project sensors with the corresponding sensors physically connected to the control unit.
10. Send the configuration to the control unit.
11. Print the configuration.

For more information about these steps, see "Configure the system" on page 78.

## 3.1.5 Validate the safety functions

### 3.1.5.1 Validation

The validation is addressed to the machinery manufacturer and the system installer.

Once the system has been installed and configured, check that the safety functions are activated/deactivated as expected and that the dangerous area is monitored by the system.

The machinery manufacturer must define all the required tests based on the application conditions and the risk assessment.

 **WARNING! The system response time is not guaranteed during the validation procedure.**

 **WARNING! The system application facilitates the installation and configuration of the system. Nevertheless, the validation process described below is still required to complete the installation.**

### 3.1.5.2 Validation procedure for the access detection function

The access detection safety function must be operative, and the following requirements must be fulfilled:

- The target (for stationary applications) or the machinery/vehicle on which the sensor is installed (for mobile applications) must move in compliance with the maximum allowed speed. For details, see "Access detection speed limits" on page 26.
- No objects should completely occlude the target.

#### Starting conditions

- Machinery switched off (Safe condition)
- Inxpect SRE 200 Series configured to fulfill the access detection safety function
- Detection signals monitored via digital outputs or safety Fieldbus

#### Test setup

The following tests aim to validate the sensor's performance for the access detection safety function.

In stationary applications, all the tests share these parameters:

<b>Target type</b>	Human
<b>Target speed</b>	In the range [0.1, 1.6] m/s ([0.33, 5.25] ft/s), with particular attention to the minimum and the maximum speeds.
<b>Target direction</b>	Any
<b>Acceptance criteria</b>	The system reaches the safe state via digital outputs or Fieldbus when the target accesses the area during the test.

In mobile applications, all the tests share these parameters:

<b>Target type</b>	Human
<b>Machinery/Vehicle speed</b>	See the access detection speed limit for mobile application of each sensor, reported in the "Main features" chapter in "Appendix A: sensor lines" on page 137.
<b>Target movement</b>	Stationary
<b>Acceptance criteria</b>	The system reaches the safe state via digital outputs or Fieldbus when, during the movement of the machinery/vehicle, the sensor's field of view reaches the target.

### Validation test

The validation procedure of Inxpect SRE 200 Series is reported below:

1. Identify the test positions, including those locations where the operator could access during the production cycle:
  - a. boundaries of the dangerous area
  - b. intermediate points between sensors
  - c. positions that are partially hidden by existing or presumed obstacles during the operating cycle
  - d. positions indicated by the risk assessor
2. Check that the corresponding detection signal is active or wait for its activation.
3. Perform the test according to the test setup previously defined, moving toward one of the test positions.
4. Check that the test acceptance criteria previously defined are fulfilled. If the test acceptance criteria are not fulfilled, see "Troubleshooting validation" on page 71.
5. Repeat steps 2, 3, and 4 for each test position.

#### 3.1.5.3 Validation procedure for the restart prevention function

The restart prevention safety function must be operative, and the following requirements must be fulfilled:

- The person must breathe normally.
- No objects should completely occlude the person.

### Starting conditions

- Machinery switched off (safe condition)
- Inxpect SRE 200 Series configured to fulfill the restart prevention safety function
- Detection signals monitored via digital outputs or safety Fieldbus

### Test setup

The following tests aim to validate the performance of the sensor restart prevention safety function.

All the tests share the following parameters:

<b>Configured radar restart timeout</b>	At least 4 s
<b>Target type</b>	Human according to ISO 7250, breathing normally
<b>Target speed</b>	0 m/s (0 ft/s)
<b>Target pose</b>	Standing or crouching (or other poses if requested by specific risk assessment)
<b>Test duration</b>	At least 20 s
<b>Acceptance criteria</b>	The detection signal remains deactivated during the test. When the operator leaves the area; the detection signal is activated.

### Validation test

The validation procedure of the Inxpect SRE 200 Series system is reported below:



1. Identify the test positions, including those locations where the operator should normally be located during the production cycle:
  - boundaries of the dangerous area
  - intermediate points between sensors
  - positions that are partially hidden by already present or presumed obstacles during the operating cycle
  - positions indicated by the risk assessor
2. Access the dangerous area and go to one of the test positions: the corresponding detection signal should be deactivated.
3. Perform the test according to the test setup previously defined.

### 3.1 Installation and use procedures

4. Check that the test acceptance criteria previously defined are fulfilled.
5. If the test acceptance criteria are not fulfilled, see "Validate the system with the system application" on the next page.
6. Repeat steps 2, 3, and 4 for each test position.

### Example of test positions

The following images show examples of positions to be tested and suggestions about identifying other possible positions of interest.



**Position 1:** position outside the dangerous area

**Position 2:** position hidden from the operator's viewpoint at "Position 1". Any other similar hidden position should be tested.

**Position 3:** position at the center distance between two sensors and/or close to the boundaries of the dangerous area (e.g., along safety fences). This position is suggested to verify that the detection fields of different sensors overlap without leaving uncovered areas. Standing close to the fences also allows for verifying that the sensors are rotated correctly, covering both the right and the left side.

**Position 4:** possible hidden position by elements in the environment that are present or not present during the validation process. Examples: Obstacle 2 precludes detection by Sensor 1 (**S1**). Obstacle 3 is partially present during the Validation process but will likely be present during the normal operating cycle and will preclude the detection of Sensor 4 (**S4**). This position must be covered by additional Sensor 5 (**S5**) and Sensor 6 (**S6**) that should be added within a proper feasibility study.

**Position 5:** any raised and walkable position indicated by the risk assessor.

Other positions can be indicated by the risk assessor or the machinery manufacturer.

### 3.1.5.4 Validate the system with the system application

 **WARNING!** When the validation function is active, the system response time is not guaranteed.

The system application is helpful during the safety functions validation phase and allows the actual field of view of the sensors to be checked based on their installation position.

To validate the safety functions using Inxpect Safety, see "Validate the safety functions" on page 76.

To validate the safety functions using Inxpect Safety Studio, refer to Inxpect Safety Studio user manual.

### 3.1.5.5 Additional checks for safety Fieldbus

- Refer to the relevant documentation to integrate the Fieldbus properly, see "Fieldbus network integration" below.
- Check safety Fieldbus connection cables and make certain they function as intended.
- Check the safety Fieldbus settings in the configuration.
- Only for CIP Safety™: before entering the configuration signature into the configuration of the PLC of the machinery, check the configuration of the control unit.
- Only for CIP Safety™: check that the assigned SNN numbers for each safety or safety sub-net are unique system-wide.

### 3.1.5.6 Troubleshooting validation

Problem	Cause	Solution
The detection signal does not remain deactivated during the restart prevention test, or it does not deactivate during the access detection test	Presence of objects obstructing the field of view	If possible, remove the object. Otherwise, implement additional safety measures in the area where the object is present (e.g., adding new sensors).
	Position of one or more sensors	Position the sensors to ensure that the monitored area is adequate for the dangerous area (see "Applications" on page 43).
	Inclination and/or installation height of one or more sensors	<ol style="list-style-type: none"> <li>1. Change the sensor's inclination and/or installation height to ensure the monitored area is adequate for the dangerous area (see "Applications" on page 43).</li> <li>2. Note or update the inclination and installation height of the sensors in the printed configuration report.</li> </ol>
	Inadequate restart timeout (only with the static object detection option enabled)	Change the <b>Restart timeout</b> parameter through the system application and verify that it is set to at least 4 seconds for each sensor.
After that the operator leaves the area, the detection signal does not activate	Presence of moving objects in the sensor's field of view (including vibrations of metal parts where the sensors are installed or vibration of brackets)	Identify the moving objects/brackets and, if possible, tighten all the loose parts
	Reflections of signals	Change the sensor positions or adjust the detection fields reducing the detection distance

## 3.1.6 Fieldbus network integration

### 3.1.6.1 Integration procedure

The integration into the Fieldbus network may differ depending on the control unit model and type. Refer to the relevant additional manuals:

- C201A-PNS and C201B-P: PROFIsafe communication Reference guide (Inxpect 100S\_200S PROFIsafe RG\_7\_00067\_en)

### 3.1 Installation and use procedures

- C201A-F and C201B-F: FSoE communication Reference guide (Inxpect 100S\_200S FSoE RG\_7\_00237\_en)
- C201B-C: CIP Safety communication Reference guide (Inxpect 100S\_200S CIP RG\_7\_00326\_en)

## 3.1.7 Other procedures

### 3.1.7.1 Restore factory default settings

**WARNING!** The system is provided without any valid configuration. Therefore the system maintains the safe state at the first start-up until a valid configuration is sent to the control unit via the system application.

**WARNING!** The procedure resets both the configuration and the password of all the users.


#### Procedure using Inxpect Safety

1. Log in to the Inxpect Safety application as the Admin user.
2. In **Admin > FACTORY RESET**.

#### Procedure using the reset button on the control unit

1. Press and hold the button **[C]** for longer than 10 seconds: all the system status LEDs **[B]** turn on (steady orange), and the system is ready to be reset.
2. Release the button **[C]**: all the system status LEDs **[B]** turn on (flashing green), and the reset procedure starts. The procedure can last up to 30 seconds. Do not switch off the system during the reset.

**Note:** if the button is pressed for longer than 30 seconds, the status of the LEDs switches to red, and the reset is not performed even after the button is released.




### 3.1.7.2 Reset the control unit Ethernet parameters

1. Ensure the control unit is turned on.
2. Press the Network parameter reset button and hold it down during steps 3 and 4.
3. Wait for five seconds.
4. Wait until all the six LEDs on the control unit turns steady green: the Ethernet parameters are set to their default values (see "Ethernet connection (if available)" on page 103).
5. Configure the control unit again.

### 3.1.7.3 Restore network parameters

**WARNING!** After the restore network parameters procedure, the system goes into the safe state. The configuration must be validated and, if necessary, modified through the system application. Then save and send the configuration to the control unit.

1. To restore the network parameters to the default settings, press and hold the reset button **[C]** on the control unit for 2 to 5 seconds: the first three system status LEDs **[B]** turn on (steady orange) and the network parameters are ready to be reset.
2. Release the button **[C]**: the reset is performed.



## 3.2 Use Inxpect Safety application

### Contents

This section includes the following topics:

<b>3.2.1 Get to know Inxpect Safety</b>	73
<b>3.2.2 Configure the system</b>	74
<b>3.2.3 Validate the safety functions</b>	76
<b>3.2.4 Manage the configuration</b>	76

### 3.2.1 Get to know Inxpect Safety

#### 3.2.1.1 Compatibility

Inxpect Safety application can manage all sensors, except for S202A sensors.

#### 3.2.1.2 Main menu

Page	Function
<b>Dashboard</b>	Display main information on the configured system. <i>Note: the messages show the same information in the log files. For the meanings of the messages, see the chapters on logs in "Troubleshooting" on page 84.</i>
<b>Configuration</b>	Define the monitored area. Configure the sensors, their shape, and the detection fields. Define the dynamic configurations. Choose the safety working mode. Enable the static object detection option. Set the restart timeout.
<b>Settings</b>	Configure the sensor groups. Choose the detection fields dependency. Enable the anti-tampering functions. Synchronize more control units. Configure the inputs and outputs function. Perform the configuration backup and load a configuration. Download the log. Perform the sensor Node ID assignment. Other general functions.

Page	Function
<b>Admin</b>	<p>Configure and manage the users.</p> <p>Enable the SD Backup and the SD Restore.</p> <p>Perform a factory reset.</p> <p>Configure, show, and change the Network parameters (if available).</p> <p>Configure, show and change the MODBUS parameters (if available).</p> <p>Configure, show and change the Fieldbus parameters (if available).</p> <p>Set labels for control units and sensors.</p>
<b>Validation</b>	<p>Start the validation procedure.</p> <p><b>Note:</b> the messages shown in this page are those in the log file. To know the meaning of the messages, see the chapters on logs in "Troubleshooting" on page 84.</p>
 <b>REFRESH CONFIGURATION</b>	Refresh configuration or ignore unsaved changes.
<b>User</b>	<p>Change user profile.</p> <p>Modify account settings.</p>
<b>Control unit</b>	<p>Retrieve control unit information.</p> <p>Close the connection with the control unit and allow it to connect to another control unit.</p>
	Change the language.

### 3.2.1.3 Inxpect Safety application usage

To use the application, the control unit must be connected to a computer with a data USB cable or, if the Ethernet port is available, an Ethernet cable. The USB cable allows to configure the system locally, whereas the Ethernet cable allows to do it remotely.

The Ethernet communication between the control unit and the Inxpect Safety application is secured by the most advanced security protocols (TLS).

## 3.2.2 Configure the system

### 3.2.2.1 Start Inxpect Safety application

1. Connect the control unit to the computer using a data USB cable with a micro-USB connector or the Ethernet cable (if an Ethernet port is available).
2. Supply power to the control unit.
3. Start the Inxpect Safety application.
4. Choose the connection mode (USB or Ethernet).

**Note:** the default IP address for the Ethernet connection is 192.168.0.20. The computer and the control unit must be connected to the same network.

5. Set a new admin password, memorize it, and provide it only to authorized people.
6. Select the system Inxpect SRE 200 Series, the sensor model-type, and the number of sensors.
7. Optional. Reset and re-assign all Node IDs.
8. Set the country in which the system is installed.

**Note:** this setting does not have any effect on system performance or safety. The country selection is requested during the first installation of the system to configure the system's radio profile, which must comply with the national regulations of the installation country.

9. Only if the selected country is **United States** or **Canada**, set the installation type in which the system is installed (**Indoor** or **Outdoor**).
10. Select the application type:
  - for stationary applications, select **Stationary**.
  - for installation on a machinery moving gantry, on a truck on rails, on a crane, select **Mobile**.
  - for both automated guided vehicles and vehicles with driver, select **Vehicle**.

**Note:** the algorithms are optimized to minimize the interference between sensors based on the installation conditions. Even though this choice does not affect the performance and the robustness, it is mandatory to select the correct application type.

### 3.2.2.2 Define the area to be monitored

 **WARNING!** The system is disabled during configuration. Prepare opportune safety measures in the dangerous area protected by the system before configuring the system.

1. In the Inxpect Safety application click **Configuration**.
2. Optional. Add the desired number of sensors in the plane.
3. Define the position and inclination of each sensor.

 **WARNING!** Set the values of those parameters accurately because the system behavior is optimized following those values.

4. Choose the area shape (only Pro line and Omni line sensors).
5. Define the safety working mode, detection distance, angular coverage, and restart timeout for each detection field of each sensor.
6. Optional. Enable the **Static object detection** option for each detection field only if needed. For details, see "Restart prevention function: static object detection option" on page 37.

### 3.2.2.3 Configure the inputs and outputs

1. In the Inxpect Safety application, click **Settings**.
2. Click **Digital Input-Output** and define the input and output functions.
3. If the muting is managed, click **Settings** > **Muting** and assign the sensors to the groups according to the logic of the digital inputs.
4. If needed, in **Settings** > **Restart function** and choose the type of managed restart.
5. Click **APPLY CHANGES** to save the configuration.

### 3.2.2.4 Save and print the configuration

1. In the application, click **APPLY CHANGES**: the sensors will save the inclination set and the surrounding environment. The application will transfer the configuration to the control unit, and once transfer is complete it will generate a configuration report.
2. Click  to save and print the report.

**Note:** to save the PDF, a printer must be installed on the computer.

3. Ask the authorized person for a signature.

### 3.2.2.5 Re-assign the Node IDs

#### Type of assignment

**Note:** if the connected sensors do not already have a Node ID assigned (e.g., at first startup), the system automatically assigns them a Node ID during the installation procedure.

Three types of assignment are possible:

- Manual: to assign the Node ID to a sensor at a time. Can be performed with all the sensors already connected or after each connection. Useful for adding a sensor or to change Node ID to a sensor.
- Automatic: to assign the Node IDs to all the sensors at once. To be performed when all the sensors are connected.

**Note:** the control unit assigns the Node ID in ascending order of sensor ID (SID).

- Semi-automatic: wizard for connecting the sensors and assign the Node ID one sensor at a time.

#### Procedure

1. Start the application.
2. Click **Configuration** and verify that the number of sensors in the configuration is the same as those installed.

3. Click **Settings > Node ID Assignment**.
4. Proceed according to the type of assignment:

If the assignment is...	Then...
manual	<ol style="list-style-type: none"> <li>1. Click <b>DISCOVER CONNECTED SENSORS</b> to display the connected sensors.</li> <li>2. To assign a Node ID, click <b>Assign</b> for the unassigned Node ID in the <b>Configured sensors</b> list.</li> <li>3. To change a Node ID, click <b>Change</b> for the already assigned Node ID in the <b>Configured sensors</b> list.</li> <li>4. Select the SID of the sensor and confirm.</li> </ol>
automatic	<ol style="list-style-type: none"> <li>1. Click <b>DISCOVER CONNECTED SENSORS</b> to display the connected sensors.</li> <li>2. Click <b>ASSIGN NODE IDS &gt; Automatic</b>: the control unit assigns the Node ID in ascending order of sensor ID (SID).</li> </ol>
semi-automatic	Click <b>ASSIGN NODE IDS &gt; Semi-automatic</b> and follow the instructions displayed.

### 3.2.2.6 Synchronize the control units

If there is more than one control unit in the area, perform the following steps:

1. In the Inxpect Safety application, click **Settings > Advanced**.
2. In **Multi-control unit synchronization**, assign a different **Control unit channel** to each control unit.

**Note:** if there are more than four control units, the control units with the same channel must have their monitored areas as far from each other as possible.

## 3.2.3 Validate the safety functions

### 3.2.3.1 Procedure

 **WARNING!** When the validation function is active, the system response time is not guaranteed.

The Inxpect Safety application is helpful during the safety functions validation phase and allows the actual field of view of the sensors to be checked based on their installation position.

1. Click **Validation**: the validation starts automatically.
2. Move in the monitored area as indicated in "Validation test" on page 69 and "Validation procedure for the restart prevention function" on page 69.
3. Check that the sensor behaves as expected.  
*Note:* if the static object detection option is enabled, the empty dot represents a moving target, and the full dot represents a static target.
4. Check that the distance and the angle\* where the motion is detected are the expected values.  
*Note\*:* see "Target position angle conventions" on page 122.

## 3.2.4 Manage the configuration

### 3.2.4.1 Configuration checksums

In the Inxpect Safety application in **Settings > Configuration checksums**, it is possible to consult:

- the configuration report hash, a unique alphanumeric code associated with a report. It is computed considering the entire configuration, plus the time of the configuration saving and uploading, and the name of the computer which did it
- dynamic configuration checksum, associated with a specific dynamic configuration. It considers both common and dynamic parameters

### 3.2.4.2 Configuration reports

After changing the configuration, the system generates a configuration report with the following information:

- configuration data
- unique hash
- date and time of configuration change
- name of the computer used for the configuration

The reports are documents that cannot be changed and can only be printed and signed by the machinery safety manager.

**Note:** to save the PDF, a printer must be installed on the computer.

### 3.2.4.3 Change the configuration

 **WARNING! The system is disabled during configuration. Prepare opportune safety measures in the dangerous area protected by the system before configuring the system.**

1. Start the Inxpect Safety application.
2. Click **User** and enter the admin password.

**Note:** after five wrong password entries, application authentication is blocked for one minute.

3. Depending on what you want to change, follow the instructions below:

To change...	Then...
Monitored area and sensors configuration	Click <b>Configuration</b>
Node ID	Click <b>Settings &gt; Node ID Assignment</b>
Function of inputs and outputs	Click <b>Settings &gt; Digital Input-Output</b>
Detection field groups configuration	Click <b>Settings &gt; Detection field groups</b> and select the group for each detection field of each connected sensor. Then click <b>Settings &gt; Digital Input-Output</b> and set a digital output as <b>Detection signal group 1</b> or <b>Detection signal group 2</b> function
Muting	Click <b>Settings &gt; Muting</b>
Sensor number and positioning	Click <b>Configuration</b>

4. Click **APPLY CHANGES**.
5. Upon conclusion of transfer of the configuration to the control unit, click  to print the report.

**Note:** to save the PDF, a printer must be installed on the computer.

### 3.2.4.4 Display the configuration archive

In **Settings**, click **Activity History** and then click **Configuration reports page**: the reports archive opens.

## 3.3 Use Inxpect Safety Studio application

### Contents

This section includes the following topics:

<b>3.3.1 Get to know Inxpect Safety Studio</b> .....	<b>78</b>
<b>3.3.2 Configure the system</b> .....	<b>78</b>
<b>3.3.3 Manage the configuration</b> .....	<b>78</b>

## 3.3.1 Get to know Inxpect Safety Studio

### 3.3.1.1 Compatibility

Inxpect Safety Studio application can manage the following components:

- control units: only eXtended Line
- sensors: all, except for S201A

## 3.3.2 Configure the system

### 3.3.2.1 Create and configure the system project

Refer to Inxpect Safety Studio user manual.

### 3.3.2.2 Pair the sensors

This procedure is only possible if the control unit is connected to the computer.

1. In DESIGN (in the control unit card) click **...** > **Sensors pairing**: the application scans all sensors connected to the control unit. When the scan is completed, a matrix is displayed with the connected and the configured sensors.
2. To pair the configured sensor to the corresponding connected sensor, select the relevant check box.
3. To physically recognize a connected sensor, click **Blink sensor LED** to make the sensor LED blink.
4. Click **CONFIRM**: each sensor is assigned a node ID.

### 3.3.2.3 Send and print the configuration

This procedure is only possible if the control unit is connected to the computer.

1. Pair the project sensors with the corresponding sensors physically connected to the control unit. See "Pair the sensors" above.
2. Upload the configuration as follows:

To send the configuration to...	Then...
a single control unit	in the control unit card, click <b>...</b> > <b>Upload configuration</b> or click  .
all control units added to the project	in the <b>DESIGN</b> section, click <b>UPLOAD</b> .

The sensors paired with the control unit will save the surrounding environment as reference for anti-tampering functions.

3. Save the report generated at the end of the uploading process.
4. Ask the authorized person for a signature.

### 3.3.2.4 Synchronize the control units

If there is more than one control unit in the area, perform the following steps:

In DESIGN > control unit card > OTHER OPTIONS, in MULTI-CONTROL UNIT SYNCHRONIZATION, assign a different **Control unit channel** to each control unit.

**Note:** if there are more than four control units, the control units with the same channel must have their monitored areas as far from each other as possible.

## 3.3.3 Manage the configuration

### 3.3.3.1 Configuration checksums

In DESIGN > control unit card > **Device info**, it is possible to consult:

- the configuration report hash, a unique alphanumeric code associated with a report. It is computed considering the entire configuration, plus the time of the configuration saving and uploading, and the name of the computer which did it
- dynamic configuration checksum, associated with a specific dynamic configuration. It considers both common and dynamic parameters

### 3.3.3.2 Configuration reports

After changing the configuration, the system generates a configuration report with the following information:

- configuration data
- unique hash
- date and time of configuration change
- name of the computer used for the configuration

The reports are documents that cannot be changed and can only be printed and signed by the machinery safety manager.

**Note:** to save the PDF, a printer must be installed on the computer.

### 3.3.3.3 Change the configuration

 **WARNING! The system is disabled during configuration. Prepare opportune safety measures in the dangerous area protected by the system before configuring the system.**

To change the configuration with Inxpect Safety Studio, refer to Inxpect Safety Studio user manual.

### 3.3.3.4 Display the configuration archive

Click **REPORT**: the reports archive opens.

# 4. Maintenance and troubleshooting

## 4.1 LEDs


### Contents

This section includes the following topics:

4.1.1 Control unit status LEDs .....	80
4.1.2 Control unit Fieldbus LEDs .....	81
4.1.3 Sensor status LEDs .....	84

### 4.1.1 Control unit status LEDs

#### 4.1.1.1 System status LEDs



#### 4.1.1.2 Meaning in normal and safe state (detection state)

The LEDs are each dedicated to a sensor, and can display the following statuses:

Status	Meaning
Steady green	Normal sensor function and no motion detected
Orange	Normal sensor function and some motion detected
Flashing red	Sensor in error (see "Sensor LED" on page 87)
Steady red	System error (see "Control unit LED" on page 85)
Flashing green	Sensor in boot status (see "Control unit LED" on page 85)

### 4.1.1.3 Meaning in safe state (fault, stop signal and configuration states)


See "Control unit LED" on page 85.

## 4.1.2 Control unit Fieldbus LEDs

### 4.1.2.1 PROFI safe Fieldbus status LEDs

The LEDs reflect the status of the PROFI safe Fieldbus, and their meanings are reported below.

#### LEDs



LEDs	Type	Description
F1	SYS	System status
F2		
F3	BF	Bus failure
F4		
F5	SF	System failure
F6		

#### Meaning of SYS LEDs

F1 status	F2 status	Meaning
Steady green	Off	Normal behavior
Flashing green	Off	Contact technical support
Off	Flashing yellow	Contact technical support
Off	Steady yellow	Contact technical support
Off	Off	Contact technical support

#### Meaning of BF LEDs

F3 status	F4 status	Meaning
Off	Off (not used)	Data exchange is running with the host
Flashing red	Off (not used)	No data exchange
Steady red	Off (not used)	No physical link


#### Meaning of SF LEDs

F5 status	F6 status	Meaning
Off	Off (not used)	Normal behavior
Steady red	Off (not used)	Diagnostic error at the PROFI safe layer (wrong F Dest Address, watchdog timeout, or wrong CRC) or at the PROFINET layer (watchdog timeout, channel, generic or extended diagnosis present, or system error)
Flashing red	Off (not used)	DCP signal service is initiated via the bus

### 4.1.2.2 FSoE Fieldbus status LEDs

The LEDs reflect the status of the FSoE Fieldbus, and their meanings are reported below.

#### LEDs



LEDs	Type	Description
F1	SYS	System status
F2		
F3	ERR	Error code
F4		
F5	RUN	Current state of the State Machinery
F6		

#### Meaning of SYS LEDs

F1 status	F2 status	Meaning
Steady green	Off	Normal behavior
Flashing green	Off	Contact technical support
Off	Flashing yellow	Contact technical support
Off	Steady yellow	Contact technical support
Off	Off	Contact technical support

#### Meaning of ERR LEDs

F3 status	F4 status	Meaning
Off	Off (not used)	Normal behavior
Flashing red	Off (not used)	Invalid configuration: General Configuration Error. Possible reason: State change commanded by master is impossible due to register or object settings
Single flash red	Off (not used)	Local error: Slave device application has changed the EtherCAT state autonomously. Possible reason 1: A host watchdog timeout has occurred. Possible reason 2: Synchronization error, the device enters Safe-Operational state automatically
Double flash red	Off (not used)	Application watchdog timeout. Possible reason: Sync Manager Watchdog timeout

#### Meaning of RUN LEDs


F5 status	F6 status	Meaning
Off (not used)	Off	INIT state
Off (not used)	Steady green	OPERATIONAL state
Off (not used)	Single flash green	SAFE-OPERATIONAL state
Off (not used)	Flashing green	SAFE-OPERATIONAL state

### 4.1.2.3 CIP Safety™ status LEDs

The LEDs reflect the status of the CIP Safety Fieldbus, and their meanings are reported below.

**WARNING!** CIP Safety status LEDs are NOT reliable indicators and cannot be guaranteed to provide accurate information. They should ONLY be used for general diagnostics during commissioning or troubleshooting. Do not attempt to use LEDs as operational indicators.

## LEDs



LEDs	Type	Description
F1	SYS	System status
F2		
F3	NS	Network Status
F4		
F5	MS	Module Status
F6		

### Meaning of SYS LEDs

F1 status	F2 status	Meaning
Steady green	Off	Normal behavior
Flashing green	Off	Contact technical support
Off	Flashing yellow	Contact technical support
Off	Steady yellow	Contact technical support
Off	Off	Contact technical support

### Meaning of NS LEDs

F3 status	F4 status	Meaning
Steady red	Off	Duplicate IP address
Flashing red	Off	Connection timeout: an IP address is configured, and an Exclusive Owner connection for which this device is the target has timed out
Off	Steady green	Connected: an IP address is configured, at least one CIP connection is established, and an Exclusive Owner connection has not timed out
Off	Flashing green	No CIP connections
Flashing red	Flashing green	[Sequence F4-F3-Off] Self-test: the device is performing its power-up testing
Off	Off	Not powered or no IP address

### Meaning of MS LEDs

F5 status	F6 status	Meaning
Steady red	Off	Major unrecoverable fault
Flashing red	Off	Major recoverable fault, e.g., an incorrect or inconsistent configuration
Off	Steady green	The device is operating correctly
Off	Flashing green	Standby: the device has not been configured
Flashing red	Flashing green	[Sequence F6-F5-Off] Self-test: the device is performing its power-up testing. The MS indicator test sequence occurs before the NS indicator test sequence
Off	Off	Not powered

## 4.1.3 Sensor status LEDs

### 4.1.3.1 Meaning in normal and safe state (detection state)

Status	Meaning
Steady blue	Sensor is working. No motion detected.
Flashing blue	Sensor is detecting motion*. Not available if the sensor is in muting. Only for S202A sensors, for restart prevention function, the LED keeps flashing for about 2 seconds after the end of a detection
Purple	Firmware update conditions (see "Sensor LED" on page 87)
Red	Error conditions (see "Sensor LED" on page 87)

**Note\***: the detection signal overrides the masking signal if they are present at the same time. Only for S202A sensors, the masking signal overrides the detection signal.

### 4.1.3.2 Meaning in safe state (fault, stop signal and configuration states)

See "Sensor LED" on page 87.

## 4.2 Troubleshooting

### Machinery maintenance technician

The machinery maintenance technician is a qualified person with the administrator privileges required to modify the configuration of Inxpect SRE 200 Series through the software and perform maintenance and troubleshooting.

### Contents

This section includes the following topics:

4.2.1 Troubleshooting procedures .....	84
4.2.2 Event log management .....	88
4.2.3 INFO events .....	92
4.2.4 ERROR events (control unit) .....	94
4.2.5 ERROR events (sensor) .....	96
4.2.6 ERROR events (CAN bus) .....	98
4.2.7 Auto-resume .....	98

## 4.2.1 Troubleshooting procedures

### 4.2.1.1 Download sensor debug info

If requested by Technical Support, download the sensor debug info files and forward them to Inxpect for debugging (in Inxpect Safety: **Settings > Activity History > Download sensor debug info**).

### 4.2.1.2 Control unit LED

For more details about the LEDs in the control unit, see "Control units" on page 17 and "Control units" on page 17.

LED	Status	Application messages	Problem	Solution
S1*	Steady red	CONTROL UNIT POWER ERROR	At least one voltage value on the control unit is wrong	If at least one digital input is connected, check that the SNS input and the GND input are connected.  Check that the input power supply is the specified type (see "General specifications" on page 103).
S1 + S3	Steady red	BACKUP or RESTORE ERROR	Error during the backup and restore to/from microSD card	Check if the microSD card is inserted.  Check if the configuration file on the microSD card is present and not corrupted.
S2	Steady red	CONTROL UNIT TEMPERATURE ERROR	Control unit temperature value is wrong	Check that the system is operating at the correct operating temperature (see "General specifications" on page 103).
S3	Steady red	OSSD ERROR or INPUT ERROR	At least one input or output is in error	If at least one input is used, check that both the channels are connected and that there is no short-circuit on the outputs.  If the problem persists, please contact Technical Support.
S4	Steady red	PERIPHERAL ERROR	At least one of the control unit peripherals is in error	Check the status of the terminal block and connections.  If the problem persists, please contact Technical Support.
S5	Steady red	CAN ERROR	Communication error with at least one sensor	Check connections of all sensors in the chain starting from the last sensor in error.  Check that all the sensors have an assigned ID (for Inxpect Safety, see "Re-assign the Node IDs" on page 75; for Inxpect Safety Studio, see "Pair the sensors" on page 78).  Check that the firmware of the control unit and sensors are updated to the compatible versions.
S6	Steady red	FEE ERROR, FLASH ERROR or RAM ERROR	Configuration saving error, configuration not performed or memory error	Reconfigure or configure the system (see "Manage the configuration" on page 76).  If the error persists, please contact Technical Support.

## 4.2 Troubleshooting

LED	Status	Application messages	Problem	Solution
All LEDs from S1 to S6 together	Steady red	FIELDBUS ERROR	Communication error on the Fieldbus	At least one input or output is configured as <b>Fieldbus controlled</b> . Check that the cable is correctly connected, communication with the host is correctly established, watchdog timeout is configured correctly, and exchanged data are not maintained passivated.
All LEDs from S1 to S5 together	Steady red	DYNAMIC CONFIGURATION ERROR	Error in the selection of the dynamic configuration: invalid ID	Check the preset configurations within the system application.
All LEDs from S1 to S4 together	Steady red	SENSOR CONFIGURATION ERROR	Error during the configuration of the sensors	Check the sensors connected and try again to perform the configuration of the system via the system application. Check that the firmware of the control unit and sensors are updated to the compatible versions.
At least one LED	Flashing red	See "Sensor LED" on the next page	Sensor corresponding to the flashing LED in error ** (see "Sensor LED" on the next page)	Check the problem through the LED on the sensor.
At least one LED	Flashing green	See "Sensor LED" on the next page	Sensor corresponding to the flashing LED in error ** (see "Sensor LED" on the next page)	If the issue persists longer than one minute, please contact Technical Support.
All LEDs	Steady orange	-	The system is starting up.	Wait for a few seconds.
All LEDs	Flashing green one after the other in sequence	-	The control unit is in boot state.	Open the latest available version of the system application, connect to the device and proceed with the automatic recovery procedure. If the issue persists, please contact Technical Support.
All LEDs	Off	In Inxpect Safety: <b>Dashboard</b> > <b>System status</b>  icons In Inxpect Safety Studio: <b>Validation</b> > control unit status  and message "The project has not been uploaded"	Configuration not yet applied to the control unit.	Configure the system.
All LEDs	Off	Progress icon	Configuration transfer to the control unit in progress.	Wait for the transfer to be completed.

**Note:** fault signal on the control unit (steady LED) takes priority over a faulty sensor signal. For the status of the single sensor, check the sensor LED.

**Note\*:** S1 is the first from the top.

**Note\*\*:** S1 corresponds to the sensor with ID 1, S2 corresponds to the sensor with ID 2 and so on.

### 4.2.1.3 Sensor LED

Status	Application messages	Problem	Solution
Steady purple	-	Sensor in boot state	Contact Technical Support.
Flashing purple *	-	Sensor receiving a firm-ware update	Wait for the update to be completed without disconnecting the sensor.
Flashing red. Two flashes followed by a pause **	CAN ERROR	Sensor without a valid identifier assigned	Assign a Node ID to the sensor (see "Connect the sensors to the control unit" on page 63).
Flashing red. Three flashes followed by a pause **	CAN ERROR	Sensor does not receive valid messages from the control unit	Verify the connection of all the sensors in the chain and check that the number of sensors configured in the system application is equal to the number of the sensors physically connected
Flashing red. Four flashes followed by a pause **	SENSORTEMPERATURE ERROR or SENSORPOWER ERROR	Sensor in temperature error or is receiving an incorrect supply voltage	Check the sensor connection and that the cable length is within the maximum limits. Verify that the temperature of the environment in which the system is operating conforms to the operating temperatures listed in the technical data in this manual.
Flashing red. Five flashes followed by a pause **	MASKING, SIGNAL PATTERN ERROR***	Sensor detected a masking (tampering) or there are radar signal errors	Not available if the sensor is in muting. Check that the sensor is installed correctly and that the area is clear of objects that obstruct the sensor's field of view.
	MASKING REFERENCE MISSING	Sensor is not able to save the monitored area reference for occlusion	Repeat the system configuration making sure no movement is present inside the monitored area
	MSS ERROR/DSS ERROR	Error detected by diagnostics relative to the internal micro-controllers (MSS and DSS), their internal peripherals or memories	If the issue persists, please contact Technical Support.
Flashing red. Six flashes followed by a pause **	TAMPER ERROR	Sensor detected a variation in rotation around the axes (tampering)	Not available if the sensor is in muting. Check if the sensor has been tampered with or if the side or mounting screws have loosened.

**Note \*:** flashes at 100 ms intervals without pause

**Note \*\*:** flashes at 200 ms intervals and then with a 2 s pause.

**Note\*\*\*:** the detection signal overrides the masking signal if they are present at the same time. Only for S202A sensors, the masking signal overrides the detection signal.

#### 4.2.1.4 Other problems

Problem	Cause	Solution
Undesired detections	Transit of people or objects in close proximity to the detection field	Change the configuration (see "Change the configuration" on page 77).
Machinery in safe status without motion in the detection field	No power supply	Check electrical connection. Contact Technical Support if necessary.
	Failure of the control unit or one or more sensors	Check the status of the LEDs on the control unit (see "Control unit LED" on page 85).  In Inxpect Safety: <b>Dashboard</b> > mouse-over  at the control unit or the sensor; in Inxpect Safety Studio: <b>VALIDATION</b> .
The voltage value detected on the SNS input is zero	The chip that detects inputs is faulty	Contact Technical Support.
The system does not function correctly	Control unit error	Check the status of the LEDs on the control unit (see "Control unit LED" on page 85).  In Inxpect Safety: <b>Dashboard</b> > mouse-over  at the control unit or the sensor; in Inxpect Safety Studio: <b>VALIDATION</b> .
	Sensor error	Check the status of the LEDs on the sensor (see "Sensor LED" on the previous page).  In Inxpect Safety: <b>Dashboard</b> > mouse-over  at the control unit or the sensor; in Inxpect Safety Studio: <b>VALIDATION</b> .

## 4.2.2 Event log management

### 4.2.2.1 Introduction

The event log recorded by the system can be downloaded from the system application in a PDF file. The system saves up to 4500 events, divided in two sections. In each section the events are displayed from the most recent to the least recent. Above this limit, the oldest events are overwritten.

### 4.2.2.2 Download the system log

 **WARNING!** The system response time is not guaranteed while downloading the log file.

#### Procedure using Inxpect Safety

1. Start the Inxpect Safety application.
2. Click **Settings** and then **Activity History**.
3. Click **DOWNLOAD LOG**.

**Note:** to save the PDF, a printer must be installed on the computer.

#### Procedure using Inxpect Safety Studio

1. Start the Inxpect Safety Studio application.
2. In **DESIGN** > control unit card, click **ACTIVITY HISTORY**.
3. In **System log**, click **DOWNLOAD**.

**Note:** to save the PDF, a printer must be installed on the computer.

### 4.2.2.3 Log file sections

The first line of the file reports the NID (Network ID) of the device and the date of the download.

The rest of the file log is divided in two sections:

Section	Description	Content	Size	Reset
1	Event log	Information events	3500	At every firmware update or on demand using the system application
		Error events		
2	Diagnostic event log	Error events	1000	Not possible

### 4.2.2.4 Log line structure

Each line in the log file reports the following information, separated by tab character:

- Timestamp (seconds counter from the latest boot)
- Timestamp (absolute/relative value)
- Event type:
  - [ERROR] = diagnostic event
  - [INFO] = information event
- Source
  - CONTROL UNIT = if the event is generated by the control unit
  - SENSOR ID = if the event is generated by a sensor. In this case, the Node ID of the sensor is also provided
- Event description

### 4.2.2.5 Timestamp (seconds counter from the latest boot)

An indication of the instant when the event occurred is provided as relative time from the latest boot, in seconds.

Example: 92

Meaning: the event occurred 92 seconds after the latest boot

### 4.2.2.6 Timestamp (absolute/relative value)

An indication of the instant when the event occurred is provided.

- After a new system configuration, it is provided as absolute time.

Format: YYYY/MM/DD hh:mm:ss

Example: 2024/08/08 23:58:00

- After a reboot of the device, it is provided as relative time from the latest boot.

Format: Rel. x d hh:mm:ss

Example: Rel. 0 d 00:01:32

**Note:** when a new system configuration is performed, even the older timestamps are updated in absolute time format.

**Note:** during system configuration, the control unit is receiving the local time of the machinery where the software is running.

### 4.2.2.7 Event description

A complete description of the event is reported. Whenever possible, depending on the event, additional parameters are reported.

In case of a diagnostic event, an internal error code is also added, useful for the purpose of debug. If the diagnostic event disappears, the label “(Disappearing)” is reported as an additional parameter.

Examples

Detection access (field #3, 1300 mm/40°)

System configuration #15

CAN ERROR (Code: 0x0010) COMMUNICATION LOST

## 4.2 Troubleshooting

CAN ERROR (Disappearing)

### 4.2.2.8 Log file example

Event logs of ISC NID UP304 updated 2024/11/18 16:59:56

[Section 1 - Event logs]

380	2024/11/18 16:53:49	[ERROR]	SENSOR#1	CAN ERROR (Disappearing)	
375	2024/11/18 16:53:44	[ERROR]	SENSOR#1	CAN ERROR (Code: 0x0010)	COMMUNICATION LOST
356	2024/11/18 16:53:25	[INFO]	CONTROL UNIT	System configuration #16	
30	2024/11/18 16:53:52	[ERROR]	SENSOR#1	ACCELEROMETER ERROR (Disappearing)	
27	2024/11/18 16:47:56	[ERROR]	SENSOR#1	ACCELEROMETER ERROR (Code: 0x0010)	TILT ANGLE ERROR
5	2024/11/18 16:47:30	[ERROR]	SENSOR#1	SIGNAL ERROR (Code: 0x0012)	MASKING
0	2024/11/18 16:47:25	[INFO]	CONTROL UNIT	Dynamic configuration #1	
0	2024/11/18 16:47:25	[INFO]	CONTROL UNIT	System Boot #60	
92	Rel. 0 d 00:01:32	[INFO]	CONTROL UNIT	Detection exit (field #2)	
90	Rel. 0 d 00:01:30	[INFO]	CONTROL UNIT	Detection exit (field #1)	
70	Rel. 0 d 00:01:10	[INFO]	SENSOR#1	Detection access (field #2, 3100 mm/20°)	
61	Rel. 0 d 00:01:01	[INFO]	SENSOR#1	Detection access (field #1, 1200 mm/30°)	
0	Rel. 0 d 00:00:00	[INFO]	CONTROL UNIT	Dynamic configuration #1	
0	0 d 00:00:00	[INFO]	CONTROL UNIT	System Boot #61	

[Section 2 - Diagnostic events log]

380	Rel. 0 d 00:06:20	[ERROR]	SENSOR #1	CAN ERROR	(Disappearing)
375	Rel. 0 d 00:06:15	[ERROR]	SENSOR #1	CAN ERROR (Code: 0x0010)	COMMUNICATION LOST
356	Rel. 0 d 00:05:56	[INFO]	CONTROL UNIT	System configuration #16	
30	Rel. 0 d 00:00:30	[ERROR]	SENSOR #1	ACCELEROMETER ERROR	(Disappearing)
27	Rel. 0 d 00:00:27	[ERROR]	SENSOR #1	ACCELEROMETER ERROR (Code: 0x0012)	TILT ANGLE ERROR
5	Rel. 0 d 00:00:05	[ERROR]	SENSOR #1	SIGNAL ERROR (Code: 0x0014)	MASKING

### 4.2.2.9 Event list

The event logs are listed below:

Event	Type
Diagnostic errors	ERROR
System Boot	INFO
System configuration	INFO
Factory reset	INFO
Stop signal	INFO
Restart signal	INFO
Detection access	INFO
Detection exit	INFO
Dynamic configuration in use	INFO
Muting status	INFO

Event	Type
Fieldbus connection	INFO
MODBUS connection	INFO
Session authentication	INFO
Validation	INFO
Log download	INFO

For further information about the events, see "INFO events" on the next page and "ERROR events (control unit)" on page 94.

#### 4.2.2.10 Verbosity level

There are six verbosity levels for the log. The verbosity can be set during the configuration of the system via the system application (in Inxpect Safety: **Settings > Activity History > Log verbosity level**; in Inxpect Safety Studio: **DESIGN > control unit card > ACTIVITY HISTORY**).

Depending on the selected verbosity level, the events are logged in accordance to the following table:

Event	Level 0 (default)	Level 1	Level 2	Level 3	Level 4	Level 5
Diagnostic errors	x	x	x	x	x	x
System Boot	x	x	x	x	x	x
System configuration	x	x	x	x	x	x
Factory reset	x	x	x	x	x	x
Stop signal	x	x	x	x	x	x
Restart signal	x	x	x	x	x	x
Detection access	-	See "Verbosity level for detection access and exit events" below				
Detection exit	-	See "Verbosity level for detection access and exit events" below				
Dynamic configuration in use	-	-	-	-	x	x
Muting status	-	-	-	-	-	x

#### 4.2.2.11 Verbosity level for detection access and exit events

Depending on the selected verbosity level, the detection access and exit events are logged as follows:

- LEVEL 0: no detection info is logged
- LEVEL 1: the events are logged at the control unit level, and the additional information is the detection distance (in mm) and the detection angle (in °)\*at detection access

Format:

*CONTROL UNIT Detection access (distance mm/azimuth°)*

*CONTROL UNIT Detection exit*

- LEVEL 2: the events are logged in a single field at the control unit level, and the additional information is: detection field, detection distance (in mm) and detection angle (in °)\*at access, and detection field at exit

Format:

*CONTROL UNIT Detection access (field #n, distance mm/azimuth°)*

*CONTROL UNIT Detection exit (field #n)*

- LEVEL 3 / LEVEL 4 / LEVEL 5 The events are logged:

- in a single field at the control unit level, and the additional information is: detection field, detection distance (in mm) and detection angle (in °)\* at access, and detection field at exit
- at the sensor level and the additional information read by the sensor is: detection distance (in mm) and detection angle (in °)\* at access, and detection field at exit

Format:

*CONTROL UNIT #k Detection access (field #n, distance mm/azimuth°)*

## 4.2 Troubleshooting

*SENSOR #k Detection access (distance mm/azimuth°)*

*CONTROL UNIT Detection exit (field #n)*

*SENSOR #k Detection exit*

**Note\***: see "Target position angle conventions" on page 122.

## 4.2.3 INFO events

### 4.2.3.1 System Boot

Every time the system is powered up, the event is logged reporting the incremental count of the boot from the beginning of the life of the device.

Format: *System Boot #n*

Example:

```
0 2024/11/18 16:47:25 [INFO] CONTROL UNIT SYSTEM BOOT #60
```

### 4.2.3.2 System configuration

Every time the system is configured, the event is logged reporting the incremental count of the configuration from the beginning of the life of the device.

Format: *System configuration #3*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT System configuration #3
```

### 4.2.3.3 Factory reset

Every time a factory reset is required, the event is logged.

Format: *Factory reset*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Factory reset
```

### 4.2.3.4 Stop signal

If configured, every change of the Stop Signal is logged as ACTIVATION or DEACTIVATION.

Format: *Stop signal ACTIVATION/DEACTIVATION*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Stop signal ACTIVATION
```

### 4.2.3.5 Restart signal

If configured, every time the system is waiting for the restart signal or the restart signal is received, the event is logged as WAITING or RECEIVED.

Format: *Restart signal WAITING/RECEIVED*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Restart signal RECEIVED
```

#### 4.2.3.6 Detection access

Every time motion is detected, a detection access is logged with additional parameters depending on the selected verbosity level: the detection field number, the sensor which detected the motion, the detection distance (in mm), and the detection angle (°)\* (see "Verbosity level for detection access and exit events" on page 91).

Format: *Detection access (field #n, distance mm/azimuth°)*

**Note\***: see "Target position angle conventions" on page 122.

Example:

```
20 2024/11/18 16:47:25 [INFO] SENSOR #1 Detection access (field #1, 1200 mm/30°)
```

#### 4.2.3.7 Detection exit

After at least one detection access event, a detection exit event related to the same field is logged when the detection signal returns to its default no-motion status.

Depending on the selected verbosity level additional parameters are logged: the detection field number, the sensor which detected the motion.

Format: *Detection exit (field #n)*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Detection exit (field #1)
```

#### 4.2.3.8 Dynamic configuration in use

At every change of the dynamic configuration, the new ID of the dynamic configuration selected is logged.

Format: *Dynamic configuration #1*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Dynamic configuration #1
```

#### 4.2.3.9 Muting status

Every change of the muting status of each sensor is logged as disabled or enabled.

**Note**: the event indicates a change of the muting status of the system. It does not correspond to the muting request.

Format: *Mutingdisabled/enabled*

Example:

```
20 2024/11/18 16:47:25 [INFO] SENSOR#1 Mutingenabled
```

#### 4.2.3.10 Fieldbus connection

The Fieldbus communication status is logged as CONNECTED, DISCONNECTED or FAULT.

Format: *Fieldbus connection CONNECTED/DISCONNECTED/FAULT*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Fieldbus connection CONNECTED
```

#### 4.2.3.11 MODBUS connection

The MODBUS communication status is logged as CONNECTED or DISCONNECTED.

Format: *MODBUS connection CONNECTED/DISCONNECTED*

Example:

```
20 2024/11/18 16:47:25 [INFO] CONTROL UNIT MODBUS connection CONNECTED
```

### 4.2.3.12 Session authentication

The status of the session authentication and the interface used (USB/ETH) are logged.

Format: *SessionOPEN/CLOSE/WRONGB PASSWORD/UNSET PASSWORD/TIMEOUT/CHANGE PASSWORD* via *USB/ETH*

Example:

20 2024/11/18 16:47:25 [INFO] CONTROL UNIT SessionOPENviaUSB

### 4.2.3.13 Validation

Every time a validation activity starts or ends on the device, it is logged. The interface used (USB/ETH) is logged as well.

Format: *ValidationSTARTED/ENDED* via *USB/ETH*

Example:

20 2024/11/18 16:47:25 [INFO] CONTROL UNIT ValidationSTARTEDviaUSB

### 4.2.3.14 Log download

Every time a log download is performed on the device, it is logged. The interface used (USB/ETH) is logged as well.

Format: *Log download* via *USB/ETH*

Example:

20 2024/11/18 16:47:25 [INFO] CONTROL UNIT Log download viaUSB

## 4.2.4 ERROR events (control unit)

### 4.2.4.1 Introduction

A diagnostic error is logged every time the periodic diagnostic functions detect a coming or going fault on the control unit.

### 4.2.4.2 Temperature errors (TEMPERATURE ERROR)

Error	Meaning
<b>BOARD TEMPERATURE TOO LOW</b>	Board temperature below minimum
<b>BOARD TEMPERATURE TOO HIGH</b>	Board temperature above maximum

### 4.2.4.3 Control unit voltage errors (POWER ERROR)

Error	Meaning
<b>Control unit voltage UNDERVOLTAGE</b>	Undervoltage error for the indicated voltage
<b>Control unit voltage OVERVOLTAGE</b>	Ovvoltage error for the indicated voltage
<b>ADC CONVERSION ERROR</b>	ADC conversion error in the micro-controller

The following table describes the control unit voltage:

Screen printing	Description
<b>VIN</b>	Power supply voltage (+24 V DC)
<b>V12</b>	Internal supply voltage
<b>V12 sensors</b>	Sensors power supply voltage
<b>VUSB</b>	USB port voltage
<b>VREF</b>	Inputs reference voltage ( <b>VSNS Error</b> )
<b>ADC</b>	Analog-digital converter

#### 4.2.4.4 Peripheral error (PERIPHERAL ERROR)

Error detected by diagnostics relative to the micro-controller, its internal peripherals or memories.

#### 4.2.4.5 Configuration errors (FEE ERROR)

Indicates that the system must still be configured. This message can appear when the system is first turned on or after reset to default values. It can also represent another error on the FEE (internal memory).

#### 4.2.4.6 Output errors (OSSD ERROR)

Error	Meaning
<b>OSSD 1 SHORT-CIRCUIT</b>	Short-circuit error on MOS output 1
<b>OSSD 2 SHORT-CIRCUIT</b>	Short-circuit error on MOS output 2
<b>OSSD 3 SHORT-CIRCUIT</b>	Short-circuit error on MOS output 3
<b>OSSD 4 SHORT-CIRCUIT</b>	Short-circuit error on MOS output 4
<b>OSSD 1 NO LOAD</b>	No load on OSSD 1
<b>OSSD 2 NO LOAD</b>	No load on OSSD 2
<b>OSSD 3 NO LOAD</b>	No load on OSSD 3
<b>OSSD 4 NO LOAD</b>	No load on OSSD 4

#### 4.2.4.7 Flash errors (FLASH ERROR)

A flash error represents an error on the external flash.

#### 4.2.4.8 Dynamic configuration error (DYNAMIC CONFIGURATION ERROR)

A dynamic configuration error indicates an invalid dynamic configuration ID.

#### 4.2.4.9 Internal communication error (INTERNAL COMMUNICATION ERROR)

Indicates that there is an internal communication error.

#### 4.2.4.10 Input error (INPUT ERROR)

Error	Meaning
<b>INPUT 1 REDUNDANCY</b>	Error in the redundancy on Input 1
<b>INPUT 2 REDUNDANCY</b>	Error in the redundancy on Input 2
<b>ENCODING</b>	Invalid encoding when the encoded channel option is enabled
<b>PLAUSIBILITY</b>	0->1->0 transition not compliant with input functionality specification

#### 4.2.4.11 Fieldbus error (FIELDBUS ERROR)

At least one of the inputs and outputs has been configured as **Fieldbus controlled**, but the Fieldbus communication is not established or not valid.

Error	Meaning
<b>NOT VALID COMMUNICATION</b>	Error on the Fieldbus

#### 4.2.4.12 RAM error (RAM ERROR)

Error	Meaning
<b>INTEGRITY ERROR</b>	Wrong integrity check on the RAM

#### 4.2.4.13 SD Backup or restore error (SD BACKUP OR RESTORE ERROR)

Error	Meaning
<b>GENERIC FAIL</b>	Unknown fault
<b>TIMEOUT</b>	Writing and reading internal operation timeout
<b>NO_SD</b>	microSD not present

Error	Meaning
<b>WRITE OPERATION FAILED</b>	Writing error on the microSD card
<b>CHECK OPERATION FAILED</b>	File corrupted or no file during restore from microSD card

#### 4.2.4.14 Sensor configuration errors (SENSOR CONFIGURATION ERROR)

Error occurred on the sensors during the configuration process or at the system power up. At least one of the connected sensors did not get the correct configuration.

As details, the list of sensors not configured is reported.

### 4.2.5 ERROR events (sensor)

#### 4.2.5.1 Introduction

A diagnostic error is logged every time the periodic diagnostic functions detect a coming or going fault on the sensor.

 **WARNING! No sensor errors are available if the sensor is in muting.**

If requested by Technical Support, download the sensor debug info files and forward them to Inxpect for debugging (in Inxpect Safety: **Settings > Activity History > Download sensor debug info**).

#### 4.2.5.2 Sensor configuration error (SENSOR CONFIGURATION ERROR)

Error occurred on the sensors during the configuration process or at the system power up. At least one of the connected sensors is not correctly configured.

The list of sensor configuration errors is the following:

Error	Meaning
<b>UNKNOWN MODEL-TYPE</b>	Unknown model-type
<b>WRONG MODEL-TYPE</b>	Model-type different from the one set during system configuration
<b>RADIO BANDWIDTH n.a.</b>	Selected radio bandwidth not supported
<b>STATIC OBJECT DETECTION n.a.</b>	Static object detection not supported
<b>CUSTOM TARGET DETECTION n.a.</b>	Custom target detection not supported
<b>ADVANCED FOV n.a.</b>	Advanced field of view not supported
<b>ANTI-MASKING REF</b>	Error occurred during the anti-masking reference grabbing
<b>ANTI-ROTATION REF</b>	Error occurred during the anti-rotation around axes reference grabbing
<b>TIMEOUT</b>	Timeout error occurred during the system recondition
<b>ASSIGN NODE ID ERROR</b>	Error occurred during the Node ID setting of the system recondition
<b>SEQUENCE, STREAM SEQUENCE, STREAM END, STREAM CRC</b>	Sequence error occurred during the sensor configuration
<b>MISSING SENSORS</b>	Too many sensors are missing during the system recondition

#### 4.2.5.3 Misconfiguration error (MISCONFIGURATION ERROR)

The misconfiguration error occurs when the sensor does not have a valid configuration or it has received an invalid configuration from the control unit.

#### 4.2.5.4 Status error and fault (STATUS ERROR/FAULT ERROR)

The status error occurs when the sensor is in an internal invalid status or it has reached an internal fault condition.

#### 4.2.5.5 Protocol error (PROTOCOL ERROR)

The protocol error occurs when the sensor receives commands with an unknown format.

#### 4.2.5.6 Sensor voltage errors (POWER ERROR)

Error	Meaning
<b>Sensor voltage UNDERVOLTAGE</b>	Undervoltage error for the indicated voltage
<b>Sensor voltage OVERVOLTAGE</b>	Ovvoltge error for the indicated voltage

The following table describes the sensor voltage:

Screen printing	Description
<b>VIN</b>	Power supply voltage (+12 V DC)
<b>V3.3</b>	Internal chip power supply voltage
<b>V1.2</b>	Micro-controller power supply voltage
<b>V1.8</b>	Internal chip power supply voltage (1.8 V)
<b>V1</b>	Internal chip power supply voltage (1 V)

#### 4.2.5.7 Anti-tampering sensor (TAMPER ERROR)

Error	Meaning
<b>TILT ANGLE ERROR</b>	Sensor rotation around the y-axis
<b>ROLL ANGLE ERROR</b>	Sensor rotation around the x-axis
<b>PAN ANGLE ERROR</b>	Sensor rotation around the z-axis

*Note: the information of the angle (in degrees) is reported.*

#### 4.2.5.8 Signal error (SIGNAL ERROR)

The signal error occurs when the sensor detected an error in the RF signals part, in particular:

Error	Meaning
<b>MASKING</b>	The sensor is obstructed
<b>MASKING REFERENCE MISSING</b>	During the configuration process, it was not possible to get the masking reference
<b>SIGNAL PATTERN ERROR</b>	Radar internal fault or unexpected signal pattern

#### 4.2.5.9 Temperature errors (TEMPERATURE ERROR)

Error	Meaning
<b>BOARD TEMPERATURE TOO LOW</b>	Board temperature below minimum
<b>BOARD TEMPERATURE TOO HIGH</b>	Board temperature above maximum
<b>CHIP TEMPERATURE TOO LOW</b>	Internal chip below minimum
<b>CHIP TEMPERATURE TOO HIGH</b>	Internal chip above maximum
<b>IMU TEMPERATURE TOO LOW</b>	IMU below minimum
<b>IMU TEMPERATURE TOO HIGH</b>	IMU above maximum

#### 4.2.5.10 MSS error and DSS error (MSS ERROR/DSS ERROR)

Error detected by diagnostics relative to the internal micro-controllers (MSS and DSS), their internal peripherals or memories

### 4.2.6 ERROR events (CAN bus)

#### 4.2.6.1 Introduction

A diagnostic error is logged every time the periodic diagnostic functions detect a coming or going fault on the CAN bus communication.

Depending on the communication bus side, the logged source can be the control unit or a single sensor.

#### 4.2.6.2 CAN errors (CAN ERROR)

Error	Meaning
<b>TIMEOUT</b>	Timeout on message to sensor/control unit
<b>CROSS CHECK</b>	Two redundant messages do not coincide
<b>SEQUENCE NUMBER</b>	Message with sequence number different from the expected number
<b>CRC CHECK</b>	Packet control code does not match
<b>COMMUNICATION LOST</b>	Impossible to communicate with the sensor
<b>PROTOCOL ERROR</b>	Control unit and sensors have different and incompatible firmware versions
<b>POLLING TIMEOUT</b>	Timeout on data polling

**NOTICE:** A shielded cable between the control unit and the first sensor, and between the sensors is strongly recommended. Nevertheless, route the CAN cables separately from high-potential power lines or through an exclusive conduit.

### 4.2.7 Auto-resume

#### 4.2.7.1 Availability

The auto-resume function is available for Pro line, Omni line and Plug&Safe sensors.

#### 4.2.7.2 Introduction

Some transient faults cause a permanent lock-out condition that prevents normal operation from being restored.

While the safe state is maintained, this behavior represents a limitation, especially for remote systems that are not easily accessible.

The Auto-resume function tries to restore the normal functioning of the sensor for five consecutive attempts: if the fault condition persists, the block condition is preserved. Otherwise, the normal functioning condition is automatically restored.

#### 4.2.7.3 Function limitations

The following faults are not subjected to auto-resume:

- POWER ERROR
- SIGNAL ERROR
- TAMPER ERROR
- TEMPERATURE ERROR

The function is not performed when the sensor is muted.

# 4.3 Maintenance

## Contents

This section includes the following topics:

4.3.1 Planned maintenance .....	99
4.3.2 Extraordinary maintenance .....	99

## 4.3.1 Planned maintenance

### Generic maintenance technician

The generic maintenance technician is a person qualified only to perform basic maintenance without the administrator privileges required to modify the configuration of Inxpect SRE 200 Series through the application.

#### 4.3.1.1 Cleaning

Keep the sensor clean and free of any work residues and conductive material to prevent masking and/or poor system operation.

#### 4.3.1.2 Spare parts

See 200S Inxpect Spare Parts document on the <https://tools.inxpect.com> website.

## 4.3.2 Extraordinary maintenance

### 4.3.2.1 Machinery maintenance technician

The machinery maintenance technician is a qualified person with the administrator privileges required to modify the configuration of Inxpect SRE 200 Series through the system application and perform maintenance and troubleshooting.

### 4.3.2.2 Control unit firmware update

**NOTICE:** control unit firmware update can be performed only to firmware version of the same production line.

#### Procedure using Inxpect Safety

1. Download the latest Inxpect Safety application version from the <https://tools.inxpect.com> website and install it on your computer.
2. In **Settings > General**, check if a new update is available.
3. Update without disconnecting from or turning off the device.

#### Procedure using Inxpect Safety Studio

1. Download the latest Inxpect Safety Studio application version from the <https://tools.inxpect.com> website and install it on your computer.
2. In **DESIGN > control unit card > Device info**, check if a new update is available.
3. Update without disconnecting from or turning off the device.

### 4.3.2.3 Replace a sensor: System recondition function

The system recondition function is useful for replacing an existing sensor without changing current settings.

 **WARNING! If the system recondition function has been configured through the safety Fieldbus and the digital inputs, the function can be used from both.**

**Note:** keep the scene static while running the system recondition function so that the anti-tampering functions can save their references.

**Note:** while running the system recondition function, the system goes to the safe state, deactivating the OSSDs, until the process is completed.

1. Configure the digital inputs or Fieldbus to perform the system recondition function.
2. Connect a sensor without Node ID in the same position of the CAN bus line as the replaced sensor.  
**Note:** *only one sensor at a time must be connected to complete the procedure correctly.*
3. Activate the function (via digital inputs or Fieldbus) and wait for the operation to be performed. See "Control unit LED" on page 85 to know which is the system status.

The following actions are performed:

- The first available Node ID is assigned to the new sensor.
- The previous configuration of the system is sent to the control unit and the surrounding environment is saved as reference for the anti-tampering functions. The operation is saved in the event log as a standard **System configuration** event.
- The event is logged in the reports archive with the following strings in the **User, PC** column:
  - "sys-recondition-i" when the function is performed via digital input
  - "sys-recondition-f" when Fieldbus is used

For more details, see "Digital input signals" on page 108.

#### 4.3.2.4 Back up the configuration to a PC

The current configuration can be backed up, including the input/output settings. The configuration is saved in a .cfg file, which can be used to restore the configuration or to facilitate configuration of several Inxpect SRE 200 Series.

##### Procedure using Inxpect Safety

1. In **Settings > General**, click **BACKUP**.
2. Select the file destination and save.

**Note:** *user login credentials are not saved using this backup mode.*

##### Procedure using Inxpect Safety Studio

1. In **Settings > General**, click **BACKUP**.
2. Select the file destination and save.

**Note:** *user login credentials are not saved using this backup mode.*

#### 4.3.2.5 Back up the configuration to a microSD card

If the control unit is provided with a microSD slot, a backup file of the system settings, and (optionally) the login credentials of all the users, can be stored on the microSD card. The SD Backup function can be enabled/disabled through the system application, as well as the backup of the login credentials of all the users. By default, both options are disabled.

##### Procedure using Inxpect Safety

1. To enable the SD Backup function, in **Admin > SD Card** select **Automatic backup creation**.
2. To enable the saving of all users' login credentials, select **Users data included**.
3. To perform the backup, insert a microSD card into the control unit memory card slot.  
**Note:** *the microSD card is not supplied with the control unit. For details about the microSD card specifications, see "microSD card specifications" on the next page*
4. In the Inxpect Safety application, click **APPLY CHANGES**: the backup is automatically performed.

**Note:** *the settings of the **Automatic backup creation** options are not saved during the microSD backup.*

##### Procedure using Inxpect Safety Studio

1. To enable the SD Backup function, in **DESIGN > control unit card > OTHER OPTIONS > SD Card**, select **Automatic backup creation**.
2. To enable the saving of all users' login credentials, select **Users data included**.
3. To perform the backup, insert a microSD card into the control unit memory card slot.  
**Note:** *the microSD card is not supplied with the control unit. For details about the microSD card specifications, see "microSD card specifications" on the next page*
4. In the Inxpect Safety Studio application, click **UPLOAD**: the backup is automatically performed, included the surrounding environment saving.

**Note:** *the settings of the **Automatic backup creation** options are not saved during the microSD backup.*

#### 4.3.2.6 Load a configuration from a PC

##### Procedure using Inxpect Safety

1. In **Settings > General**, click **RESTORE**.
2. Select the previously saved .cfg file (see "Back up the configuration to a PC" on the previous page) and open it.

**Note:** a re-imported configuration requires new downloading onto the control unit and approval according to the safety plan.

##### Procedure using Inxpect Safety Studio

1. In **Settings > General**, click **RESTORE**.
2. Select the previously saved .cfg file (see "Back up the configuration to a PC" on the previous page) and open it.

**Note:** a re-imported configuration requires new downloading onto the control unit and approval according to the safety plan.

#### 4.3.2.7 Load a configuration from a microSD card

If the control unit is provided with a microSD slot, the administrator can restore both the system settings and (if any) the login credentials of all the users. This requires a valid backup file saved on a microSD. The SD Restore function can be enabled/disabled through the system application. By default the option is enabled.

**Note:** this SD Restore function also includes a System recondition operation, see "Replace a sensor: System recondition function" on page 99.

1. To perform the restore, insert the microSD card with the saved configuration into the memory card slot of the new control unit.  
**Note:** the microSD card is not supplied with the control unit. For details about the microSD card specifications, see "microSD card specifications" below
2. Press the SD Restore button on the control unit for at least 5 seconds: the system status LEDs turn off, and when the reset is performed, the LEDs return to the previous state.

**Note:** to disable the SD Restore function, in Inxpect Safety: **Admin > SD Card** deselect **Enable restore by button**; in Inxpect Safety Studio: **DESIGN > control unit card > OTHER OPTIONS > SD Card**.

The following actions are performed:

- The system configuration is sent to the control unit and the surrounding environment is saved as reference for the anti-tampering functions.
- The event is logged in the reports archive with the string **Restore-via-sdcard**.

#### 4.3.2.8 microSD card specifications

Type	microSD
File system	FAT32
Recommended capacity	32 GB or less

# 5. Technical references

## 5.1 Data and parameters

---

### Contents

This section includes the following topics:

<b>5.1.1 Technical data</b> .....	<b>103</b>
<b>5.1.2 Digital input signals</b> .....	<b>108</b>
<b>5.1.3 Control units layout</b> .....	<b>118</b>
<b>5.1.4 Control unit parameters</b> .....	<b>121</b>
<b>5.1.5 Target position angle conventions</b> .....	<b>122</b>
<b>5.1.6 Separation distance calculation</b> .....	<b>123</b>

## 5.1.1 Technical data

### 5.1.1.1 General specifications

<b>Detection method</b>	Inxpect motion detection algorithm based on FMCW radar
<b>Frequency</b>	Working band: <ul style="list-style-type: none"><li>• for S201A model: 60.6-62.8 GHz</li><li>• for S202A model: 60.7-62.9 GHz</li><li>• for S203A model: 61.2-63.4 GHz</li></ul> Maximum radiated power: see National configuration addendum Modulation: FMCW
<b>Detection interval</b>	From 0 to 5 m (from 0 to 16.4 ft)
<b>Detectable target RCS (Human detection)</b>	0.17 m <sup>2</sup>
<b>Field of view</b>	Horizontal angular coverage: <ul style="list-style-type: none"><li>• S201A and S203A models: programmable from 10° to 100°</li><li>• S202A model: programmable from 20° to 100°</li></ul> Vertical angular coverage: <ul style="list-style-type: none"><li>• S201A model: 20°</li><li>• S202A model: programmable from 30° to 90°</li><li>• S203A model: 12°</li></ul> S202A-MV sensor: The sensor provides a reduced set of parameters and two different exclusive SPE functions (see "Configuration parameters" on page 177 and "Configuration parameters" on page 177)
<b>Decision probability</b>	> 1-(2.5E-07)
<b>CRT (Certified Restart Timeout)</b>	4 s
<b>Guaranteed response time</b>	Access detection: < 100 ms * Restart prevention: 4000 ms
	 <b>WARNING!</b> During the real-time validation and the download of the log file, the response time is not guaranteed.
<b>Total consumption</b>	Max. 26.5 W (control unit and sensors)
<b>Electrical protections</b>	Polarity inversion Overcurrent through resettable integrated fuse (max. 5 s @ 8 A)
<b>Overvoltage category</b>	II
<b>Altitude</b>	Max. 1500 m ASL
<b>Air humidity</b>	Max. 95%
<b>Noise emission</b>	Negligible**

**Note\*:** the value depends on the Electromagnetic robustness level set through the system application, see "Electromagnetic robustness" on page 42.

**Note\*\*:** the A-weighted emission sound pressure level does not exceed 70 dB(A).

### 5.1.1.2 Safety parameters

<b>SIL (Safety Integrity Level)</b>	2
<b>HFT</b>	0
<b>SC*</b>	2
<b>TYPE</b>	B
<b>PL (Performance Level)</b>	d
<b>ESPE Type (EN 61496-1)</b>	3
<b>Category (EN ISO 13849)</b>	3 equivalent
<b>Class (IEC TS 62998-1)</b>	D
<b>Communication protocol (sensors-control unit)</b>	CAN complies with standard EN 50325-5
<b>Mission time</b>	20 years
<b>MTTF<sub>D</sub></b>	42 years
<b>PFH<sub>D</sub></b>	With Fieldbus communication: <ul style="list-style-type: none"><li>• Access detection: 1.40E-08 [1/h]</li><li>• Restart prevention: 1.40E-08 [1/h]</li><li>• Muting: 6.37E-09 [1/h]</li><li>• Stop signal: 6.45E-09 [1/h]</li><li>• Restart signal: 6.45E-09 [1/h]</li><li>• Dynamic Configuration Switch: 6.37E-09 [1/h]</li><li>• Fieldbus controlled: 6.45E-09 [1/h]</li></ul> Without Fieldbus communication: <ul style="list-style-type: none"><li>• Access detection: 1.30E-08 [1/h]</li><li>• Restart prevention: 1.30E-08 [1/h]</li><li>• Muting: 5.37E-09 [1/h]</li><li>• Stop signal: 5.45E-09 [1/h]</li><li>• Restart signal: 5.45E-09 [1/h]</li><li>• Dynamic Configuration Switch: 5.37E-09 [1/h]</li><li>• Fieldbus controlled: 5.45E-09 [1/h]</li></ul>
<b>SFF</b>	≥ 99.89%
<b>DCavg</b>	≥ 99.46%
<b>MRT**</b>	< 10 min
<b>Safe state when a fault occurs</b>	At least one channel for each safety output is in OFF-state. Stop message sent on Fieldbus (if available) or communication interrupted

**Note\*:** the systematic capability is guaranteed only if the user uses the product according to the instructions of this manual and uses the product in the appropriate environment.

**Note\*\*:** the MRT considered is the Technical Mean Repair Time, i.e., it takes in consideration availability of skilled personnel, adequate tools and spare parts. Considering the type of device, the MRT corresponds to the time necessary for the device replacement.

### 5.1.1.3 Ethernet connection (if available)

<b>Default IP address</b>	192.168.0.20
<b>Default TCP port</b>	80 (range 1-65534)
<b>Default netmask</b>	255.255.255.0
<b>Default gateway</b>	192.168.0.1


### 5.1.1.4 Control unit features

<b>Outputs</b>	Configurable as follows: <ul style="list-style-type: none"> <li>• 4 Output Signal Switching Devices (OSSDs) (used as single channels)</li> <li>• 2 dual channel safety outputs</li> <li>• 1 dual channel safety output and 2 Output Signal Switching Devices (OSSDs)</li> </ul>
<b>OSSD characteristic</b>	<ul style="list-style-type: none"> <li>• Maximum resistive load: 100 kΩ</li> <li>• Minimum resistive load: 70 Ω</li> <li>• Maximum capacitive load: 1000 nF</li> <li>• Minimum capacitive load: 10 nF</li> </ul>
<b>Safety outputs</b>	<p>High-side outputs (with extended protection function)</p> <ul style="list-style-type: none"> <li>• Maximum current: 0.4 A</li> <li>• Maximum power: 11.2 W</li> </ul> <p>The OSSDs provide what follows:</p> <ul style="list-style-type: none"> <li>• ON-state: from U<sub>v</sub>-1V to U<sub>v</sub> (U<sub>v</sub> = 24 V +/- 4 V)</li> <li>• OFF-state: from 0 V to 2.5 V r.m.s.</li> </ul>
<b>Inputs</b>	Configurable as follows: <ul style="list-style-type: none"> <li>• 4 single channel (cat. 2) type 3 digital inputs with common GND</li> <li>• 2 dual channel (cat. 3) type 3 digital inputs with common GND</li> <li>• 1 dual channel (cat. 3) and 2 single channels (cat. 2) type 3 digital inputs with common GND</li> </ul> <p>See "Voltage and current limits for digital inputs" on page 127.</p>
<b>Fieldbus interface (if available)</b>	Ethernet based interface with different standard Fieldbus
<b>Power supply</b>	24 V DC (20–28 V DC) * Maximum current: 1.2 A
<b>Consumption</b>	Max. 5 W
<b>Assembly</b>	On DIN rail
<b>Weight</b>	<p>For Type A: with cover: 170 g (6 oz)</p> <p>For Type B: with cover: 160 g (5.7 oz)</p>
<b>Degree of protection</b>	IP20
<b>Terminals</b>	<p>Section: 1 mm<sup>2</sup> (16 AWG) max.</p> <p>Maximum current: 4 A with 1 mm<sup>2</sup> cables (16 AWG)</p>
<b>Impact test</b>	<p>For Type A: 0.5 J, 0.25 kg ball from a 20 cm height</p> <p>For Type B: 1 J, 0.25 kg ball from a 40 cm height</p>
<b>Shock/Bump</b>	<p>For Type A: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.2 (IEC 60068-2-27)</p> <p>For Type B: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.2 class 5M3 (IEC 60068-2-27)</p>
<b>Vibration</b>	<p>For Type A: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.1 (IEC 60068-2-6)</p> <p>For Type B: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.1 class 5M3 (IEC 60068-2-6 and IEC 60068-2-64)</p>
<b>Pollution degree</b>	2
<b>Outdoor use</b>	No

<b>Operating temperature</b>	From -30 to +60 °C (from -22 to +140 °F)
<b>Storage temperature</b>	From -40 to +80 °C (from -40 to +176 °F)


**Note\***: the control unit shall be supplied by an isolated power source which complies with the standard IEC/EN 60204-1 and fulfils the requirements of:

- *Limited-Energy Circuit in accordance with IEC/UL/CSA 61010-1/ IEC/UL/CSA 61010-2-201 or*
- *Limited Power Source (LPS) in accordance with IEC/UL/CSA 60950-1 or*
- *(For North America and/or Canada only) a Class 2 supply source which complies with the National Electrical Code (NEC), NFPA 70, Clause 725.121 and Canadian Electrical Code (CEC), Part I, C22.1. (typical examples are a Class 2 transformer or a Class 2 power sources in compliance with, UL 5085-3/CSA-C22.2 No. 66.3 or UL 1310/CSA-C22.2 No. 223).*



mm  
(in)

Type A




mm  
(in)

Type B


### 5.1.1.5 Sensor features

<b>Connectors</b>	2 5-pin M12 connectors (1 male and 1 female)
<b>CAN bus termination resistance</b>	120 $\Omega$ (not supplied, to be installed with a bus terminator)
<b>Power supply</b>	12 V DC $\pm$ 20%, through control unit
<b>Consumption</b>	For S201A and S203A model: <ul style="list-style-type: none"> <li>Average 2.2 W</li> <li>Peak 3.4 W</li> </ul> For S202A model: <ul style="list-style-type: none"> <li>Average 2.6 W</li> <li>Peak 4.3 W</li> </ul>
<b>Degree of protection</b>	Type 3 enclosure, according to UL 50E, in addition to IP 67 rating
<b>Material</b>	Sensor: PA66 Bracket: PA66 and glass fiber (GF)
<b>Frame rate</b>	62 fps
<b>Weight</b>	S201A: <ul style="list-style-type: none"> <li>With 2-axis bracket: 300 g (10.6 oz)</li> <li>With 3-axis bracket: 355 g (12.5 oz)</li> </ul> S202A, S203A: <ul style="list-style-type: none"> <li>With 2-axis bracket: 335 g (11.8 oz)</li> <li>With 3-axis bracket: 395 g (13.9 oz)</li> </ul>
<b>Shock/Bump</b>	For S201A model: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.2 (IEC 60068-2-27) For S202A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.2 class 5M3 (IEC 60068-2-27) For S203A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.2 class 5M3 (IEC 60068-2-27)
<b>Vibration</b>	For S201A model: in accordance with IEC/EN 61496-1:2013 sec. 5.4.4.1 (IEC 60068-2-6) For S202A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.1 class 5M3 (IEC 60068-2-6 and IEC 60068-2-64) For S203A model: in accordance with IEC/EN 61496-1:2020 sec. 5.4.4.1 class 5M3 (IEC 60068-2-6 and IEC 60068-2-64)
<b>Pollution degree</b>	4
<b>Outdoor use</b>	Yes
<b>Operating temperature</b>	From -30 to +60 $^{\circ}$ C (from -22 to +140 $^{\circ}$ F)*
<b>Storage temperature</b>	From -40 to +80 $^{\circ}$ C (from -40 to +176 $^{\circ}$ F)

**Note\*:** in environmental conditions where the operating temperature can reach values higher than the supported range, install a cover to shield the sensor from sun rays.



S201A model




### 5.1.1.6 CAN bus cables recommended specifications

<b>Section</b>	2 x 0.50 mm <sup>2</sup> (21 AWG) power supply 2 x 0.22 mm <sup>2</sup> (24 AWG) data line
<b>Type</b>	Two twisted pairs (power supply and data) and one drain wire (or shield)
<b>Connectors</b>	5-pole M12 (see "Connectors M12 CAN bus" on page 128) Connectors shall be type 3 (raintight)
<b>Impedance</b>	120 Ω ±12 Ω (f = 1 MHz)
<b>Shield</b>	Shield with twisted wires in tin-plated copper. To be connected to ground circuit on the power supply terminal block of the control unit.
<b>Standards</b>	Cables shall be listed in accordance with application as described in the National Electrical Code, NFPA 70, and in the Canadian Electrical Code, C22.1. Total maximum length of the CAN bus line: 80 m (262.5 ft)

### 5.1.1.7 Tamper-proof screws specifications


#### Pin Hex button head security screw



	Sensor-bracket screw	3-axis bracket
$d_1$	M4	M4
$l$	10 mm (0.39 in)	16 mm (0.63 in)
$d_2$	7.6 mm (0.30 in)	7.6 mm (0.30 in)
$k$	2.2 mm (0.09 in)	2.2 mm (0.09 in)
$t$	min 1.3 mm (0.05 in)	min 1.3 mm (0.05 in)
$s$	2.5 mm (0.10 in)	2.5 mm (0.10 in)
$d_3$	max. 1.1 mm (0.04 in)	max 1.1 mm (0.04 in)

### 5.1.1.8 Non tamper-proof screws specifications

#### Hex button head screw (2-axis bracket)




$d_1$	M4
$l_1$	19 mm (0.74 in)
$l_2$	6 mm (0.23 in)
$l_3$	2 mm (0.07 in)
$d_2$	7.6 mm (0.30 in)
$k$	3 mm (0.11 in)
$s$	2.5 mm (0.10 in)
$d_3$	4 mm (0.15 in)

### 5.1.1.9 Bottom screws specifications

The bottom screws can be:


- cheese head
- button head

**Note:** avoid using countersunk head screws.



## 5.1.2 Digital input signals


### 5.1.2.1 Stop signal



Part	Description
<b>OSSDx:</b> <b>Detection signal "N"/Detection signal group "N"</b>	Detection signal outputs deactivate on the falling edge of at least one of the two input channels of the input signal. They remain in OFF-state as long as one of the two input channels remains to the low logic status (0).
<b>Stop signal CH1</b> <b>Stop signal CH2</b>	Interchangeable channel. As soon as one channel goes to the low logic level (0), Detection signal 1 and Detection signal 2 are set to OFF-state.
<b>Diff</b>	Less than 50 ms. If the value is greater than 50 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
<b>Dt</b>	Activation delay. Less than 5 ms. For eXtended Line: if the Stop signal debounce filter is disabled, less than 5 ms; if the Stop signal debounce filter is enabled, less than 50 ms.


### 5.1.2.2 Muting (with/without pulse)

#### Without pulse (redundancy mode coherent)




Part	Description
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
<b>Muting signal (group n) CH 1</b>	Interchangeable channel.
<b>Muting signal (group n) CH 2</b>	
<b>Muting status</b>	They are enabled as long as both channels are at a high logic level (1) and deactivated when both channels go to a low logic level (0).
<b>Dt</b>	Activation/deactivation delay. Less than 50 ms.

### Without pulse (redundancy mode inverted)




Part	Description
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
<b>Muting status</b>	They are enabled as long as channel 1 of the Muting signal is at a high logic level (1) and channel 2 is at a low logic level (0). Disabled as long as channel 1 is at a low logic level (0) and channel 2 is at a high logic level (1).
<b>Dt</b>	Activation/deactivation delay. Less than 50 ms.

## With pulse




Part	Description
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
<b>Muting signal (group n) CH 1</b>	Interchangeable channel.
<b>Muting signal (group n) CH 2</b>	
<b>Muting status</b>	They are enabled as long as both the input signals follow the configured muting parameters (pulse width, period, and phase shift).
<b>Dt</b>	Activation/deactivation delay. Less than three times the period.

### 5.1.2.3 Restart signal (dual channel, redundancy mode coherent)




Part	Description
<b>OSSDx:</b> <b>Detection signal "N"/Detection signal group "N"</b>	Detection signal outputs go to ON-state as soon as the last channel has correctly completed the transition 0 -> 1 -> 0.
<b>Restart signal CH1</b>	Interchangeable channel. Both channels of Restart signal must have a transition of logical level 0 -> 1 -> 0. The time they stay at a high logical level ( $t$ ) must be at least 200 ms and less than 5 s.
<b>Restart signal CH2</b>	Interchangeable channel. Both channels of Restart signal must have a transition of logical level 0 -> 1 -> 0. The time they stay at a high logical level ( $t$ ) must be at least 200 ms and less than 5 s.
<b>Dt</b>	Activation delay. Less than 50 ms.
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

### 5.1.2.4 Restart signal (dual channel, redundancy mode inverted)




Part	Description
<b>OSSDx:</b>	Detection signal outputs go to ON-state as soon as the last channel has correctly completed the transition.
<b>Detection signal "N"/Detection signal group "N"</b>	
<b>Restart signal CH1</b>	Channel 1 of the Restart signal must have a transition of logical level 0 -> 1 -> 0. Channel 2 of Restart signal must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) must be at least 200 ms and less than 5 s.
<b>Restart signal CH2</b>	
<b>Dt</b>	Activation delay. Less than 50 ms.
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

### 5.1.2.5 Restart signal (single channel)




Part	Description
<b>OSSDx:</b>	Detection signal outputs go to ON-state as soon as the Restart signal has correctly completed the transition 0 -> 1 -> 0.
<b>Detection signal "N"/Detection signal group "N"</b>	
<b>Restart signal</b>	The channel must have a transition of logical level 0 -> 1 -> 0. The time they stay at a high logical level (t) must be at least 200 ms and less than 5 s.
<b>Dt</b>	Activation delay. Less than 50 ms.

### 5.1.2.6 System recondition (dual channel, redundancy mode coherent)




Part	Description
<b>System recondition CH1</b>	Interchangeable channel. Both channels of System recondition must have a transition of logical level 0 -> 1 -> 0. They must stay at a high logical level (t) for at least 10 s and less than 30 s.
<b>System recondition CH2</b>	
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

### 5.1.2.7 System recondition (dual channel, redundancy mode inverted)




Part	Description
<b>System recondition CH1</b>	Channel 1 of System recondition must have a transition of logical level 0 -> 1 -> 0. Channel 2 of System recondition must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) for at least 10 s and less than 30 s.
<b>System recondition CH2</b>	
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

### 5.1.2.8 System recondition (single channel)




Part	Description
<b>System recondition</b>	The channel must have a transition of logical level 0 -> 1 -> 0. The time it stays at a high logical level (t) must be at least 10 s and less than 30 s.

### 5.1.2.9 Restart signal + System recondition (dual channel, redundancy mode coherent)



Part	Description
<b>CH1</b> <b>CH2</b> <b>(Restart signal)</b>	Interchangeable channel. Both channels must have a transition of logical level 0 -> 1 -> 0. The time they stay at a high logical level (t) must be at least 200 ms and less than 5 s.
	For details about the behavior of Detection signal 1 and 2 outputs and the deactivation delay, see "Restart signal (dual channel, redundancy mode coherent)" on page 112.
<b>CH1</b> <b>CH2</b> <b>(System recondition)</b>	Interchangeable channel. Both channels must have a transition of logical level 0 -> 1 -> 0. They must stay at a high logical level (t) for at least 10 s and less than 30 s.
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.

### 5.1.2.10 Restart signal + System recondition (dual channel, redundancy mode inverted)



Part	Description
<b>CH1</b> <b>CH2</b> <b>(Restart signal)</b>	Channel 1 of the Restart signal must have a transition of logical level 0 -> 1 -> 0. Channel 2 of Restart signal must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) must be at least 200 ms and less than 5 s.
	For details about the behavior of Detection signal 1 and 2 outputs and the deactivation delay, see "Restart signal (dual channel, redundancy mode inverted)" on page 113.
<b>CH1</b> <b>CH2</b> <b>(System recondition)</b>	Channel 1 of System recondition must have a transition of logical level 0 -> 1 -> 0. Channel 2 of System recondition must have a transition of logical level 1 -> 0 -> 1. The time Channel 1 stays at a high logical level and the time Channel 2 stays at a low logical level (t) for at least 10 s and less than 30 s.
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the system maintains the outputs deactivated.


### 5.1.2.11 Restart signal + System recondition (single channel)




Part	Description
<b>Restart signal</b>	The channel must have a transition of logical level 0 -> 1 ->0. The time it stays at a high logical level (t) must be at least 200 ms and less than 5 s. For details about the behavior of Detection signal 1 and 2 outputs and the deactivation delay, see "Restart signal (single channel)" on page 113.
<b>System recondition</b>	The channel must have a transition of logical level 0 -> 1 ->0. The time it stays at a high logical level (t) must be at least 10 s and less than 30 s.

### 5.1.2.12 Dynamic configuration switch (redundancy mode coherent)

#### With one input




### With two inputs (encoded channels disabled)




Part	Description
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
<b>Dynamic configuration number</b>	For details about the dynamic configuration number and the encoded channel option, see "Dynamic system configuration" on page 34.
<b>Dt</b>	Activation/deactivation delay. Less than 50 ms.

### 5.1.2.13 Dynamic configuration switch (redundancy mode inverted)

#### With one input




## With two inputs




Part	Description
<b>Diff</b>	Less than 100 ms. If the value is greater than 100 ms, the diagnostic alarm starts and the system deactivates the safety outputs.
<b>Dynamic configuration number</b>	For details about the dynamic configuration number and the encoded channels option, see "Dynamic system configuration" on page 34.
<b>Dt</b>	Activation/deactivation delay. Less than 50 ms.

## 5.1.3 Control units layout


### 5.1.3.1 Type A control units



C201A model



C202A model




C203A model

Part	Description	C201A model	C202A model	C203A model
<b>A</b>	I/O terminal block	x	x	x
<b>B</b>	System status LEDs	x	x	x
<b>C</b>	Network parameter reset button / Factory reset button	x	x	x
<b>D</b>	Reserved for internal use. Output reset button	x	x	x
<b>E</b>	Micro-USB port (micro-B type) for connecting the PC and communicating with the system application	x	x	x
<b>F</b>	Micro-USB port, if mounted (reserved)	x	-	-
<b>G</b>	Fieldbus status LEDs See "Control units" on page 17 or "Control units" on page 17.	x	-	-
<b>H</b>	Ethernet port with LEDs for connecting the PC, communicating with the system application, and for MODBUS communication	x	x	-
<b>I</b>	Power supply terminal block	x	x	x
<b>J</b>	Power supply LEDs (steady green)	x	x	x
<b>K</b>	CAN bus terminal block for connecting the first sensor	x	x	x
<b>L</b>	DIP switch to turn on/off the bus termination resistance: <ul style="list-style-type: none"> <li>• On (top position, default) = resistance included</li> <li>• Off (bottom position) = resistance excluded</li> </ul>	x	x	x
<b>M1</b>	Status LED of hardware functions of the secondary micro-controller: <ul style="list-style-type: none"> <li>• slow flashing orange: normal behavior</li> <li>• other status: contact Technical Support</li> </ul>	x	x	x
<b>M2</b>	Status LED of hardware functions of the primary micro-controller: <ul style="list-style-type: none"> <li>• off: normal behavior</li> <li>• steady red: contact Technical Support</li> </ul>	x	x	x
<b>N</b>	Fieldbus port no. 1 with LEDs (PROFIsafe or FS0E IN)	x	-	-
<b>O</b>	Fieldbus port no.2 with LEDs (PROFIsafe or FS0E OUT)	x	-	-


## 5.1 Data and parameters

**Note:** only for C201A-F and C201A-FX1: the processing direction is from the N connection to the O connection. In normal operation, the device receives the data from the controller on N and sends the outgoing data on O.


### 5.1.3.2 Type B control units



C201B model



C202B model



C203B model

Part	Description	C201B model	C202B model	C203B model
<b>A</b>	I/O terminal block	X	X	X
<b>B</b>	System status LEDs	X	X	X
<b>C</b>	Network parameter reset button / Factory reset button	X	X	X
<b>D</b>	Micro-USB port (micro-B type) for connecting the PC and communicating with the system application	X	X	X
<b>E</b>	Fieldbus status LEDs See "Control units" on page 17 or "Control units" on page 17.	X	-	-
<b>F</b>	SD Restore button	X	X	X
<b>G</b>	MicroSD slot	X	X	X

Part	Description	C201B model	C202B model	C203B model
<b>H</b>	Ethernet port with LEDs for connecting the PC, communicating with the system application, and for MODBUS communication	x	x	-
<b>I</b>	Power supply terminal block	x	x	x
<b>J</b>	Power supply LEDs (steady green)	x	x	x
<b>K</b>	CAN bus terminal block for connecting the first sensor	x	x	x
<b>L</b>	DIP switch to turn on/off the bus termination resistance: <ul style="list-style-type: none"> <li>On (top position, default) = resistance included</li> <li>Off (bottom position) = resistance excluded</li> </ul>	x	x	x
<b>M1</b>	Status LED of hardware functions of the secondary micro-controller: <ul style="list-style-type: none"> <li>slow flashing orange: normal behavior</li> <li>other status: contact Technical Support</li> </ul>	x	x	x
<b>M2</b>	Status LED of hardware functions of the primary micro-controller: <ul style="list-style-type: none"> <li>off: normal behavior</li> <li>steady red: contact Technical Support</li> </ul>	x	x	x
<b>N</b>	Fieldbus port no. 1 with LEDs (PROFIsafe, CIP Safety™ or FSoE IN)	x	-	-
<b>O</b>	Fieldbus port no.2 with LEDs (PROFIsafe, CIP Safety™ or FSoE OUT)	x	-	-

**Note:** only for C201B-F and C201B-FX1: the processing direction is from the N connection to the O connection. In normal operation, the device receives the data from the controller on N and sends the outgoing data on O.

## 5.1.4 Control unit parameters

### 5.1.4.1 Parameter list

Parameter	Min	Max	Default value
Control unit channel	0	3	0
Digital input (for each input)	Not configured, Stop signal, Restart signal, Muting group 1, Muting group 2, Dynamic configuration switch, Fieldbus controlled, System recondition, Restart signal + System recondition, Single channel (Category 2), Anti-masking reference saving, Anti-rotation reference saving		
Digital input channel (for each channel of each input)	Not configured, Restart signal, Fieldbus controlled, System recondition, Restart signal + System recondition		
Redundancy mode	Coherent, Inverted		
Encoded channel	Enabled, Disabled <b>Note:</b> available only when both the digital inputs are configured as Dynamic configuration switch		

Parameter	Min	Max	Default value
Pulse width (for each input)	0 µs (= Period and Phase shift disabled) 200 µs	2000 µs	0 µs
Period (for each input)	200 ms	2000 ms	200 ms
Phase shift (for each input)	0.4 ms	1000 ms	0.4 ms
Stop signal debounce filter	Enabled, Disabled		Disabled
Digital output (for each output)	Not configured, System diagnostic signal, Muting enable feedback signal, Fieldbus controlled, Restart feedback signal, Detection signal "N", Detection warning "N", Static object detection feedback signal, Detection signal group 1, Detection signal group 2, Detection warning group 1, Detection warning group 2		Not configured
OSSD Pulse width	Short (300 µs), Long (2 ms)		Short (300 µs)
Short-circuit/Open circuit diagnostics	Enabled, Disabled		Disabled
Electromagnetic robustness	Standard, High, Very High		Standard
Static object detection sensitivity	-20 dB	+20 dB	0 dB
Log verbosity level	0	5	0
Automatic backup creation	Enabled, Disabled		Disabled
Users data included	Enabled, Disabled		Disabled
Enable restore by button	Enabled, Disabled		Enabled


For sensor configuration parameters, see "Appendix A: sensor lines" on page 137.

## 5.1.5 Target position angle conventions

### 5.1.5.1 Horizontal angle

The horizontal angle of the target position is reported according to the following convention:


- the angle has a plus (+) sign when the target is on the sensor's left side.
- the angle has a minus sign (-) when the target is on the sensor's right side.



### 5.1.5.2 Vertical angle

The vertical angle of the target position is reported according the following convention:

- the angle has a plus (+) sign when the target is above the center of the sensor.
- the angle has minus sign (-) when the target is below the center of the sensor.



## 5.1.6 Separation distance calculation

### 5.1.6.1 Introduction

The formula to be used to calculate the separation distance is compliant with the ISO 13855:2024 standard and is described in the sections below.

### 5.1.6.2 Stationary application

To calculate the separation distance, the integrator should take into consideration the following parameters:

- $H_{VT}$ : height of the upper edge of the detection volume from the reference plane
- $H_{VB}$ : height of the lower edge of the detection volume from the reference plane

The sensor should be installed such that  $H_{VT}$  and  $H_{VB}$  are sufficient to guarantee a proper detection of persons according to the risk analysis.

The overall separation distance  $S$  can be calculated as:

$$S = K * T + D_{DS} + Z_G$$

Where:

Variable	Description
$K$	Maximum approach speed. It is considered to be 1600 mm/s, because RPDs are body protection devices. This is consistent with the definition of approach speed of ISO 13855:2024.
$T$	Overall system response time in s*
$D_{DS}$	Reaching distance
$Z_G$	Supplemental distance factor in mm. The tolerance zone is already considered in the provided detection distance as expressed in IEC TS 61496-5. No corrective values for the tolerance zone need to be added to the calculation of the separation distance.

**Note\*:** it includes portions of time that vary according to machinery type, safeguard(s) applied, and elements of the SRP/CS involved in the safety function. When using Fieldbus, the computation of the overall response time should consider the cycle time.

The separation distance value can be calculated depending on the height of  $H_{VT}$ :

- for  $H_{VT} \geq 900$  mm approach is considered orthogonal, see "Separation distance calculation:  $H_{VT} \geq 900$  mm" below
- for  $H_{VT} < 900$  mm approach is considered parallel, see "Separation distance calculation:  $H_{VT} < 900$  mm" on page 125

### 5.1.6.3 Separation distance calculation: $H_{VT} \geq 900$ mm

For  $H_{VT} \geq 900$  mm approach is considered orthogonal.

The calculation of the separation distance should be made in accordance with clause 8 of ISO 13855:2024.

## 5.1 Data and parameters

The following considerations are valid:

- For *reaching over*  $D_{DO}$  (clause 8.2 of ISO 13855:2024),  $H_{DT}$  should be considered equivalent to  $H_{VT}$ .
- For *reaching through*  $D_{DT}$  (clause 8.3 of ISO 13855:2024), a detection capability  $55 \text{ mm} < d_e \leq 120 \text{ mm}$  or higher should be considered.
- For *reaching under*  $D_{DU}$  (clause 8.4 of ISO 13855:2024),  $H_{DB}$  should be considered equivalent to  $H_{VB}$ .

Example


- $T = 0.1 \text{ s} + 0.4 \text{ s} = 0.5 \text{ s}$
- $H_{VB} = H_{DB} = 180 \text{ mm}$
- $H_{VT} = H_{DT} = 1000 \text{ mm}$
- $H_H = 600 \text{ mm}$
- $Z_G = 0 \text{ mm}$

According to clauses 8.2, 8.3 and 8.4, respectively, of ISO 13855:2024:

- $D_{DO} = 950 \text{ mm}$
- $D_{DT} = 850 \text{ mm}$
- $D_{DU} = 750 \text{ mm}$
- $D_{DS} = \max(D_{DO}, D_{DT}, D_{DU})$

According to these values, the overall separation distance is:

$$S = K \times T + D_{DS} + Z_G = K \times T + \max(D_{DO}, D_{DT}, D_{DU}) + ZG = 1600 \times 0.5 + \max(950, 850, 750) + 0 = 1750 \text{ mm}$$



### 5.1.6.4 Separation distance calculation: $H_{VT} < 900$ mm

For  $H_{VT} < 900$  mm approach is considered parallel.

The calculation of the separation distance should be made in accordance with clauses 9.3 and 9.4 of ISO 13855:2024.

The following considerations are valid:

- $H_{VB}$  should not be greater than 200 mm
- $H_{VT}$  should not be greater than 900 mm

#### Example


- $T = 0.1\text{ s} + 0.4\text{ s} = 0.5\text{ s}$
- $H_{VB} = H_{DB} = 150\text{ mm}$
- $H_{VT} = 800\text{ mm}$
- $G_D \geq 70\text{ mm}$
- $F_D \geq 1200\text{ mm}$  according to clause 9.4 of ISO 13855:2024
- $Z_G = 0\text{ mm}$

According to formula in clause 9.3 of ISO 13855:2024:

- $D_{DS} = 1200\text{ mm}$

According to these values, the overall separation distance is:

$$S = K \times T + D_{DS} + Z_G = 1600 \times 0.5 + 1200 + 0 = 2000\text{ mm}$$



### 5.1.6.5 Mobile application

In case of mobile applications, the calculation of the separation distance should be made in accordance with ISO 13855:2024.

The supplemental distance factor of the Inxpect SRE 200 Series is 200 mm. In accordance with the ISO 13855:2024, additional supplemental distance factors shall be considered.

The overall separation distance  $S$  can be calculated as:

$$S = K * T + D_{DS} + Z_G$$

Where:

Variable	Description
<b>K</b>	Maximum vehicle/part of the machinery speed*. <ul style="list-style-type: none"> <li>For detection distance <math>\leq 4</math> m (13.12 ft): <math>K \leq 3000</math>.</li> <li>For detection distance <math>&gt; 4</math> m (13.12 ft): <math>K \leq 2000</math>.</li> </ul>
<b>T</b>	Overall system response time in $s^{**}$
<b>D<sub>DS</sub></b>	Reaching distance
<b>Z<sub>G</sub></b>	Supplemental distance factor in $mm$ .

**Note\***: only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

**Note\*\***: it includes portions of time that vary according to machinery type, safeguard(s) applied, and elements of the SRP/CS involved in the safety function. When using Fieldbus, the computation of the overall response time should consider the cycle time.

Example

- $T = 0.1 \text{ s} + 0.4 \text{ s} = 0.5 \text{ s}$
- $Z_G = 200 \text{ mm}$

According to these values, the overall separation distance is:

$$S = K \times T + D_{DS} + Z_G = 2000 \times 0.5 + 0 + 200 = 1200 \text{ mm}$$

## 5.2 Electrical installation


### Contents

This section includes the following topics:

<b>5.2.1 Terminal blocks and connector pin-outs</b> .....	<b>127</b>
<b>5.2.2 Electrical connections</b> .....	<b>129</b>

## 5.2.1 Terminal blocks and connector pin-outs

### 5.2.1.1 Digital inputs and outputs terminal block



**Note:** facing the control unit so that the terminal block is on the top left, number 12 is the closest to the control unit corner.

Terminal block	Symbol	Description	Pin
Digital In	4	Input 2, Channel 2, 24 V DC type 3 - INPUT #2-2	1
	3	Input 2, Channel 1, 24 V DC type 3 - INPUT #2-1	2
	2	Input 1, Channel 2, 24 V DC type 3 - INPUT #1-2	3
	1	Input 1, Channel 1, 24 V DC type 3 - INPUT #1-1	4
	V+	V+ (SNS), 24 V DC for diagnostics of the digital inputs (mandatory if at least one input is used)	5
	V-	V- (SNS), common reference for all digital inputs (mandatory if at least one input is used)	6
Digital Out	-	GND, common reference for all digital outputs	7
	4	Output 4 (OSSD4)	8
	3	Output 3 (OSSD3)	9
	2	Output 2 (OSSD2)	10
	1	Output 1 (OSSD1)	11
	-	GND, common reference for all digital outputs	12

**Note:** the cables used must have a maximum length of 30 m (98.4 ft) and the maximum operating temperature must be at least 80 °C.


**Note:** use only copper wires with a minimum gauge of 18 AWG and a torque of 0.62 Nm (5.5 lbs in).

### 5.2.1.2 Voltage and current limits for digital inputs

The digital inputs (input voltage 24 V DC) adhere to the following voltage and current limits, in accordance with standard IEC/EN 61131-2:2003.

Type 3	
Voltage limits	
0	from - 3 to 11 V
1	from 11 to 30 V
Current limits	
0	15 mA
1	from 2 to 15 mA

### 5.2.1.3 Power supply terminal block




**Note:** connector front view.

Symbol	Description
V-	GND
	Earth
V+	+ 24 V DC

**Note:** the maximum operating temperature of the cables must be at least 70 °C.

**Note:** use only copper wires with a minimum gauge of 18 AWG and a torque of 0.62 Nm (5.5 lbs in).


### 5.2.1.4 CAN bus terminal block




Symbol	Description
+	+ 12 V DC output
H	CAN H
L	CAN L
-	GND

**Note:** the maximum operating temperature of the cables must be at least 70 °C.

### 5.2.1.5 Connectors M12 CAN bus



Male connector




Female connector

Pin	Function
<b>1</b>	Shield to be connected to the functional earth on the power supply terminal block of the control unit.
<b>2</b>	+12 V dc
<b>3</b>	GND
<b>4</b>	CAN H
<b>5</b>	CAN L

## 5.2.2 Electrical connections


### 5.2.2.1 Connection of safety outputs to the Programmable Logic Controller



#### Digital I/O settings (through the system application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Detection signal 1
- Digital output #2 Detection signal 1
- Digital output #3 Not configured
- Digital output #4 Not configured


### 5.2.2.2 Connection of safety outputs to an external safety relay



#### Digital I/O settings (through the system application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Detection signal 1
- Digital output #2 Detection signal 1
- Digital output #3 Not configured
- Digital output #4 Not configured

### 5.2.2.3 Connection of stop signal (Emergency button)



**Note:** the indicated emergency button opens the contact when pressed.

**Note:** the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

#### Digital I/O settings (through the system application)

Digital input #1 Not configured

Digital input #2 Stop signal


Digital output #1 Not configured

Digital output #2 Not configured

Digital output #3 Not configured

Digital output #4 Not configured

### 5.2.2.4 Connection of restart signal (dual channel)



**Note:** the button indicated for the restart signal closes the contact when pressed.

**Note:** the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

#### Digital I/O settings (through the system application)

Digital input #1 Not configured

Digital input #2 Restart signal


Digital output #1 Not configured

Digital output #2 Not configured

Digital output #3 Not configured

Digital output #4 Not configured

### 5.2.2.5 Connection of the muting input and output (one group of sensors)




**Note:** the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

#### Digital I/O settings (through the system application)

- Digital input #1 Muting group 1
- Digital input #2 Not configured
- Digital output #1 Not configured
- Digital output #2 Not configured
- Digital output #3 Muting enable feedback signal
- Digital output #4 Not configured

### 5.2.2.6 Connection of the muting input and output (two groups of sensors)




**Note:** the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

#### Digital I/O settings (through the system application)

- Digital input #1 Muting group 1
- Digital input #2 Muting group 2
- Digital output #1 Not configured
- Digital output #2 Not configured
- Digital output #3 Muting enable feedback signal
- Digital output #4 Not configured


### 5.2.2.7 Detection signal 1 and 2 connection



#### Digital I/O settings (through the system application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Detection signal 1
- Digital output #2 Detection signal 1
- Digital output #3 Detection signal 2
- Digital output #4 Detection signal 2

### 5.2.2.8 Diagnostic output connection



**Note:** the cables used for wiring the digital inputs must have a maximum length of 30 m (98.4 ft).

#### Digital I/O settings (through the system application)

- Digital input #1 Not configured
- Digital input #2 Not configured
- Digital output #1 Not configured
- Digital output #2 Not configured
- Digital output #3 System diagnostic signal
- Digital output #4 Not configured

# 6. Appendix A: sensor lines

## 6.1 Core line sensors: S201A

### Contents

This section includes the following topics:

<b>6.1.1 Main features</b>	<b>137</b>
<b>6.1.2 Sensor field of view</b>	<b>138</b>
<b>6.1.3 Installation recommendations for stationary application</b>	<b>140</b>
<b>6.1.4 Installation recommendations for mobile application</b>	<b>142</b>
<b>6.1.5 Range of distances</b>	<b>143</b>
<b>6.1.6 Configuration parameters</b>	<b>144</b>

### 6.1.1 Main features

#### 6.1.1.1 Feature list

<b>Model-type</b>	S201A
<b>Compatible control unit production line</b>	Core Line eXtended Line
<b>Safety function managed</b>	Access detection Restart prevention
<b>Safety working modes</b>	Access detection and restart prevention Always-on access detection Always-on restart prevention
<b>Application</b>	Stationary Mobile Vehicle
<b>Outdoor installation</b>	Yes
<b>Configuration tool</b>	Inxpect Safety
<b>Access detection speed limit (stationary application)</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Access detection speed limit* (mobile application)</b>	For detection distance less than or equal to 4 m (13.12 ft): <ul style="list-style-type: none"><li>• Min: 0.1 m/s (0.33 ft/s)</li><li>• Max: 3 m/s (9.84 ft/s)</li></ul> For detection distance greater than 4 m: <ul style="list-style-type: none"><li>• Min: 0.1 m/s (0.33 ft/s)</li><li>• Max: 2 m/s (6.56 ft/s)</li></ul>
<b>Dynamic configuration available</b>	Up to 32**
<b>Static object detection option</b>	Yes

**Note\*:** only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

**Note\*\*:** for limitations that reduce the maximum number of dynamic configurations, see "Dynamic configuration presets" on page 34.

## 6.1.2 Sensor field of view


### 6.1.2.1 Dimensions

Below are the maximum field of view dimensions **[A]** and the relative gray area **[B]**.


The gray area dimensions are the same for maximum angular coverage (as described in the figures below) and smaller coverages.

**Note:** the gray area dimensions described are related to the detection of humans.

#### Access detection function



## Restart prevention function




Top view

### 6.1.2.2 Position of the field of view

The field of view is tilted of 2.5°


To understand the actual position of the sensor field of view consider the LED position:

- left with sensor LED on the right (with respect to the sensor center, facing the sensor)
- right with sensor LED on the left (with respect to the sensor center, facing the sensor)
- downward with sensor LED up



Top view with sensor inclination 0°.

Top view with sensor inclination 0°.



Side view with sensor inclination 0°.

## 6.1.3 Installation recommendations for stationary application

### 6.1.3.1 For access detection function

**⚠️ WARNING!** Take all necessary precautions to prevent people from climbing over and entering the area, whenever there is that risk.

Below are some recommendations for the sensor positioning for the access detection function:


- If the distance between the ground and the bottom portion of the field of view is greater than 20 cm (7.9 in), take precautions to make sure that even a person entering the dangerous area below the volume monitored by the field of view is still detected.
- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).
- If the height above the ground is less than 20 cm (7.9 in), install the sensor with an inclination of minimum 10° upwards.

### For access control of an entrance


If the sensor is used in access detection for monitoring a pedestrian entry in a confined area, the recommendations below should be taken into consideration:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 20 cm (7.9 in).
- The horizontal angular coverage must be 90°.
- The rotation around the x-axis must be 90°.
- The inclination must be 40° upwards.

Below is an example:



**WARNING!** The horizontal angular coverage in the first 800 mm (31.5 in) of the field of view must be at least 60°. If this specification cannot be respected, take precautions to avoid the access of a human in the first 800 mm (31.5 in) of the field of view.



### 6.1.3.2 For restart prevention function

Below are some recommendations for the sensor positioning for the restart prevention function:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).
- If the height above the ground is less than 20 cm (7.9 in), install the sensor with an inclination of minimum 10° upwards.

The restart prevention function is effective if the sensor can detect a person's movements or their static residual movements. To detect people who are not standing or squatting, it is important that the sensor can clearly detect the person's chest.

Particular attention should be paid to the following situations:

- There are objects that limit or prevent the sensor from detecting motion.
- The sensor does not detect a sufficient portion of the body or does not properly detect the person's chest.
- The risk assessment requires the detection of a lying person and the sensor is installed at a height below 2.5 m (8.2 ft) or with an inclination lower than 60° downwards


A validation procedure (see "Validate the safety functions" on page 68) must be performed when one or more of the above conditions are met.


If the conditions described above limit the performance of the sensor, take the following steps to reach an appropriate level of performance:

- Increase the **Restart timeout** parameter.
- Change the position of the sensors.
- Add more sensors.

If one or more of the above actions are taken, it is recommended to perform a validation procedure (see "Validate the safety functions" on page 68).

Below are some examples of situations where the above conditions are met (✓) or not met (✗). These examples are not meant to be exhaustive.





### 6.1.3.3 For outdoor application

The recommendations reported above for access detection and restart prevention functions are still valid in outdoor environments.

Before installing a sensor facing downwards, make sure there are neither liquids nor radar reflective materials on the floor.

#### Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:

- Make a cover to protect the sensor from rain, hail or snow, so that the drops do not fall directly on the sensor.
- Position the sensor so that it does not frame the ground where puddles might form.


**NOTICE:** Weather conditions outside specifications can prematurely age the device.

If the monitored area is free of static objects, the system is robust against a rainfall rate up to 45 mm/h.

#### Recommendations for covering the sensor

Below are some recommendations for creating and installing a sensor cover:

- height from sensor: 15 cm (6 in)
- width: minimum 30 cm (11.8 in), maximum 40 cm (15.7 in)
- protrusion from the sensor: minimum 15 cm (6 in), maximum 20 cm (7.9 in)
- water outflow: at the sides or behind but not in front of the sensor (the cover should be arched and/or tilted backwards)



#### Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.


## 6.1.4 Installation recommendations for mobile application

### 6.1.4.1 General recommendations

In mobile applications, the sensor moves with the vehicle or moving machinery parts.

Below are some recommendations for defining the sensor position:

- position the sensor so the floor is excluded from its detection field to avoid undesired alarms
- installation height (from the ground to the center of the sensor): minimum 15 cm (5.9 in)
- suggested inclination: minimum 15°



### 6.1.4.2 For outdoor application

The general recommendations reported above are still valid in outdoor environments.

Before installing a sensor facing downwards, make sure there are neither liquids nor radar reflective materials on the floor.

#### Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:

- Make a cover to protect the sensor from rain, hail or snow, so that the drops do not fall directly on the sensor.
- Position the sensor so that it does not frame the ground where puddles might form.

**NOTICE:** Weather conditions outside specifications can prematurely age the device.

If the monitored area is free of static objects, the system is robust against a rainfall rate up to 45 mm/h.

#### Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.


## 6.1.5 Range of distances

### 6.1.5.1 Introduction

The detection distances at which the human body is guaranteed depend on the inclination of the sensor. Below are reported the three possible configurations and the relative range of distances (**D1** = start detection distance, **D2** = end of detection distance).

**Note:** these range of distances are valid only for field of view with classic shape.


### 6.1.5.2 Installation configurations



*Both the upper portion and the bottom portion of the field of view always intersect the ground.*

**D1** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)


**D2** = projection on the reference plane of the intersection point of the field of view at height X (where "X" is 0.6 m (19.68 ft))



*The field of view of the sensor never intersects the ground*

**D1 = 0**

**D2** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)



*The upper portion of the field of view of the sensor never intersects the ground.*

**D1** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)

**D2** = 5 m (16.4 ft)

### 6.1.6 Configuration parameters

#### 6.1.6.1 Introduction

For each sensor the programmable parameters are the following:

- number of detection fields
- detection field dependency

- for each detection field:
  - horizontal angular coverage
  - detection distance
  - safety working mode
  - static object detection function
  - restart timeout
  - Toff

### 6.1.6.2 Parameters table

#### General sensor parameters

Parameter	Min	Max	Default value	Unit of measure
Detection field dependency		Enabled, Disabled	Enabled	-
Anti-masking sensitivity		Disabled, Low, Medium, High	Low	-
Anti-masking distance	200	1000	1000	mm
Anti-rotation around axes		Disabled, Enabled	Disabled	-
Anti-rotation around axes - Tilt		Disabled, Enabled	Disabled	-
Anti-rotation around axes - Roll		Disabled, Enabled	Disabled	-
Muting group		None, Group 1, Group 2, both	Group 1	-

#### General detection field parameters



Parameter	Min	Max	Default value	Unit of measure
Detection distance of detection field 1	200	5000*	1000	mm
Detection distance of detection field 2	0	5000*	1000	mm
Detection distance of detection field 3	0	5000*	0	mm
Detection distance of detection field 4	0	5000*	0	mm
Horizontal angular coverage	0	100	45	degrees
Safety working mode		Access detection and restart prevention, Always-on access detection, Always-on restart prevention	Access detection and restart prevention	-
Static object detection		Enabled, Disabled	Disabled	-
Restart timeout	100	60000	4000	ms
TOFF	100	60000	100	ms
Restart signal type		Automatic, Manual, Safe manual	Automatic	-

**Note\*:** the sum of all the detection distances (for each sensor) cannot exceed 5000 mm.

### 6.1.6.3 Horizontal angular coverage



The horizontal angular coverage ranges from 10° to 100° for the entire field of view.

The horizontal angular coverage of the detection field must be wider than or equal to the horizontal angular coverage of the following detection fields.




#### 6.1.6.4 Detection distance

The detection distance of the first detection field starts from the sensor. The detection distance of one field starts where the one of the previous field ends.



The detection distance of one or more fields can be 0 (e.g., detection field 3). The first detection field with a detection distance other than 0 (e.g., detection field 1) must have a minimum detection distance of 500 mm.



## 6.2 Pro line sensors: S201A-W and S203A-W

### Contents

This section includes the following topics:

<b>6.2.1 Main features</b>	<b>147</b>
<b>6.2.2 Sensor field of view</b>	<b>149</b>
<b>6.2.3 Installation recommendations for stationary application</b>	<b>153</b>
<b>6.2.4 Installation recommendations for mobile application</b>	<b>156</b>
<b>6.2.5 Range of distances</b>	<b>157</b>
<b>6.2.6 Configuration parameters</b>	<b>158</b>
<b>6.2.7 Classic shape</b>	<b>159</b>
<b>6.2.8 Corridor shape</b>	<b>160</b>

### 6.2.1 Main features

#### 6.2.1.1 Feature list S201A-W sensors

<b>Model-type</b>	S201A-W
<b>Compatible control unit production line</b>	Core Line eXtended Line
<b>Safety function managed</b>	Access detection Restart prevention
<b>Safety working modes</b>	Access detection and restart prevention Always-on access detection Always-on restart prevention
<b>Application</b>	Stationary Mobile Vehicle
<b>Outdoor installation</b>	Yes

<b>Configuration tool</b>	Inxpect Safety Inxpect Safety Studio
<b>Access detection speed limit (stationary application)</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Access detection speed limit* (mobile application)</b>	For detection distance less than or equal to 4 m (13.12 ft): <ul style="list-style-type: none"> <li>• Min: 0.1 m/s (0.33 ft/s)</li> <li>• Max: 3 m/s (9.84 ft/s)</li> </ul> For detection distance greater than 4 m: <ul style="list-style-type: none"> <li>• Min: 0.1 m/s (0.33 ft/s)</li> <li>• Max: 2 m/s (6.56 ft/s)</li> </ul>
<b>Dynamic configuration available</b>	Up to 32**
<b>Static object detection option</b>	Yes

**Note\*:** only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

**Note\*\*:** for limitations that reduce the maximum number of dynamic configurations, see "Dynamic configuration presets" on page 34.

### 6.2.1.2 Feature list S203A-W sensors

<b>Model-type</b>	S203A-W
<b>Compatible control unit production line</b>	Core Line eXtended Line
<b>Safety function managed</b>	Access detection Restart prevention
<b>Safety working modes</b>	Access detection and restart prevention Always-on access detection Always-on restart prevention
<b>Application</b>	Stationary Mobile Vehicle
<b>Outdoor installation</b>	Yes, also with Surface Moisture Robustness function, see "Surface moisture robustness" on page 42
<b>Configuration tool</b>	Inxpect Safety Inxpect Safety Studio
<b>Access detection speed limit (stationary application)</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Access detection speed limit* (mobile application)</b>	For detection distance less than or equal to 4 m (13.12 ft): <ul style="list-style-type: none"> <li>• Min: 0.1 m/s (0.33 ft/s)</li> <li>• Max: 3 m/s (9.84 ft/s)</li> </ul> For detection distance greater than 4 m: <ul style="list-style-type: none"> <li>• Min: 0.1 m/s (0.33 ft/s)</li> <li>• Max: 2 m/s (6.56 ft/s)</li> </ul>
<b>Dynamic configuration available</b>	Up to 32**
<b>Static object detection option</b>	Yes

**Note\*:** only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

**Note\*\*:** for limitations that reduce the maximum number of dynamic configurations, see "Dynamic configuration presets" on page 34.

## 6.2.2 Sensor field of view


### 6.2.2.1 Dimensions for S201A-W sensors

Below are the maximum field of view dimensions **[A]** and the relative gray area **[B]**.

The gray area dimensions are the same for maximum angular coverage (as described in the figures below) and smaller coverages.


**Note:** the gray area dimensions described are related to the detection of humans.

#### Access detection function



Top view

## Restart prevention function




Top view

### 6.2.2.2 Position of the field of view for S201A-W sensors

The field of view is tilted of 2.5°


To understand the actual position of the sensor field of view consider the LED position:

- left with sensor LED on the right (with respect to the sensor center, facing the sensor)
- right with sensor LED on the left (with respect to the sensor center, facing the sensor)
- downward with sensor LED up



Top view with sensor inclination 0°.

Top view with sensor inclination 0°.



Side view with sensor inclination 0°.


### 6.2.2.3 Dimensions for S203A-W sensors

Below are the maximum field of view dimensions [A] and the relative gray area [B].

The gray area dimensions are the same for maximum angular coverage (as described in the figures below) and smaller coverages.


**Note:** the gray area dimensions described are related to the detection of humans.

#### Access detection function



Top view

## Restart prevention function




Top view

### 6.2.2.4 Position of the field of view for S201A-W sensors

The field of view is tilted of 1°


To understand the actual position of the sensor field of view consider the LED position:

- left with sensor LED on the right (with respect to the sensor center, facing the sensor)
- right with sensor LED on the left (with respect to the sensor center, facing the sensor)
- downward with sensor LED up



Top view with sensor inclination 0°.

Top view with sensor inclination 0°.



Side view with sensor inclination 0°.

## 6.2.3 Installation recommendations for stationary application

### 6.2.3.1 For access detection function (general)

**WARNING!** Take all necessary precautions to prevent people from climbing over and entering the area, whenever there is that risk.


Below are some recommendations for the sensor positioning for the access detection function:

- If the distance between the ground and the bottom portion of the field of view is greater than 20 cm (7.9 in), take precautions to make sure that even a person entering the dangerous area below the volume monitored by the field of view is still detected.
- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).
- If the height above the ground is less than 20 cm (7.9 in), install the sensor with an inclination of minimum 10° upwards.

### For access detection function (S203A-W, fw version 5.0)

For over-the-head installations, the line perpendicular to the sensor must intersect the reference plane. Below are some recommendations to be followed:

- installation height **[h]** must be greater than 2 m (6.56 ft)
- inclination **[α]** in the range [-90°; -60°]




### For access control of an entrance


If the sensor is used in access detection for monitoring a pedestrian entry in a confined area, the recommendations below should be taken into consideration:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 20 cm (7.9 in).
- The horizontal angular coverage must be 90°.
- The rotation around the x-axis must be 90°.
- The inclination must be 40° upwards.

Below is an example:



**⚠️ WARNING!** The horizontal angular coverage in the first 800 mm (31.5 in) of the field of view must be at least 60°. If this specification cannot be respected, take precautions to avoid the access of a human in the first 800 mm (31.5 in) of the field of view.



### 6.2.3.2 For restart prevention function

Below are some recommendations for the sensor positioning for the restart prevention function:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).
- If the height above the ground is less than 20 cm (7.9 in), install the sensor with an inclination of minimum 10° upwards.

The restart prevention function is effective if the sensor can detect a person's movements or their static residual movements. To detect people who are not standing or squatting, it is important that the sensor can clearly detect the person's chest.

Particular attention should be paid to the following situations:

- There are objects that limit or prevent the sensor from detecting motion.
- The sensor does not detect a sufficient portion of the body or does not properly detect the person's chest.

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 15 cm (5.9 in).


A validation procedure (see "Validate the safety functions" on page 68) must be performed when one or more of the above conditions are met.

If the conditions described above limit the performance of the sensor, take the following steps to reach an appropriate level of performance:

- Increase the **Restart timeout** parameter.
- Change the position of the sensors.
- Add more sensors.

If one or more of the above actions are taken, it is recommended to perform a validation procedure (see "Validate the safety functions" on page 68).

Below are some examples of situations where the above conditions are met (✓) or not met (✗). These examples are not meant to be exhaustive.



### 6.2.3.3 For outdoor application

The recommendations reported above for access detection and restart prevention functions are still valid in outdoor environments.

Before installing a sensor facing downwards, make sure there are neither liquids nor radar reflective materials on the floor.

#### Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:

- Make a cover to protect the sensor from rain, hail or snow, so that the drops do not fall directly on the sensor.
- Position the sensor so that it does not frame the ground where puddles might form.


**NOTICE:** Weather conditions outside specifications can prematurely age the device.

If the monitored area is free of static objects, the system is robust against a rainfall rate up to 45 mm/h.

#### Recommendations for covering the sensor

Below are some recommendations for creating and installing a sensor cover:

- height from sensor: 15 cm (6 in)
- width: minimum 30 cm (11.8 in), maximum 40 cm (15.7 in)
- protrusion from the sensor: minimum 15 cm (6 in), maximum 20 cm (7.9 in)
- water outflow: at the sides or behind but not in front of the sensor (the cover should be arched and/or tilted backwards)



#### Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.


### 6.2.4 Installation recommendations for mobile application

#### 6.2.4.1 General recommendations


In mobile applications, the sensor moves with the vehicle or moving machinery parts.

Below are some recommendations for defining the sensor position:

- position the sensor so the floor is excluded from its detection field to avoid undesired alarms
- installation height (from the ground to the center of the sensor): minimum 15 cm (5.9 in)
- suggested inclination: minimum 15° for S201A model, 10° for S203A model



S201A model sensors



S203A model sensors

#### 6.2.4.2 For outdoor application

The general recommendations reported above are still valid in outdoor environments.

Before installing a sensor facing downwards, make sure there are neither liquids nor radar reflective materials on the floor.

#### Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:

- Make a cover to protect the sensor from rain, hail or snow, so that the drops do not fall directly on the sensor.
- Position the sensor so that it does not frame the ground where puddles might form.

**NOTICE:** Weather conditions outside specifications can prematurely age the device.

If the monitored area is free of static objects, the system is robust against a rainfall rate up to 45 mm/h.

#### Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.


## 6.2.5 Range of distances

### 6.2.5.1 Introduction

The detection distances at which the human body is guaranteed depend on the inclination of the sensor. Below are reported the three possible configurations and the relative range of distances (**D1** = start detection distance, **D2** = end of detection distance).

**Note:** these range of distances are valid only for field of view with classic shape.


### 6.2.5.2 Installation configurations



Both the upper portion and the bottom portion of the field of view always intersect the ground.

**D1** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)


**D2** = projection on the reference plane of the intersection point of the field of view at height X (where "X" is 0.6 m (19.68 ft))



The field of view of the sensor never intersects the ground

**D1** = 0

**D2** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)



The upper portion of the field of view of the sensor never intersects the ground.

**D1** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)

**D2** = 5 m (16.4 ft)

## 6.2.6 Configuration parameters

### 6.2.6.1 Introduction

For each sensor the programmable parameters are the following:

- number of detection fields
- detection field dependency\*
- detection area shape
- for each detection field:
  - horizontal angular coverage
  - detection distance
  - safety working mode
  - static object detection function
  - restart timeout
  - TOFF
  - classic shape parameters
  - corridor shape parameters

**Note\*:** it can be set for each sensor only with Inxpect Safety Studio.

### 6.2.6.2 Parameters table

#### General sensor parameters

Parameter	Min	Max	Default value	Unit of measure
Detection field dependency	Enabled, Disabled		Enabled	-
Detection area shape	Classic, Corridor		Classic	-
Anti-masking sensitivity	Disabled, Low, Medium, High		Low	-
Anti-masking distance	200	1000	1000	mm
Anti-rotation around axes	Disabled, Enabled		Disabled	-
Anti-rotation around axes - Tilt	Disabled, Enabled		Disabled	-
Anti-rotation around axes - Roll	Disabled, Enabled		Disabled	-
Muting group	None, Group 1, Group 2, both		Group 1	-

#### General detection field parameters

Parameter	Min	Max	Default value	Unit of measure
Detection distance of detection field 1	500	5000*	1000	mm
Detection distance of detection field 2	0	5000*	1000	mm
Detection distance of detection field 3	0	5000*	0	mm
Detection distance of detection field 4	0	5000*	0	mm
Safety working mode	Access detection and restart prevention, Always-on access detection, Always-on restart prevention		Access detection and restart prevention	-
Static object detection	Enabled, Disabled		Disabled	-
Restart timeout	100	60000	4000	ms
TOFF	100	60000	100	ms
Restart signal type	Automatic, Manual, Safe manual		Automatic	-

**Note\*:** the sum of all the detection distances (for each sensor) cannot exceed 5000 mm.

#### Classic shape parameters

Parameter	Min	Max	Default value	Unit of measure
Horizontal angular coverage - left	0*	50	45	degrees
Horizontal angular coverage - right	0*	50	45	degrees

**Note\*:** the minimum horizontal angular coverage (left + right) is 10°.


## Corridor shape parameters

Parameter	Min	Max	Default value	Unit of measure
Left side	0*	4000	500	mm
Right side	0*	4000	500	mm


**Note\***: the minimum width (left + right) is 200 mm.

### 6.2.6.3 Detection distance

The detection distance of the first detection field starts from the sensor. The detection distance of one field starts where the one of the previous field ends.



The detection distance of one or more fields can be 0 (e.g., detection field 3). The first detection field with a detection distance other than 0 (e.g., detection field 1) must have a minimum detection distance of 200 mm.




## 6.2.7 Classic shape

### 6.2.7.1 Horizontal angular coverage

The classic shape allows you to set the horizontal angular coverage and, if desired, to make it asymmetric.

The horizontal angular coverage ranges from 10° to 100° for the entire field of view.

Each detection field can have its own symmetric/asymmetric horizontal angular coverage.



Examples of asymmetric horizontal angular coverage.


Conditions:

- The sensor axis must always be included in all the detection fields.
- The horizontal angular coverage of each detection field must be wider than, or equal to, the horizontal angular coverage of the following detection fields.
- The minimum field of view width is 10°.

## 6.2.8 Corridor shape

### 6.2.8.1 Width

The corridor shape allows to customize the shape of the field of view. Starting from the standard shape with maximum angular coverage, it is possible to crop it on the side with two flat surfaces. Each detection field can have its own corridor width.



Examples of corridor width.

Conditions:

- The sensor axis must always be included in all the detection fields.
- The corridor width of each detection field must be wider than, or equal to, the corridor width of the following detection fields.
- The minimum corridor width is 20 cm.

# 6.3 Omni line sensors: S202A-MC1, S202A-MC2, S202A-MC4

## Contents

This section includes the following topics:

6.3.1 Main features .....	161
6.3.2 Sensor field of view .....	162
6.3.3 Installation recommendations for stationary application .....	163
6.3.4 Installation recommendations for mobile application .....	164
6.3.5 Configuration parameters .....	164
6.3.6 Classic shape .....	166
6.3.7 Corridor shape .....	168
6.3.8 Range of distances .....	170
6.3.9 Cuboid shape .....	172

## 6.3.1 Main features

### 6.3.1.1 Feature list

<b>Model-type</b>	S202A-MC1 S202A-MC2 S202A-MC4
<b>Compatible control unit production line</b>	eXtended Line
<b>Safety function managed</b>	Access detection Restart prevention
<b>Safety working modes</b>	Access detection and restart prevention Always-on access detection Always-on restart prevention
<b>Application</b>	Stationary Mobile Vehicle
<b>Outdoor installation</b>	Yes, only stationary
<b>Configuration tool</b>	Inxpect Safety Studio
<b>Access detection speed limit (stationary application)</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Access detection speed limit* (mobile application)</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Dynamic configuration available</b>	Up to 16***
<b>Static object detection option</b>	Yes


**Note\*:** only the speed of the vehicle or of the part of machinery is considered. This is based on the assumption that the person recognizes the hazard and stands still.

**Note\*\*\*:** for limitations that reduce the maximum number of dynamic configurations, see "Dynamic configuration presets" on page 34.

## 6.3.2 Sensor field of view

### 6.3.2.1 Dimensions


#### Access detection function



Top view

Side view

#### Restart prevention function



Top view


Side view

## 6.3.3 Installation recommendations for stationary application


### 6.3.3.1 General recommendations

Below are some recommendations for the sensor positioning:

- The installation height (from the ground to the center of the sensor) must be greater than or equal to 20 cm (7.9 in).
- The sensor shall always be installed following one of these positions:
  - installation height **[h]** (from the reference plane to the center of the sensor) between 0.2 and 1.5 m (between 0.7 and 4.9 ft), with an inclination (tilt) in the range [-25, +25]°.



- installation height **[h]** (from the reference plane to the center of the sensor) between 2 and 3.2 m (between 6.6 and 10.5 ft), with an inclination (tilt) of -60°.



### 6.3.3.2 For access detection function

**⚠ WARNING! Take all necessary precautions to prevent people from climbing over and entering the area, whenever there is that risk.**

Below are some recommendations for the sensor positioning for the access detection function:

- If the distance between the ground and the bottom portion of the field of view is greater than 20 cm (7.9 in), take precautions to make sure that even a person entering the dangerous area below the volume monitored by the field of view is still detected.

### 6.3.3.3 For restart prevention function

The restart prevention function is effective if the sensor can detect a person's movements or their static residual movements. To detect people who are not standing or squatting, sensor must clearly detect the person's chest or at least a portion of 1 meter (3.28 ft) of the body.

Particular attention should be paid to the following situations:

- There are objects that limit or prevent the sensor from detecting motion.
- The sensor does not detect a sufficient portion of the body or does not properly detect the person's chest.

A validation procedure (see "Validate the safety functions" on page 68) must be performed when one or more of the above conditions are met.

If the conditions described above limit the performance of the sensor, take the following steps to reach an appropriate level of performance:

- Increase the **Restart timeout** parameter.
- Change the position of the sensors.
- Add more sensors.

If one or more of the above actions are taken, it is recommended to perform a validation procedure (see "Validate the safety functions" on page 68).

### 6.3.3.4 For outdoor application

The recommendations reported above for access detection and restart prevention functions are still valid in outdoor environments.

Before installing a sensor facing downwards, make sure there are neither liquids nor radar reflective materials on the floor.

#### Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:

- Make a cover to protect the sensor from rain, hail or snow, so that the drops do not fall directly on the sensor.
- Position the sensor so that it does not frame the ground where puddles might form.

**NOTICE:** Weather conditions outside specifications can prematurely age the device.

If the monitored area is free of static objects, the system is robust against the following rainfall rates:

- if the sensor has an installation height (from the reference plane to the center of the sensor) 0.2 and 1.5 m (between 0.66 and 4.9 ft), with an inclination (tilt) in the range [-25, +25]°:
  - up to 100 mm/h in Access Detection
  - up to 15 mm/h in Restart Prevention
- otherwise:
  - up to 10 mm/h, in Access Detection

#### Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.


## 6.3.4 Installation recommendations for mobile application

### 6.3.4.1 General recommendations

In mobile applications, the sensor moves with the vehicle or moving machinery parts.

Below are some recommendations for defining the sensor position:

- position the sensor so the floor is excluded from its detection field to avoid undesired alarms
- installation height (from the ground to the center of the sensor): minimum 15 cm (5.9 in)
- suggested inclination: 0°
- field of view shape: cuboid (Zmin: 15 cm; Zmax: 115 cm)



## 6.3.5 Configuration parameters

### 6.3.5.1 Introduction

For each sensor the programmable parameters are the following:

- detection field dependency\*
- detection area shape

- for each detection field:
  - horizontal angular coverage
  - detection distance
  - safety working mode
  - static object detection function
  - restart timeout
  - TOFF
  - classic shape parameters
  - corridor shape parameters
  - cuboid shape parameters

**Note\*:** for each sensor only for classic and corridor shapes; not configurable for cuboid shape.

### 6.3.5.2 Detection fields

The maximum number of detection fields is fixed for each model-type:

- S202A-MC1: 1 detection field
- S202A-MC2: 2 detection fields
- S202A-MC4: 4 detection fields

### 6.3.5.3 Parameters table

#### General sensor parameters

Parameter	Min	Max	Default value	Unit of measure
Detection field dependency	Enabled, Disabled		Enabled*	-
Detection area shape	Classic, Corridor, Cuboid		Classic	-
Pan				degrees
Tilt				degrees
Anti-masking sensitivity	Disabled, Low, Medium, High		Low	-
Anti-masking distance	200	500	500	mm
Anti-rotation around axes	Disabled, Enabled		Disabled	-
Anti-rotation around axes - Tilt	Disabled, Enabled		Disabled	-
Anti-rotation around axes - Roll	Disabled, Enabled		Disabled	-
Muting group	None, Group 1, Group 2, both		Group 1	-

**Note:** with cuboid shape of the detection fields, the detection field dependency is disabled and can not be enabled.

#### General detection field parameters

Parameter	Min	Max	Default value	Unit of measure
Safety working mode	Access detection and restart prevention, Always-on access detection, Always-on restart prevention		Access detection and restart prevention	-
Static object detection	Enabled, Disabled		Disabled	-
Restart timeout	100	60000	4000	ms
TOFF	100	60000	100	ms
Restart signal type	Automatic, Manual, Safe manual		Automatic	-

#### Classic shape parameters

Parameter	Min	Max	Default value	Unit of measure
Horizontal angular coverage - left	0*	50	40	degrees
Horizontal angular coverage - right	0*	50	40	degrees
Vertical angular coverage – top	0**	50	30	degrees
Vertical angular coverage - bottom	0**	50	30	degrees
Detection distance of detection field 1	200	5000***	1000	mm
Detection distance of detection field 2	0	5000***	1000	mm

Parameter	Min	Max	Default value	Unit of measure
Detection distance of detection field 3	0	5000***	0	mm
Detection distance of detection field 4	0	5000***	0	mm

**Note\*:** the minimum horizontal angular coverage (left + right) is 20°.

**Note\*\*:** the minimum vertical angular coverage (top + bottom) is 30°.

**Note\*\*\*:** the sum of all the detection distances (for each sensor) cannot exceed 5000 mm.

### Corridor shape parameters

Parameter	Min	Max	Default value	Unit of measure
Left side	0*	4000	500	mm
Right side	0*	4000	500	mm
Top side	0**	4000	500	mm
Bottom side	0**	4000	500	mm
Detection distance of detection field 1	200	5000***	1000	mm
Detection distance of detection field 2	0	5000***	1000	mm
Detection distance of detection field 3	0	5000***	0	mm
Detection distance of detection field 4	0	5000***	0	mm

**Note\*:** the minimum width (left + right) is 500 mm.

**Note\*\*:** the minimum height (top + bottom) is 500 mm.

**Note\*\*\*:** the sum of all the detection distances (for each sensor) cannot exceed 5000 mm.

### Cuboid shape parameters

Parameter	Min	Max	Default value	Unit of measure
X MIN	-5000*	5000	2000	mm
X MAX	-5000*	5000	3000	mm
Y MIN	-5000**	5000	Depends on the detection field	mm
Y MAX	-5000**	5000	Depends on the detection field	mm
Z MIN	0 ***	5000	0	mm
Z MAX	0 ***	5000	1000	mm
Cuboid line of sight	Enabled/Disabled		Enabled	mm
Show/hide full FOV	Show/hide full FOV		Show	mm
Cuboid rotation (pan) with respect to the sensor****	-180	+180	0	degrees

**Note\*:** the minimum depth (difference between X MIN and X MAX values) is 500 mm.

**Note\*\*:** the minimum width (difference between Y MIN and Y MAX) is 500 mm.

**Note\*\*\*:** the minimum height (difference between Z MIN and Z MAX) is 1000 mm.


**Note\*\*\*\*:** setting valid for the entire field of view of the sensor.

## 6.3.6 Classic shape

### 6.3.6.1 Horizontal angular coverage

The classic shape allows you to set the horizontal angular coverage and, if desired, to make it asymmetric. The horizontal angular coverage ranges from 10°20° to 100° for the entire field of view.

Each detection field can have its own symmetric/asymmetric horizontal angular coverage.



Examples of asymmetric horizontal angular coverage.


Conditions:

- The sensor axis must always be included in all the detection fields.
- The horizontal angular coverage of each detection field must be wider than, or equal to, the horizontal angular coverage of the following detection fields.
- The minimum field of view width is 20°.

### 6.3.6.2 Vertical angular coverage

It is possible to customize also the vertical angular coverage, and if desired, to make it asymmetric. The vertical angular coverage ranges from 30° to 90° for the entire field of view.

Each detection field can have its own symmetric/asymmetric vertical angular coverage.




Examples of asymmetric vertical angular coverage.

Conditions:


- The sensor axis must always be included in all the detection fields.
- The vertical angular coverage of each detection field must be wider than, or equal to, the vertical angular coverage of the following detection fields.
- The minimum field of view height is 30°.

### 6.3.6.3 Detection distance

The detection distance of the first detection field starts from the sensor. The detection distance of one field starts where the one of the previous field ends.



The detection distance of one or more fields can be 0 (e.g., detection field 3). The first detection field with a detection distance other than 0 (e.g., detection field 1) must have a minimum detection distance of 200 mm.




### 6.3.7 Corridor shape

#### 6.3.7.1 Width

The corridor shape allows to customize the shape of the field of view. Starting from the standard shape with maximum angular coverage, it is possible to crop it on the side with two flat surfaces. Each detection field can have its own corridor width.

The field of view is cut by a vertical surface at the end.



Examples of corridor width.


Conditions:

- The sensor axis must always be included in all the detection fields.
- The corridor width of each detection field must be wider than, or equal to, the corridor width of the following detection fields.
- The minimum corridor width is 50 cm.


### 6.3.7.2 Height

It is possible to customize also the height of the field of view. Starting from the standard shape with maximum vertical angular coverage, it is possible to crop it on the top/bottom with two flat surfaces. Each detection field can have its own corridor height.

The field of view is cut by a vertical surface at the end.



Examples of corridor height.




Example of corridor width and height.

Conditions:


- The sensor axis must always be included in all the detection fields.
- The corridor height of each detection field must be wider than, or equal to, the corridor height of the following detection fields.
- The minimum corridor width is 50 cm.

### 6.3.7.3 Detection distance

The detection distance of the first detection field starts from the sensor. The detection distance of one field starts where the one of the previous field ends.



The detection distance of one or more fields can be 0 (e.g., detection field 3). The first detection field with a detection distance other than 0 (e.g., detection field 1) must have a minimum detection distance of 200 mm.




## 6.3.8 Range of distances

### 6.3.8.1 Introduction

The detection distances at which the human body is guaranteed depend on the inclination of the sensor. Below are reported the three possible configurations and the relative range of distances (**D1** = start detection distance, **D2** = end of detection distance).

**Note:** these range of distances are valid only for field of view with classic shape.


### 6.3.8.2 Installation configurations



*Both the upper portion and the bottom portion of the field of view always intersect the ground.*

**D1** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)


**D2** = projection on the reference plane of the intersection point of the field of view at height X (where "X" is 1 m (3.28 ft) )



*The field of view of the sensor never intersects the ground*

**D1 = 0**

**D2** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)



*The upper portion of the field of view of the sensor never intersects the ground.*


**D1** = projection on the reference plane of the intersection point of the field of view at a height of 0.2 m (6.56 ft)

**D2** = 5 m (16.4 ft)

## 6.3.9 Cuboid shape

### 6.3.9.1 Introduction

The cuboid shape allows you to shape each detection field as a cuboid. Starting from the standard shape of the field of view with maximum angular coverages, the cuboid is defined by its own dimensions and it can be positioned anywhere within the field of view of the sensor.



**⚠️ WARNING! Position the cuboid away from the limits of the field of view to avoid irregular cuboid shapes and tolerance area effects.**

**⚠️ WARNING! A detection signal is activated only if at least 1 m (0.32 ft) of human body is detected.**


### 6.3.9.2 Cuboid detection fields

The detection fields available for each sensors are independent from each other and there are no constraints on the positions of the cuboids, which can also be overlapped and/or included within each other. An area in common with two detection fields (e.g. detection field 1 and detection field 2), belongs to the detection field with lower numbering (detection field 1 in the previous example).

The detection field is numbered to be identified in the system and matched with the relative detection signal.

### 6.3.9.3 Dimensions

The x, y and z dimensions of the cuboid can be set. The minimum value is 500 mm for y and x dimension and 1000 mm for z dimension.





**⚠️ WARNING! At the limits of the cuboid there is a tolerance area where the actual detection of a moving object/person depends on the characteristics of the object itself. Validate the system thoroughly to check the influence of the tolerance area.**

### 6.3.9.4 Cuboid line of sight

The area of the field of view from the sensor to the vertexes of the front face of the cuboid (*line of sight*) can be included or excluded from the detection field, for all the detection fields of the sensor and for a specific dynamic configuration. When included, the line of sight belongs to detection field 1.

By default the line of sight is included. If the cuboid line of sight is excluded, graphically it is not visible in the application and the sensor will not trigger an alarm if a movement is detected in the line of sight area.



Example of cuboid detection field with the line of sight included and excluded.

### 6.3.9.5 Reference plan

If there are two walking floors (reference planes) at different heights in the area to be monitored:

- if the distance (in height) between the walking floors is greater than 1 m, it is recommended to install two sensors to cover the floors.
- if the distance (in height) is less than or equal to 1 m, the reference plane to be entered during configuration is always the lower of the two planes, and the installation height should be calculated in relation to it accordingly.

## 6.4 Plug&Safe sensors: S202A-MS

### Contents

This section includes the following topics:

<b>6.4.1 Main features</b>	173
<b>6.4.2 Installation recommendations</b>	174
<b>6.4.3 Configuration parameters</b>	174

## 6.4.1 Main features

### 6.4.1.1 Introduction

The S202A-MS sensor is designed to perform the Safeguarding SPE (Sensitive Protective Equipment): detect the access of a person in a dangerous area (e.g. through a gate).

### 6.4.1.2 Feature list


<b>Model-type</b>	S202A-MS
<b>Compatible control unit production line</b>	eXtended Line
<b>Safety function managed</b>	Access detection
<b>Safety working modes</b>	Always-on access detection
<b>Application</b>	Stationary
<b>Outdoor installation</b>	Yes
<b>Configuration tool</b>	Inxpect Safety Studio
<b>Access detection speed limit</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Dynamic configuration available</b>	1
<b>Static object detection option</b>	No
<b>T<sub>OFF</sub></b>	1 s

## 6.4.2 Installation recommendations

### 6.4.2.1 General recommendations

The sensor shall always be installed following this position:

- installation height **[h]** (from the reference plane to the center of the sensor) between 1 and 2.5 m (between 3.3 and 8.2 ft), with an inclination (tilt) of -40°.



### 6.4.2.2 For access detection function

**⚠ WARNING!** Take all necessary precautions to prevent people from climbing over and entering the area, whenever there is that risk.

Below are some recommendations for the sensor positioning for the access detection function:

- If the distance between the ground and the bottom portion of the field of view is greater than 20 cm (7.9 in), take precautions to make sure that even a person entering the dangerous area below the volume monitored by the field of view is still detected.

### 6.4.2.3 For outdoor application

The general recommendations reported above are still valid in outdoor environments.

#### Position exposed to precipitation

If the sensor installation position might be exposed to precipitation that can cause undesired alarms, it is recommended to take the following precautions:

- Make a cover to protect the sensor from rain, hail or snow, so that the drops do not fall directly on the sensor.
- Position the sensor so that it does not frame the ground where puddles might form.

**NOTICE:** Weather conditions outside specifications can prematurely age the device.

If the monitored area is free of static objects, the system is robust against a rainfall rate up to 10 mm/h.

#### Position not exposed to precipitation

If the installation position of the sensor is not exposed to precipitation, no special precautions are required.


## 6.4.3 Configuration parameters

### 6.4.3.1 Parameters table

Parameter	Min	Max	Default value	Unit of measure
Installation height	1000	2500	1000	mm
X MAX (field of view length)	500	4000	4000	mm
Z MIN (gap from the reference plane)	0	500	0	mm
Sensor rotation (pan - z)	-180	180	0	degrees

### 6.4.3.2 Detection field definition and configuration

Below is a graphic representation of the field of view and the programmable parameters.



Parameter	Part	Value
<b>Installation height</b> (from the reference plane <b>R</b> )	<b>h</b>	From 1 to 2.5 m
<b>Field of view length</b>	<b>FL</b>	From the sensor to [0.5, 4] m
<b>Field of view height</b> (from the reference plane <b>R</b> )	<b>FH</b>	From [0, 50] cm to the sensor

The field of view width (**FW**) is fixed from -5 cm to 5 cm.

## 6.5 Plug&Safe sensors: S202A-MV

### Contents

This section includes the following topics:

<b>6.5.1 Main features</b>	<b>176</b>
<b>6.5.2 Installation recommendations</b>	<b>176</b>
<b>6.5.3 Configuration parameters</b>	<b>177</b>

## 6.5.1 Main features

### 6.5.1.1 Introduction

The S202A-MV sensor is designed to perform the Presence Sensing SPE (Sensitive Protective Equipment): to prevent the machinery from restarting if people are in a dangerous area (e.g. in a closed cell).

### 6.5.1.2 Feature list


<b>Model-type</b>	S202A-MV
<b>Compatible control unit production line</b>	eXtended Line
<b>Safety function managed</b>	Restart prevention
<b>Safety working modes</b>	Access detection and restart prevention
<b>Application</b>	Stationary
<b>Outdoor installation</b>	No
<b>Configuration tool</b>	Inxpect Safety Studio
<b>Access detection speed limit</b>	Min: 0.1 m/s (0.33 ft/s) Max: 1.6 m/s (5.25 ft/s)
<b>Dynamic configuration available</b>	1
<b>Static object detection option</b>	No

## 6.5.2 Installation recommendations

### 6.5.2.1 General recommendations

The sensor shall always be installed following this position:

- installation height **[h]** (from the reference plane to the center of the sensor) between 2.5 and 3 m (between 8.2 and 9.8 ft), with an inclination (tilt) of -60°.



### 6.5.2.2 For restart prevention function

The restart prevention function is effective if the sensor can detect a person's movements or their static residual movements. To detect people who are not standing or squatting, sensor must clearly detect the person's chest or at least a portion of 1 meter (3.28 ft) of the body.

Particular attention should be paid to the following situations:

- There are objects that limit or prevent the sensor from detecting motion.
- The sensor does not detect a sufficient portion of the body or does not properly detect the person's chest.

A validation procedure (see "Validate the safety functions" on page 68) must be performed when one or more of the above conditions are met.

If the conditions described above limit the performance of the sensor, take the following steps to reach an appropriate level of performance:

- Increase the **Restart timeout** parameter.
- Change the position of the sensors.
- Add more sensors.

If one or more of the above actions are taken, it is recommended to perform a validation procedure (see "Validate the safety functions" on page 68).

**⚠ WARNING! With more than one S202A-MV sensors, two adjacent detection fields must overlap by at least 30 cm (0.98 in).**

If there are two walking floors (reference planes) at different heights in the area to be monitored:

- if the distance (in height) between the walking floors is greater than 1 m, it is recommended to install two sensors to cover the floors.
- if the distance (in height) is less than or equal to 1 m, the reference plane to be entered during configuration is always the lower of the two planes, and the installation height should be calculated in relation to it accordingly.

## 6.5.3 Configuration parameters


### 6.5.3.1 Parameters table

Parameter	Min	Max	Default value	Unit of measure
Installation height	2500	3000	2500	mm
X MAX (field of view length)	500	3500	3500	mm
Z MAX	1000	Field of view height	2000	mm
Z MIN (gap from the reference plane)	0	5000	0	mm
Y MAX (field of view width)	0*	2000	200	mm
Y MIN (field of view width)	0*	2000	200	mm
Sensor rotation (pan - z)	-180	180	0	degrees
Restart timeout	100	60000	4000	ms

**Note\***: the minimum width (left + right) is 500 mm.

### 6.5.3.2 Detection field definition and configuration

Below is a graphic representation of the field of view and the programmable parameters.



Setting	Part	Value
<b>Sensor installation height</b> (from the reference plane)	<b>h</b>	From 2.5 to 3 m
<b>Field of view length</b>	<b>FL</b>	From the sensor to [0.5, 4] m
<b>Field of view height</b> (from the reference plane <b>R</b> )	<b>FH</b>	From [0, 50] cm to the sensor
<b>Field of view width</b>	<b>FW</b>	From [-200*, 0] cm to [0, 200*] cm. Minimum: 50 cm

**Note\***: value for the maximum height of installation; the value decreases proportionally with a decrease in installation height.

# 7. Appendix B

## 7.1 Other information

### Contents

This section includes the following topics:

<b>7.1.1 System software</b>	<b>179</b>
<b>7.1.2 Disposal</b>	<b>180</b>
<b>7.1.3 Service and warranty</b>	<b>180</b>
<b>7.1.4 Intellectual property</b>	<b>180</b>
<b>7.1.5 Checklist for installing ESPE</b>	<b>181</b>

### 7.1.1 System software

#### 7.1.1.1 Introduction

The aim of this appendix is to provide and clarify the information related to the system software. It includes the information necessary for the integrator during the installation and integration in accordance with IEC 61508-3 Annex D.

Considering that Inxpect SRE 200 Series is an embedded system provided with a firmware already deployed on board, no software integration is required by the system installer or by the end user. The following paragraphs analyzes all the information required in IEC 61508-3 Annex D.

#### 7.1.1.2 Configuration

The system configuration can be performed by means of a PC-based configuration tool (Inxpect Safety or Inxpect Safety Studio application)

The system configuration is described in "Installation and usage" on page 57.

#### 7.1.1.3 Competence

Although no competence is required for software integration, a skilled person is required for system installation and configuration, as described in "Installation and use procedures" on page 57.

#### 7.1.1.4 Installation instructions

The firmware is already deployed on the hardware, the PC-based configuration tool includes a self-explanatory setup installer.

#### 7.1.1.5 Outstanding anomalies

At the moment of the issue of this document, no software/firmware anomalies or bugs are known.

#### 7.1.1.6 Backward compatibility

Backward compatibility is guaranteed.

#### 7.1.1.7 Change control

Any change proposal suggested by the integrator or the end user should be forwarded to Inxpect and evaluated by the Product Owner.

#### 7.1.1.8 Implemented security measures

Firmware upgrade packages are managed by the Inxpect Technical Support and are signed to prevent the use of unverified binary files.

## 7.1.2 Disposal



Inxpect SRE 200 Series contains electrical parts. As set forth in European Directive 2012/19/EU, do not dispose of the product with unsorted urban waste materials.



It is the responsibility of the owner/distributor to dispose of these products, as well as other electrical and electronic equipment, through specific waste collection facilities indicated by the waste disposal services.

Correct disposal and recycling will contribute to the prevention of potentially harmful consequences to the environment and human health.

For more detailed information about disposal, contact the waste disposal services or the representative from whom you purchased the product.

For instructions on how to disassemble the components for proper and sustainable disposal, download the disassembly instructions from the <https://www.inxpect.com/en/downloads> website.

## 7.1.3 Service and warranty

### 7.1.3.1 Technical Support

Inxpect SpA  
Via Serpente, 91  
25131 Brescia (BS) - Italy  
Tel: +39 030 5785105  
email: [safety-support@inxpect.com](mailto:safety-support@inxpect.com)  
website: [www.inxpect.com](http://www.inxpect.com)

### 7.1.3.2 How to return the product

If necessary, complete the request with information about the return on the website [www.inxpect.com/industrial/rma](http://www.inxpect.com/industrial/rma). Then, return the product to the local distributor or exclusive distributor. **Use the original packaging. Shipping costs are at the customer's expense.**

Area distributor	Manufacturer
<i>Note distributor information here:</i>	Inxpect SpA Via Serpente, 91 25131 Brescia (BS) Italy <a href="http://www.inxpect.com">www.inxpect.com</a>

### 7.1.3.3 Service and warranty

Refer to [www.inxpect.com](http://www.inxpect.com) for the following information:

- terms, exclusions and cancellation of the warranty
- general conditions of the Return Merchandise Authorization (RMA)

## 7.1.4 Intellectual property

### 7.1.4.1 Trademarks

EtherCAT® and Safety over EtherCAT® are registered trademarks and patented technologies licensed by Beckhoff Automation GmbH, Germany.

### 7.1.4.2 US patents

Inxpect products are protected by the following US patents:

- US Patent #10761205
- US Patent #11402481
- US Patent #11282372
- US Patent #11422227
- US Patent #11579249
- US Patent #11835616
- US Patent #11982983

- US Patent #11846724
- US Patent #11988739
- US Patent #11041937

Other US patents are pending.

## 7.1.5 Checklist for installing ESPE

### 7.1.5.1 Introduction


Collecting the details relating to the following items is mandatory no later than when the system is commissioned for the first time.

This checklist should be kept with the machinery documentation to serve as a reference during periodic tests.

This checklist does not replace the initial commissioning or regular inspection by qualified safety personnel.

### 7.1.5.2 Checklist

Question	Yes	No
Have the safety rules and regulations been observed in compliance with the directives and standards applicable to the machinery?		
Are the applied directives and standards listed in the declaration of conformity?		
Does the ESPE comply with the required PL/SIL claim limit and PFHd in accordance with EN ISO 13849-1/EN 62061 and the required type in accordance with EN 61496-1?		
Is access to the dangerous area only possible through the detection field of the ESPE?		
Have appropriate measures been taken to detect any persons in the dangerous area?		
Have the safety devices been secured or locked to prevent their removal?		
Are additional mechanical protective measures fitted and secured against manipulation which prevent reaching below, above, or around the ESPE?		
Has the maximum stopping time of the machinery been measured, specified, and documented?		
Has the ESPE been mounted such that the required minimum distance from the nearest hazardous point has been achieved?		
Are the ESPE devices properly mounted and secured against manipulation after adjustment?		
Are the required protective measures against electric shock in effect (protection class)?		
Is the control switch for resetting the protective devices (ESPE) or restarting the machinery present and correctly installed?		
Are the outputs of the ESPE integrated according to the required PL/SIL in accordance with EN ISO 13849-1/EN 62061, and does the integration correspond to the circuit diagrams?		
Has the protective function been checked in compliance with the test notes of this documentation?		
Are the specified protective functions effective at every operating mode that can be set?		
Does the ESPE activate the switching elements?		
Is the ESPE effective over the entire period of the dangerous state?		
Once initiated, will a dangerous state be stopped when switching the ESPE on or off, when changing the operating mode, or when switching to another protective device?		



Inxpect SRE 200 Series  
Instruction manual v1.10  
DEC 2025  
Inxpect SAF-IM-200S\_7\_00047\_en\_v1.10  
Copyright © 2021-2025 Inxpect SpA

**Inxpect SpA**  
Via Serpente, 91  
25131 Brescia (BS)  
Italy  
[www.inxpect.com](http://www.inxpect.com)  
[safety-support@inxpect.com](mailto:safety-support@inxpect.com)  
+39 030 5785105